



User Manual
Type II ADSL 2 + CPE / IAD
T2-B-Gawv1.4U10Y-BI
V1.00

Contents

1	Introduction	1
1.1	Packing List	1
1.2	Safety Cautions	1
1.3	LEDs and Interfaces	2
2	Hardware Installation	5
3	Web Configuration Management	7
3.1	Preparation before Login	7
3.1.1	Setup	7
3.1.2	Setting up WAN and LAN connections	7
3.1.3	PC Network Configuration	7
3.1.4	Connection between the Modem and PC	9
3.2	Login in to the Modem	10
3.3	Home	11
3.3.1	Overview	11
3.3.2	System Log	15
3.3.3	Troubleshooting	16
3.4	Configuration	17
3.4.1	Wireless Network	17
3.4.2	Internet Connection	23
3.4.3	Local Network (LAN)	62
3.4.4	Voice Configuration	66
3.4.5	DHCP Server	75
3.4.6	DHCP Relay	81
3.4.7	IPv6 Prefix	82
3.5	Security	83
3.5.1	IP Filtering	83
3.5.2	Port Forwarding	85
3.5.3	Virtual Server	86
3.6	Services	87
3.6.1	IGMP Proxy	87
3.6.2	IPv4 Routing	88
3.6.3	IPv6 Routing	90
3.6.4	Quality of Service	91
3.6.5	Mac Filtering	94

3.7	DSL Home	98
3.7.1	Management Server	98
3.7.2	CWM Parameters	101
3.8	Port Statistics	101
3.8.1	Voipfxs0	101
3.8.2	Voipcmdstat	104
3.8.3	DSL	106
3.8.4	Ethernet0/1/2/3	109
3.8.5	Wireless	111
3.9	Admin	113
3.9.1	Firmware Upgrade	113
3.9.2	Back & Restore	114
3.9.3	Reboot	115
3.9.4	Remote Access	115
3.9.5	Lan Access	116
3.9.6	Change Password	117
3.9.7	Time Zone	117
4	Network Topology	120
4.1	PPP over ATM (PPPoA) Mode	120
4.2	PPP over Ethernet (PPPoE) Mode	121
4.3	RFC2684 (Bridged) + Fixedly-Assigned IP Address Mode	123
4.4	RFC2684 (Bridged) + DHCP Mode	124
4.5	RFC2684 (Routed) + NAT Mode	125
4.6	External PPPoE Dial-up Mode	126

1 Introduction

The T2-B-Gawv1.4U10Y.BI is an ADSL2+ access device that supports multiple line modes. It supports ADSL2/ADSL2+ and is backward compatible to ADSL. It also offers auto-negotiation capability for different standards (e.g., G.dmt, T1.413 Issue 2) according to the settings of digital subscriber line access multiplexer (DSLAM) in the central office. It provides four 10/100Base-T Ethernet interfaces and one USB interface at the user end. By utilizing the high-speed ADSL connection, the T2-B-Gawv1.4U10Y.BI can provide broadband connectivity to the Internet, downstream up to 24 Mbps and upstream up to 1 Mbps.

The device supports WLAN access, such as WLAN AP or WLAN device, to the Internet. It complies with IEEE 802.11, 802.11b/g specifications, WEP, WPA, and WPA2 security specifications.

1.1 Packing List

- 1 x T2-B-Gawv1.4U10Y.BI
- 1 x External Splitter
- 1 x Power Adapter
- 2 x Telephone Cables (RJ-11)
- 1 x Ethernet Cables (RJ-45)
- 1 x Quick Start Guide
- 1 x Driver and Utility Software CD (With Motive Client Software)

1.2 Safety Cautions

Follow the following instructions to prevent the device from risks and damage caused by fire or electric power:


- Use volume labels to mark the type of power.
- Use the power adapter packed within the device package.
- Pay attention to the power load of the outlet or prolonged lines. An overburden power outlet or damaged lines and plugs may cause electric shock or fire accident. Check the power cords regularly. If you find any damage, replace it at once.
- Proper space left for heat dissipation is necessary to avoid damage caused by overheating to the device. The long and thin holes on the device are

designed for heat dissipation to ensure that the device works normally. Do not cover these heat dissipation holes.

- Do not put this device close to a place where a heat source exists or high temperature occurs. Avoid the device from direct sunshine.
- Do not put this device close to a place where it is over damp or watery. Do not spill any fluid on this device.
- Do not connect this device to any PCs or electronic products, unless our customer engineer or your broadband provider instructs you to do this, because any wrong connection may cause power or fire risk.
- Do not place this device on an unstable surface or support.

1.3 LEDs and Interfaces

Front panel




The following table describes the LEDs of the device.

LEDs	Color	Status	Description
Power	Green	On	The device is powered on.
		Off	The device is powered off.
	Red	On	The device is initializing.
		Blinks	The firmware is upgrading.
DSL	Green	On	The initial self-test of the unit is normal and ready.
		Blinks	The device is detecting itself.
		Off	The initial self-test is failed.
Internet	Green	On	The device has successful Internet connection.
		Blinks	Data is being transmitted on the Internet.
		Off	The Internet connection is failed or DSL has no synchronization.
	Red	On	The device is dialing up before obtaining IP address successfully by PPP.

LEDs	Color	Status	Description
LAN4/3/2/1	Green	On	The device has successful Ethernet connections.
		Blinks	Data is being transmitted through the LAN interface.
		Off	The LAN connection is not established.
WLAN	Green	On	The connection of WLAN interface is normal.
		Blinks	Data is being transmitted through the WLAN interface.
		Off	No WLAN connection.
WPS	Green	On	The WPS is active.
		Blinks	The WPS is active, waiting for the remote client to establish connection.
		Off	The WPS is inactive.
VoIP1	Green	On	The VoIP phone is registered.
		Blinks	The phone is off-hook.
		Off	The VoIP phone is not registered.
USB_H1	Green	On	The USB connection is normal.
		Blinks	Data is being transmitted through the USB interface.
		Off	The USB connection is failed.

Rear panel



The following table describes the interfaces of the device.

Interface	Description
○	Power switch, power on or power off the device.
Power	Power interface, for connecting to the power adapter of 12 V DC, 1 A.

Interface	Description
WLAN	WLAN switch, switch on or switch off the WLAN function.
Reset	Reset to the factory defaults. Keep the device powered on and push a paper clip into the hole for over 3 seconds, then release it. The configuration is restored to the factory defaults.
WPS	WPS switch, switch on or switch off the WPS function.
USB	USB Host Port, for connecting the device those have USB Device Port (Like Pen Drive).
LAN1/2/3/4	RJ-45 interfaces, for connecting to the Ethernet interface of PC or Ethernet devices through the Ethernet cable.
Internet	RJ-11 interface for connecting to the telephone set through the telephone cable.
FXS	Connect to phones for VoIP application.

2 Hardware Installation

Step 1 Connect the **Internet** interface of the device and the **Modem** interface of the splitter through a telephone cable. Connect the phone to the **Phone** interface of the splitter through a telephone cable. Connect the incoming line to the **Line** interface of the splitter.

The splitter has three interfaces:

- **Line**: Connect to a wall phone interface (RJ-11 jack).
- **Modem**: Connect to the DSL interface of the device.
- **Phone**: Connect to a telephone set.

Step 2 Connect the **LAN** interface of the device to the network card of the PC through an Ethernet cable (MDI/MDIX).



Note:

Use twisted-pair cables to connect with the Hub or Switch.

Step 3 Plug one end of the power adapter to the wall outlet and connect the other end to the **Power** interface of the device.

Connection 1

The following connection method is recommended.

Figure 1 displays the application diagram for the connection of the router, PC, splitter and the telephone sets, and no telephone set is placed before the splitter.




Figure 1 Connection 1 (No phone is installed before a splitter)

Connection 2

Figure 2 displays the application diagram for the connection of the router, PC, splitter and the telephone sets, and a telephone set is placed before the splitter.




Figure 2 Connection 2 (A phone is installed closed to the splitter)



Note:

When connection 2 is used, the filter must be installed close to the telephone cable. See Figure 2. Do not use the splitter to replace the filter.

Installing a telephone directly before the splitter may lead to failure of connection between the device and the central office, or failure of Internet access, or slow connection speed. If you really need to add a telephone set before the splitter, you must add a microfilter before a telephone set. Do not connect several telephones before the splitter or connect several telephones with the microfilter.

3 Web Configuration Management

3.1 Preparation before Login

Before accessing the modem, ensure the communication between PC and the modem is normal.

3.1.1 Setup

Connecting your PC or home network with the modem is a simple procedure, varying slightly depending on the operating system (OS). This chapter helps you to seamlessly integrate modem with your PC or home network. In most cases, the setup procedure described below is unnecessary. For example, the default DHCP setting in Windows 2000 is client, requiring no further modification. However, it is advised to follow the setup procedure described below to verify that the communication parameters and the physical cable connections are valid or correct.

3.1.2 Setting up WAN and LAN connections

WAN Connection

Your PC can connect to the Internet by ADSL. Connect its Internet socket to the wall socket through a telephone cable. If it has an Ethernet socket for the wide area network (WAN), connect it to the external ADSL or to the Ethernet socket through an Ethernet cable.

LAN Connection

Your PC can connect to the gateway with the LAN interface. Use an Ethernet cable to establish the connection between an LAN interface of your modem and the network card of your PC.

3.1.3 PC Network Configuration

Each network interface on the PC should either be configured with a statically defined IP address and a DNS address, or should be instructed to automatically obtain an IP address from the network DHCP server. The modem provides a DHCP server on the LAN side and it is recommended to configure your LAN to obtain its IP address and the IP address of the DNS server automatically.

This configuration principle is identical but operations are differently on each OS.

Figure 3 displays the TCP/IP Properties dialog box in the Windows XP system.




Figure 3

Windows XP

- (1) Open the Control Panel and click **Network Connections**.
- (2) Right-click the Ethernet connection icon and choose **Properties** from the shortcut menu.
- (3) On the **General** tab, select the **Internet Protocol (TCP/IP)** component, and click **Properties**. The **Internet Protocol (TCP/IP) Properties** window appears.
- (4) Select **Obtain an IP address automatically**.
- (5) Select **Obtain DNS server address automatically**.
- (6) Click **OK** to save the settings.

Windows 2000/98/Me

- (1) Open the Control Panel and click **Network and Dialing Connections**.
- (2) Right-click the **Ethernet connection** icon and choose **Properties** from the shortcut menu. The **Connection Properties** window appears.

- (3) Select the **Internet Protocol (TCP/IP)** component and click **Properties**.
- (4) The **Internet Protocol (TCP/IP) Properties** window appears.
- (5) Select **Obtain an IP address automatically**.
- (6) Select **Obtain DNS server address automatically**.
- (7) Click **OK** to save the settings.

Windows NT

- (1) Open the Control Panel and click **Network**.
- (2) On the **Protocol** tab, select the **Internet Protocol (TCP/IP)** component, and click **Properties**.
- (3) On the **IP Address** tab, select the **Obtain an IP address automatically** option.
- (4) On the **DNS** tab, ensure that no DNS server is defined in the **DNS Service Search Order** box and that no suffix is defined in the **Domain Suffix Search Order** box.

Linux

- (1) Login in to the system as a super user, by entering **su** in the terminal window.
- (2) Enter **vi /etc/sysconfig/network-script/ifcfg-eth0** to modify the eth0 network devices and assign IP addresses.
- (3) Enter **ifconfig** to view the newly assigned IP addresses.

3.1.4 Connection between the Modem and PC

The procedure of checking the connection between the modem and PC is as follows:

- (1) Configure the IP address of the PC as 192.168.1.X (2~254), netmask as 255.255.255.0, and gateway address as 192.168.1.1 (for a customized version, configure them according to the actual version).
- (2) Enter **arp -a** in the DOS window to check whether the PC can read the MAC address of the DSL. See Figure 4.

```
C:\Documents and Settings\Administrator>arp -a
Interface: 192.168.1.56 on Interface 0x10000003
Internet Address      Physical Address      Type
192.168.1.1           00-1e-e3-00-2a-31     dynamic
C:\Documents and Settings\Administrator>_
```

Figure 4

- (3) Ping the management IP address (by default, 192.168.1.1) of the modem.

```
C:\Documents and Settings\Administrator>arp -a
Interface: 192.168.1.56 on Interface 0x1000003
 Internet Address      Physical Address      Type
 192.168.1.1           00-1e-e3-00-2a-31    dynamic

C:\Documents and Settings\Administrator>ping 192.168.1.1
Pinging 192.168.1.1 with 32 bytes of data:
Reply from 192.168.1.1: bytes=32 time<10ms TTL=128
Reply from 192.168.1.1: bytes=32 time<10ms TTL=128
Reply from 192.168.1.1: bytes=32 time<10ms TTL=128
Reply from 192.168.1.1: bytes=32 time<10ms TTL=128
Ping statistics for 192.168.1.1:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\Documents and Settings\Administrator>
```

If the PC can read the MAC address of the device and ping the management IP address of the device successfully, the connection between the modem and PC is normal.



Note:

When you manage the device through Web, you must keep the power of the device on. Otherwise, the device may be damaged.

3.2 Login in to the Modem

- (1) Open the Internet Explorer and enter <http://192.168.1.1>.
- (2) Enter the user name and a password. See Figure 5. The default user name and password are **admin** and **admin** respectively.



Figure 5

Click **OK** and the main interface appears.



After logging in to the modem as a super user, you can check, configure, and modify all the settings. You can also diagnose the device system.

3.3 Home

Click **Home** to enter system information page. On the left page, there are three options: **Overview**, **System Log**, and **Troubleshooting**.

3.3.1 Overview

This page displays the current status and configuration of the system. It contains the status of the modem. Such as, firmware version, system uptime, downstream data rate, upstream data rate, DSL status, wireless and voice status.

3.3.1.1 Basic

Choose **Overview** > **Basic** and the following page appears.

Overview
Basic [Advanced](#)

System Information

Model Name	T2-B-Gawv1.4U10Y-BI
Firmware Version	10.4.3.12.12
System Up time	00:00:46s

Internet Connection

DSL Status	Not Connected
Downstream Data Rate	0 kbps
Upstream Data Rate	0 kbps
Max Att Downstream Rate	0 kbps
Max Att Upstream Rate	0 kbps

Wireless Settings

Status	Disable
SSID	BSNL_AP
Channel	1
Security	128 bit WEP

LAN Port

Mac Address	00:26:15:50:16:00
IP Address	192.168.1.1
DHCP server	On
Subnet Mask	255.255.255.0

Voice

Status	Enabled
Registration Status	Unknown
Phone Numbers-Channel 1	1

[\[Go To Advanced view\]](#)

The following table describes the parameters of this page.

Field	Description
System Information	
Model Name	It displays the model name of the modem.
Firmware Version	The software version of the modem.
System Up time	Uptime of the modem.
Internet Connection	

Field	Description
DSL Status	The status of the ADSL port.
Downstream Data Rate	Down line rate.
Upstream Data Rate	Up line rate.
Wireless Settings	
Status	The status of the wireless network.
SSID	Service set identification (SSID) is a unique name to identify the modem in the wireless LAN.
LAN Port	
Mac Address	The MAC address of the modem.
IP Address	The IP address of the modem.
DHCP server	The current status of the DHCP server.
Voice	
Status	The VoIP status.
Registration Status	It displays the registration status of VoIP application.

**Note:**

The firmware version displayed in this page may be inconsistent with the actual software version, and is for reference only.

3.3.1.2 Advanced

Click **Advanced** in the **Overview** page and the following page appears.

Overview
[Basic](#) | [Advanced](#)

System Information

Model Name	T2-B-Gawv1.4U10Y-BI
Firmware Version	10.4.3.12.12
DSL Firmware Version	E.25.41.64 A
Wireless Version	1.20
System Up time	00:08:59s

Internet Connection

DSL Status	Not Connected
Last Failed	0x00000000
Downstream Data Rate	0 kbps
Upstream Data Rate	0 kbps
Max Att Downstream Rate	0 kbps
Max Att Upstream Rate	0 kbps
SNR (Downstream)	
SNR (Upstream)	
Line Attenuation(Downstream)	
Line Attenuation(Upstream)	
Connected Standard	Inactive

Wireless Settings

Status	Disable
SSID	BSNL_AP
Channel	1
Security	128 bit WEP

LAN Port

Mac Address	00:26:15:50:16:00
IP Address	192.168.1.1
DHCP server	On
Subnet Mask	255.255.255.0

Voice

Status	Enabled
Total Number of Line Support	1
Registration Status	Unknown
Phone Numbers-Channel 1	1

Status

[ARP](#)
[DHCP](#) [Traffic Stats](#)
[Wireless Connection](#)

[\[Go To Basic view\]](#)

The following table describes the parameters of this page.

Field	Description
System Information	
DSL Firmware Version	The hardware version of the modem.
Wireless version	The wireless version of the modem.
Internet Connection	
Connected Standard	The status of the line mode.
Status	It contains the configuration information about ARP , DHCP Traffic Stats , and Wireless Connection .



Note:

The rate is measured under a zero-kilometer link. In the circumstances, the gateway is automatically set, and the DNS addresses are obtained from the BRAS.

3.3.2 System Log

Choose **Home > System Log** and the following page appears. In this page, you can consult the logs after relevant settings. You can also save the current settings to your PC.

View and save system logs

Use to save the current settings into your computer

Enter date in YYYY-MM-DD format and select a module

Date : to

Module :

System Logs
 System Logs
 Security Logs

Logs

Sat, 03 Jan 1970 - 00:00:04 ALARM::MINOR: SYSTEM UP



Note:

Set the query time consistent with the SNTP if you want to obtain the real-time of the system logs.

3.3.3 Troubleshooting

Choose **Home > Troubleshooting** to enter the troubleshooting page. This page is used to carry out diagnostic test. Troubleshooting allows you to carry out diagnostic tests on your local Ethernet and WAN connection by ping the web site or running the diagnostic tests. The tests results can be used to identify all the problems that are related to your DSL connection or the configuration of the modem.

Enter a well-known site (for example, IP 10.18.102.55) that you want to test. Click **Ping** and the following page appears.

The screenshot shows a web interface titled "Troubleshooting". Under the heading "Troubleshooting", there is a form with the following elements:

- "Select Internet Connection:" with a dropdown menu showing "bridge_8_81".
- "Ping to well known site:" with a text input field containing "10.18.102.55" and a "Ping" button.
- A "Run Diagnostic Tests" button.
- At the bottom, the text "Ping to well known site: 10.18.102.55" is displayed in red, followed by the word "FAIL" in red.

If the network connects well and the IP address or the site is effective, the ping of the well-known site passes. Otherwise, it is failed to ping the well-known site.

Select the Internet connection that you want to test from the drop-down list (take bridge_8_81 for example). Click **Run Diagnostic Tests** and the following page appears. In this page, you can view the test result.

Troubleshooting	
Select Internet Connection:	bridge_8_81
Ping to well known site: (e.g. www.yahoo.com)	10.18.102.55 <input type="button" value="Ping"/>
<input type="button" value="Run Diagnostic Tests"/>	
Test the connection to your local network	
Test your Ethernet Connection:	PASS
Test DSL Synchronization:	
F4 OAM Test	
Test your F4 OAM Segment :	N/A
Test your F4 OAM ETOE :	N/A
F5 OAM Test	
Test your F5 OAM Segment :	N/A
Test your F5 OAM ETOE :	N/A
Ping to well known site: 10.18.102.55	FAIL

The information that is displayed helps you to locate the problems.

3.4 Configuration

Click **Configuration** to enter system configuration page. On the left page, there are seven options: **Wireless Network**, **Internet Connection**, **Local Network (LAN)**, **Voice Configuration**, **DHCP Server**, **DHCP Relay**, and **IPv6 Prefix**. You can modify LAN and WAN settings, such as PVC, LAN port, and DHCP.

3.4.1 Wireless Network

A wireless local area network (WLAN) provides a flexible data communications system that you can use to access various services, such as, surfing on the Internet, E-mail, and printing services, without the cable connection. You can connect to the Internet while roaming around in the coverage area.

Choose **Configuration > Wireless Network** and the following page appears. In this page, you can configure the parameters for wireless LAN clients that may connect to the modem.

3.4.1.1 Basic Settings

By Default WiFi is disabled in your CPE, and its using default SSID as "BSNL_AP". please configure the WiFi if you want to us it.

Choose **Wireless Network > Basic Settings** and the following page appears. You must set the location where you are in order to prevent the modem from transmitting the illegal frequencies.

The following table describes the parameters of this page.

Field	Description
Select Profile	Choose the security specification. You can choose 802.11 B/G , 802.11B only , 802.11G only , or 802.11 MIXED_LONG .
Wireless Network	Enable or disable the wireless network. If you want to connect to the Internet, enable it.
Select Country	Choose the country where the modem works.
Channel Selection	You can choose Auto or Manual .
Select Channel	A channel is the radio frequency(ies) used by

Field	Description
	802.11b/g wireless device. Channels available depend on your geographical area.
Network Name(SSID)	Service set identification (SSID) is a unique name to identify the modem in the wireless LAN. All wireless devices on a WLAN must use the same SSID in order to communicate with each other. By default, the SSID of the modem is BSNL_AP .
Hide SSID	You can enable or disable this SSID. <ul style="list-style-type: none"> ● If you select Yes, the wireless adaptor will fail to auto-search the SSID .The auto-searching list does not display the SSID. However, if you know the SSID, you can set the connection manually. ● If you select No, the auto-searching list displays the SSID.
Select Security Option	It is vital to protect wireless communication between wireless stations, access points and wired network. There are six options.

3.4.1.2 Advanced Settings

Click **Advanced Settings** in the **Wireless Network** page and the following page appears. In this page, you can configure the parameters for wireless LAN clients may connect to the modem. You can also modify the Fragmentation Threshold, Rts Threshold, Nitroxm Piggyback and WMM.

Wireless Network
[Basic Settings](#) | [Advanced Settings](#) | [MAC Address Filter](#)

To make sure MyDslModem does not transmit on illegal frequencies, you must set where you are in the world.

Global Setting

Select Profile: 802.11B/G

Wireless Network: Disable Enable

Select Country: INI

You may either choose a channel yourself, or allow to automatically select the best channel.

Channel Selection: Auto

Select Channel: 1

Network Name (SSID): BSNL_AP

Hide SSID: No Yes

Fragmentation Threshold : 2346

RTS Threshold : 2347

NitroXM PiggyBack: Disable Enable

WMM: Disable Enable

Security Settings

Select Security Option: 128 Bit Encryption

WEP Authentication Mode: Open Shared

Select Tx Key Index: 0

Select Key Method: Pass Phrase

Key: 12345678901234567890123456

WEP Pass Phrase:

Select Encryption Protocol: TKIP protocol

Select Authentication Method: PSK (Pre Shared Key)

WPA Pass Phrase: 00000000000000000000000000000000

802.1x Identity String: T2-B-Gawv1.4U10Y-BI 00:26:15:50:1

802.1x Rekey Timeout: 600

The following table describes the parameters of this page.

Field	Description
Fragmentation Threshold	The fragmentation threshold is a way of limiting the size of packets (frames) transmitted over the network. If a packet exceeds the configured fragmentation threshold, the fragmentation function is

Field	Description
	enabled, and the packets are sent as multiple 802.11 frames.
RTS Threshold	Request to send (RTS) is designed to prevent collisions due to hidden node. A RTS defines the biggest size data frame you can send before a RTS handshake invoked. The RTS threshold value is between 0 and 2347. If the RTS threshold value is greater than the fragment threshold value, the RTS handshake does not occur. Because the data frames are fragmented before they reach the RTS size.
NitroXM PiggyBack	Piggyback refers to interleaving the TCP Ack return flow with the TCP data flow.

3.4.1.3 MAC Address Filter

Click **MAC Address Filter** in the **Wireless Network** page and the following page appears. In this page, you can restrict the wireless PCs that connect with the modem. You can restrict the PCs in the blacklist or whitelist way.

Wireless Network

[Basic Settings](#) | [Advanced Settings](#) | **MAC Address Filter**

You can restrict which wireless PCs can connect to your device. Select how you want to restrict PCs below.

Select MAC Auth Delete

MAC Address

Disabled ▼
 Disabled
 BlackList
 WhiteList

Select MAC Auth: There are three options: **Disabled**, **BlackList**, or **WhiteList**.

- If choose **Disabled**, all the PC are allowed to access the modem.
- If choose **BlackList**, the PC whose MAC address is listed is denied to access the modem.


- If choose **WhiteList**, only the PC whose MAC address is listed is allowed to access the modem.

3.4.1.4 Wireless Configuration Example


Before you configure the wireless network, ensure that the wireless network card is installed in the PC.

The following describes the example of wireless network configuration:


Step 1 In the **Control Panel** page, double click **Network Connections**. The following page appears.



Step 2 Right click **Wireless Network Connection**, and select **View Available Wireless Networks**.



Step 3 In the **Wireless Network Connection** page, refresh the network lists and select the network name (SSID) **PRISM_WIRELESS**, which is the default SSID name. Then click **Connect**.




After finishing the settings, you can manage the modem through graphical user interface (GUI) or Telnet.

3.4.2 Internet Connection

This page displays the information of the PVC after some effective configuration.

3.4.2.1 Connections

Choose **Configuration > Internet Connection** and the following page appears. In this page, you can view the information of the PVC.



- : Delete an existing Internet connection.
- : Modify an existing Internet connection.

Note:

In the **Connections** page, the default configuration of the modem supports six PVCs. The modem can be configured with eight PVCs at most. If you add more than eight PVCs, it refuses to add.

: **Delete an existing Internet connection.**

The following describes an example of deleting bridge_0_32.

Step 1 In the following page, click to delete bridge_0_32.

Internet Connection Configuration

[Connections](#) | [ADSL](#) | [MAC Spoofing](#)

Internet Connection Configuration
 Click Add to add Internet connection. Click Delete or Edit link to delete/edit an existing Internet connection.

PVC Name	VPI/VCI	Category	Protocol	NAT	WAN IP Address	Edit	Delete
pppoe_0_35 Connect	0/35	UBR	PPPoE LlcBridged	On	Not Assigned		<input type="checkbox"/>
bridge_0_32	0/32	UBR	RFC2684- Bridged LlcBridged	Off	-		<input type="checkbox"/>
bridge_0_100	0/100	UBR	RFC2684- Bridged LlcBridged	Off	-		<input type="checkbox"/>
bridge_8_35	8/35	UBR	RFC2684- Bridged LlcBridged	Off	-		<input type="checkbox"/>
bridge_8_81	8/81	UBR	RFC2684- Bridged LlcBridged	Off	-		<input type="checkbox"/>
bridge_14_34	14/34	UBR	RFC2684- Bridged LlcBridged	Off	-		<input type="checkbox"/>
bridge_1_41	1/41	UBR	RFC2684- Bridged LlcBridged	Off	-		<input type="checkbox"/>
select all							<input type="checkbox"/>

Step 2 The system deletes bridge_0_32. After the deletion, the following page appears.

Internet Connection Configuration

Connections | [ADSL](#) | [MAC Spoofing](#)

Internet Connection Configuration

Click Add to add Internet connection. Click Delete or Edit link to delete/edit an existing Internet connection.

PVC Name	VPI/VCI	Category	Protocol	NAT	WAN IP Address	Edit	Delete
pppoe_0_35 Connect	0/35	UBR	PPPoE LlcBridged	On	Not Assigned		<input type="checkbox"/>
bridge_0_100	0/100	UBR	RFC2684- Bridged LlcBridged	Off	-		<input type="checkbox"/>
bridge_8_35	8/35	UBR	RFC2684- Bridged LlcBridged	Off	-		<input type="checkbox"/>
bridge_8_81	8/81	UBR	RFC2684- Bridged LlcBridged	Off	-		<input type="checkbox"/>
bridge_14_34	14/34	UBR	RFC2684- Bridged LlcBridged	Off	-		<input type="checkbox"/>
bridge_1_41	1/41	UBR	RFC2684- Bridged LlcBridged	Off	-		<input type="checkbox"/>
select all							<input type="checkbox"/>

: **Modify an existing Internet connection.**

The following describes an example of modifying bridge_8_35.

Step 1 In the following page, click to modify bridge_8_35.

Internet Connection Configuration

[Connections](#) | [ADSL](#) | [MAC Spoofing](#)

Internet Connection Configuration

Click Add to add Internet connection. Click Delete or Edit link to delete/edit an existing Internet connection.

PVC Name	VPI/VCI	Category	Protocol	NAT	WAN IP Address	Edit	Delete
pppoe_0_35 Connect	0/35	UBR	PPPoE LlcBridged	On	Not Assigned		
bridge_0_32	0/32	UBR	RFC2684- Bridged LlcBridged	Off	-		
bridge_0_100	0/100	UBR	RFC2684- Bridged LlcBridged	Off	-		
bridge_8_35	8/35	UBR	RFC2684- Bridged LlcBridged	Off	-		
bridge_8_81	8/81	UBR	RFC2684- Bridged LlcBridged	Off	-		
bridge_14_34	14/34	UBR	RFC2684- Bridged LlcBridged	Off	-		
bridge_1_41	1/41	UBR	RFC2684- Bridged LlcBridged	Off	-		
select all							<input type="checkbox"/>

Step 2 The following page appears. In this page, you can modify VPI, VCI and service category.

Internet Connection Configuration

Configure ATM PVC

Please enter VPI and VCI numbers for the Internet connection which is provided by your ISP.

VPI: (0-255)

VCI: (32-65535)

Service Category:

Peak Cell Rate: cell/s (0-8000)

Sustainable Cell Rate: cell/s (1-7099)

Maximum Burst Size: cells (1-1000000)

The following table describes the parameters of this page.

Field	Description
VPI	Virtual path identifier (VPI) is the virtual path between two points in an ATM network. Its valid value is from 0 to 255.
VCI	Virtual Channel Identifier (VCI) is the virtual channel between two points in an ATM network. Its valid value is from 32 to 65535.
Service Category	<p>You can choose UBR With PCR, CBR, Non Realtime VBR, or Realtime VBR.</p> <ul style="list-style-type: none"> ● UBR with PCR: Unspecified bite rate with peak cell rate (UBR with PCR). When the network is congested, the UBR cell is dropped and communication traffic is at a fairly low level. Its peak cell rate range is from 0 to 8000. ● CBR: Constant bit rate (CBR) is a coding mode. It is adapted for strict requirement to delay and quality of data packets transmission. Its peak cell rate range is from 0 to 7100.

Field	Description
	<ul style="list-style-type: none"> ● Non Real-time VBR: Non real-time variable bit rate (NRT-VBR) is adapted for real time with relatively low requirement. Its peak cell rate range is from 0 to 8000. The sustainable cell rate range is from 1 to 7099, and the maximum burst size range is from 0 to 1000000. ● Real-time VBR: Real-time variable bit rate (Real-time VBR) is adapted for real time with high requirement. Its peak cell rate range is from 0 to 8000. The sustainable cell rate range is from 1 to 7099, and the maximum burst size range is from 0 to 1000000.
Sustainable Cell Rate	Sustainable cell rate (SCR) is an ATM parameter for traffic management. For variable bit rate (VBR) connections, SCR determines the long-term average cell rate that can be transmitted.
Maximum Burst Size	Maximum burst size (MBS) is used to specify the maximum number of cells that can be transmitted at the contracted peak cell rate (PCR).

**Note:**

The value of PCR should be greater than SCR, and MBS is usually less than 10. The service category merely is effective to upstream.

Step 3 After proper modifications, click **Next** and the following page appears. In the page, you can modify the configure connection type, such as encapsulation type or encapsulation mode (The mode is only adapted for RFC2684 protocol).

Internet Connection Configuration

Configure Connection Type

Select the encapsulation type with the ATM PVC that your ISP has instructed you to use.

Encapsulation Type:

Encapsulation Mode:

: **Add Internet connection.**

The following describes an example of adding PVC 0/32.

Step 1 In the following page, click **Add** to add PVC 0/32.

Internet Connection Configuration

Connections | [ADSL](#) | [MAC Spoofing](#)

Internet Connection Configuration

Click Add to add Internet connection. Click Delete or Edit link to delete/edit an existing Internet connection.

PVC Name	VPI/VCI	Category	Protocol	NAT	WAN IP Address	Edit	Delete
pppoe_0_35 Connect	0/35	UBR	PPPoE LlcBridged	On	Not Assigned		
bridge_0_100	0/100	UBR	RFC2684- Bridged LlcBridged	Off	-		
bridge_8_35	8/35	UBR	RFC2684- Bridged LlcBridged	Off	-		
bridge_8_81	8/81	UBR	RFC2684- Bridged LlcBridged	Off	-		
bridge_14_34	14/34	UBR	RFC2684- Bridged LlcBridged	Off	-		
bridge_1_41	1/41	UBR	RFC2684- Bridged LlcBridged	Off	-		
select all							<input type="checkbox"/>

Step 2 The following page appears. In this page, you can modify VPI, VCI, and service categories.

Internet Connection Configuration

Configure ATM PVC

Please enter PVC Name, VPI and VCI numbers for the Internet connection which is provided by your ISP.

PVC Name:

VPI: (0-255)

VCI: (32-65535)

Service Category:

Peak Cell Rate: cell/s(0-8000)

Sustainable Cell Rate: cell/s(1-7099)

Maximum Burst Size: cells(1-1000000)

The following table describes the parameters of this page.

Field	Description
VPI	Virtual path identifier (VPI) is the virtual path between two points in an ATM network. Its valid value is from 0 to 255.
VCI	Virtual Channel Identifier (VCI) is the virtual channel between two points in an ATM network. Its valid value is from 32 to 65535.
Service Category	<p>You can choose UBR With PCR, CBR, Non Realtime VBR, or Realtime VBR.</p> <ul style="list-style-type: none"> ● UBR with PCR: Unspecified bite rate with peak cell rate (UBR with PCR). When the network is congested, the UBR cell is dropped and communication traffic is at a fairly low level. Its peak cell rate range is from 0 to 8000. ● CBR: Constant bit rate (CBR) is a coding mode. It is adapted for strict requirement to delay and quality of data packets transmission. Its peak cell rate range is from 0 to 7100.

Field	Description
	<ul style="list-style-type: none"> ● Non Real-time VBR: Non real-time variable bit rate (NRT-VBR) is adapted for real time with relatively low requirement. Its peak cell rate range is from 0 to 8000. The sustainable cell rate range is from 1 to 7099, and the maximum burst size range is from 0 to 1000000. ● Real-time VBR: Real-time variable bit rate (Real-time VBR) is adapted for real time with high requirement. Its peak cell rate range is from 0 to 8000. The sustainable cell rate range is from 1 to 7099, and the maximum burst size range is from 0 to 1000000.
Sustainable Cell Rate	Sustainable cell rate (SCR) is an ATM parameter for traffic management. For variable bit rate (VBR) connections, SCR determines the long-term average cell rate that can be transmitted.
Maximum Burst Size	Maximum burst size (MBS) is used to specify the maximum number of cells that can be transmitted at the contracted peak cell rate (PCR).

**Note:**

The value of PCR should be greater than SCR, and MBS is usually less than 10. The service category merely is effective to upstream.

Step 3 After proper modifications, click **Next** and the following page appears. In this page, you can modify Internet connection protocol and encapsulation type.

Internet Connection Configuration

Configure Connection Type

Select the protocol and encapsulation type with the ATM PVC that your ISP has instructed you to use.

Protocol:

- PPP over ATM (PPPoA)
- PPP over ATM for IPv6 (PPPoA IPv6)
- PPP over Ethernet (PPPoE)
- PPP over Ethernet for IPv6 (PPPoE IPv6)
- RFC2684 (IPv4)
- RFC2684 (IPv6)
- Bridging

Encapsulation Type:

Encapsulation Mode:

Sample 1: PPP over ATM (PPPoA)

Step 1 Select **PPP over ATM (PPPoA)** protocol and set the encapsulation type to **VC MUX** (depending upon the uplink equipment, generally **VC MUX**). Then click **Next**.

Internet Connection Configuration

Configure Connection Type

Select the protocol and encapsulation type with the ATM PVC that your ISP has instructed you to use.

Protocol:

- PPP over ATM (PPPoA)
- PPP over ATM for IPv6 (PPPoA IPv6)
- PPP over Ethernet (PPPoE)
- PPP over Ethernet for IPv6 (PPPoE IPv6)
- RFC2684 (IPv4)
- RFC2684 (IPv6)
- Bridging

Encapsulation Type:

Encapsulation Mode:

Step 2 In this example, the modem must be configured as built-in PPPoA + NAT. Select **Obtain an IP address automatically**, **Enable NAT**, and **Add Default Route**.

The following table describes the parameters of this page.

Field	Description
Obtain an IP address automatically	Through PPP dial-up to obtain an IP address assigned by up-link equipment, such as BRAS.
Use the following IP address	If you want to manually enter the WAN IP address, select it and enter the IP address provided by your ISP.
Enable NAT	Select it to enable network address translation (NAT) function of the modem. If you do not enable NAT and want to the modem to access the Internet normally, you must add a route on the uplink equipment. Otherwise, the access to the Internet fails. Normally, it is required to enable NAT.
Add Default Route	Add a default route in the routing table. Normally, it must be selected. Otherwise, you have to add a default route manually.

Step 3 Enter the correct broadband user name and password. Select a proper PPP connection mode. Then click **Next**.

Internet Connection Configuration

Configure Broadband User Name and Password

To use your Broadband service, please verify your Broadband user name and password.

Broadband User Name:

Password:

Confirm Password:

Session established by:

Always On

Dial on Demand

Consider Lanside Traffic Only

Disconnect if no activity for minutes

Manually Connect

Consider Lanside Traffic Only

Disconnect if no activity for minutes

The following table describes the parameters of this page.

Field	Description
Broadband User Name	Enter the correct user name provided by your ISP.
Password	Enter the correct password provided by your ISP.
Confirm Password	Confirm the correct password provided by your ISP.
Session established by	<p>Select a PPP connection mode according to your practice.</p> <ul style="list-style-type: none"> ● Always On: After the device is powered on, the system performs PPP dial-up automatically. If the device is powered off, DSLAM or the up-link equipment is abnormal, the PPP connection will not be broken. ● Dial on Demand: After the device is powered on, the PPP dial-up performs automatically. If the device does not

Field	Description
	<p>detect the flow of the user continuously within the preset minutes, the device automatically stops the PPP connection. Once the device detects the data flow (for example, accessing the web page), it restarts the PPP for dial-up.</p> <ul style="list-style-type: none"> ● Manually Connect: Choose Configuration > Internet Connection > Connections. Click Connect in the Internet Connection Configuration page to start the PPP connection. If the device does not detect the data-flow of the user continuously within the preset minutes, the device automatically releases the PPP connection. The difference between manually connect and dial on demand is that you must start a PPP connection manually again if you select manually connect. Enter the waiting time in the field.

Step 4 Click **Next** and the following page appears. In this page, you can confirm the modification.

Internet Connection Configuration

Summary
 Make sure that the settings below match the settings provided by your ISP.

Internet(WAN) Configuration:

VPI / VCI	0 / 32
Service Category	UBR With PCR 0 cell/s
Connection Type	PPPoA VC MUX, Always On
NAT	On
WAN IP Address	Automatically Assigned
Default Route	On

Click "Cancel" to discard these settings. Click "Apply" to make modifications.

Check the configuration according to the requirements. When you ensure that the configuration is correct, click **Apply**. The following page appears.

Internet Connection Configuration

[Connections](#) | [ADSL](#) | [MAC Spoofing](#)

Internet Connection Configuration
 Click Add to add Internet connection. Click Delete or Edit link to delete/edit an existing Internet connection.

PVC Name	VPI/VCI	Category	Protocol	NAT	WAN IP Address	Edit	Delete
pppoe_0_35 Connect >>	0/35	UBR	PPPoE LlcBridged	On	Not Assigned		
bridge_0_100	0/100	UBR	RFC2684- Bridged LlcBridged	Off	-		
bridge_8_35	8/35	UBR	RFC2684- Bridged LlcBridged	Off	-		
bridge_8_81	8/81	UBR	RFC2684- Bridged LlcBridged	Off	-		
bridge_14_34	14/34	UBR	RFC2684- Bridged LlcBridged	Off	-		
bridge_1_41	1/41	UBR	RFC2684- Bridged LlcBridged	Off	-		
R_0_32 Connect >>	0/32	UBR	PPPoA VC/MUX	On	Not Assigned		
select all							<input type="checkbox"/>

Sample 2: PPP over ATM for IPv6 (PPPoA IPv6)

Step 1 Select **PPP over ATM for IPv6 (PPPoA IPv6)** protocol and set the encapsulation type to **VC MUX** (depending upon the uplink equipment, generally **VC MUX**). Then click **Next**.

Internet Connection Configuration

Configure Connection Type

Select the protocol and encapsulation type with the ATM PVC that your ISP has instructed you to use.

Protocol:

- PPP over ATM (PPPoA)
- PPP over ATM for IPv6 (PPPoA IPv6)
- PPP over Ethernet (PPPoE)
- PPP over Ethernet for IPv6 (PPPoE IPv6)
- RFC2684 (IPv4)
- RFC2684 (IPv6)
- Bridging

Encapsulation Type: **VC MUX**

Encapsulation Mode: **Bridged**

Next > **Cancel**

Step 2 In this example, the modem must be configured as built-in PPPoA + NAT. Select **Obtain an IP address automatically**, **Enable NAT**, and **Add Default Route**.

Internet Connection Configuration

Configure WAN IP Settings

Enter information provided by your ISP to configure the WAN IP settings.

- Obtain an IP address automatically
- Use the following IP address:

WAN IP Address:

- Enable NAT
- Add Default Route

Next > **Cancel**

The following table describes the parameters of this page.

Field	Description
Obtain an IP address automatically	Through PPP dial-up to obtain an IP address assigned by up-link equipment, such as BRAS.
Use the following IP address	If you want to manually enter the WAN IP address, select it and enter the IP address provided by your ISP.
Enable NAT	Select it to enable network address translation (NAT) function of the modem. If you do not enable NAT and want to the modem to access the Internet normally, you must add a route on the uplink equipment. Otherwise, the access to the Internet fails. Normally, it is required to enable NAT.
Add Default Route	Add a default route in the routing table. Normally, it must be selected. Otherwise, you have to add a default route manually.

Step 3 Enter the correct broadband user name and password. Select a proper PPP connection mode. Then click **Next**.

Internet Connection Configuration

Configure Broadband User Name and Password

To use your Broadband service, please verify your Broadband user name and password.

Broadband User Name:

Password:

Confirm Password:

Session established by:

Always On

Dial on Demand

Consider Lanside Traffic Only

Disconnect if no activity for minutes

Manually Connect

Consider Lanside Traffic Only

Disconnect if no activity for minutes

The following table describes the parameters of this page.

Field	Description
Broadband User Name	Enter the correct user name provided by your ISP.
Password	Enter the correct password provided by your ISP.
Confirm Password	Confirm the correct password provided by your ISP.
Session established by	<p>Select a PPP connection mode according to your practice.</p> <ul style="list-style-type: none"> ● Always On: After the device is powered on, the system performs PPP dial-up automatically. If the device is powered off, DSLAM or the up-link equipment is abnormal, the PPP connection will not be broken. ● Dial on Demand: After the device is powered on, the PPP dial-up performs automatically. If the device does not detect the flow of the user continuously within the preset minutes, the device automatically stops the PPP connection. Once the device detects the data flow (for example, accessing the web page), it restarts the PPP for dial-up. ● Manually Connect: Choose Configuration > Internet Connection > Connections. Click Connect in the Internet Connection Configuration page to start the PPP connection. If the device does not detect the data-flow of the user continuously within the preset minutes, the device automatically releases the PPP connection. The difference between manually connect and dial on demand is that you must start

Field	Description
	a PPP connection manually again if you select manually connect. Enter the waiting time in the field.

Step 4 Click **Next** and the following page appears. In this page, you can confirm the modification.

Internet Connection Configuration

Summary
Make sure that the settings below match the settings provided by your ISP.

Internet(WAN) Configuration:

VPI / VCI	0 / 32
Service Category	UBR With PCR 0 cell/s
Connection Type	PPPoA for IPv6 LLC/SNAP, Always On
NAT	On
WAN IP Address	Automatically Assigned
Default Route	On

Click "Cancel" to discard these settings. Click "Apply" to make modifications.

Sample 3: PPP over Ethernet (PPPoE)

Step 1 Select **PPP over Ethernet (PPPoE)** protocol. Set to **LLC/SNAP** encapsulation type and **Bridged** encapsulation mode. Then click **Next**.

Internet Connection Configuration

Configure Connection Type

Select the protocol and encapsulation type with the ATM PVC that your ISP has instructed you to use.

Protocol:

- PPP over ATM (PPPoA)
- PPP over ATM for IPv6 (PPPoA IPv6)
- PPP over Ethernet (PPPoE)
- PPP over Ethernet for IPv6 (PPPoE IPv6)
- RFC2684 (IPv4)
- RFC2684 (IPv6)
- Bridging

Encapsulation Type:

Encapsulation Mode:

Step 2 In this example, select **Obtain an IP address automatically**, **Enable NAT**, and **Add Default Route**.

Internet Connection Configuration

Configure WAN IP Settings

Enter information provided by your ISP to configure the WAN IP settings.

- Enable/Disable the Access Concentrator option
Access Concentrator :
- Obtain an IP address automatically
- Use the following IP address:
WAN IP Address:
- Enable NAT
- Add Default Route

The following table describes the parameters of this page.

Field	Description
Enable/Disable the Access Concentrator	Enable or disable the access concentrator.

Field	Description
option	
Access Concentrator	<ul style="list-style-type: none"> ● If select Enable, in the PPPoE Discovery stage, the modem makes a choice according to the AC-Name value after receiving many PADO packets. ● If select Disable, in the PPPoE Discovery stage, the modem makes a choice according other service (such as the service that PADO provides), then it sends PADR packets to each BRAS.
Obtain an IP Address automatically	Through PPP dial-up to obtain an IP address assigned by up-link equipment, such as BRAS.
Use the following IP address	If you want to manually enter the WAN IP address, select it and enter the IP address provided by your ISP.
Enable NAT	Select it to enable network address translation (NAT) function of the modem. If you do not enable NAT and want to the modem to access the Internet normally, you must add a route on the uplink equipment. Otherwise, the access to the Internet fails. Normally, it is required to enable NAT.
Add Default Route	Add a default route in the routing table. Normally, it must be selected. Otherwise, you have to add a default route manually.

Step 3 Enter the correct broadband user name, password and confirm password. Select a proper PPP connection mode. Then click **Next**.

Internet Connection Configuration

Configure Broadband User Name and Password

To use your Broadband service, please verify your Broadband user name and password.

Service Name:

Broadband User Name:

Password:

Confirm Password:

Session established by:

Always On

Dial on Demand

Consider Lanside Traffic Only

Disconnect if no activity for minutes

Manually Connect

Consider Lanside Traffic Only

Disconnect if no activity for minutes

The following table describes the parameters of this page.

Field	Description
Service Name	Enter the service name provided by the ISP. It may not fill.
Broadband User Name	Enter the correct user name provided by your ISP.
Password	Enter the correct password provided by your ISP.
Confirm Password	Confirm the correct password provided by your ISP.
Session established by	<p>Select a PPP connection mode according to your practice.</p> <ul style="list-style-type: none"> ● Always On: After the device is powered on, the system performs PPP dial-up automatically. If the device is powered off, DSLAM or the up-link equipment is abnormal, the PPP connection will not be broken.

Field	Description
	<ul style="list-style-type: none"> <li data-bbox="715 159 1147 439">● Dial on Demand: After the device is powered on, the PPP dial-up performs automatically. If the device does not detect the flow of the user continuously within the preset minutes, the device automatically stops the PPP connection. Once the device detects the data flow (for example, accessing the web page), it restarts the PPP for dial-up. <li data-bbox="715 450 1147 882">● Manually Connect: Choose Configuration > Internet Connection > Connections. Click Connect in the Internet Connection Configuration page to start the PPP connection. If the device does not detect the data-flow of the user continuously within the preset minutes, the device automatically releases the PPP connection. The difference between manually connect and dial on demand is that you must start a PPP connection manually again if you select manually connect. Enter the waiting time in the field.

Step 4 Click **Next** and the following page appears. In this page, you can confirm the modification.

Internet Connection Configuration

Summary
 Make sure that the settings below match the settings provided by your ISP.

Internet(WAN) Configuration:

VPI / VCI	0 / 32
Service Category	UBR With PCR 0 cell/s
Connection Type	PPPoE LLC/SNAP, Always On
PPPOE AC	Not Configured
PPPOE Service Name	
NAT	On
WAN IP Address	Automatically Assigned
Default Route	On

Click "Cancel" to discard these settings. Click "Apply" to make modifications. Apply Cancel

Step 5 Check the configuration according to the requirements. When you ensure that the configuration is correct, click **Apply**. The following page appears.

Internet Connection Configuration

Connections: [ADSL](#) | [MAC Spoofing](#)

Internet Connection Configuration
 Click Add to add Internet connection. Click Delete or Edit link to delete/edit an existing Internet connection.

PVC Name	VPI/VCI	Category	Protocol	NAT	WAN IP Address	Edit	Delete
pppoe_0_35 Connect >	0/35	UBR	PPPoE LlcBridged	On	Not Assigned		
bridge_0_100	0/100	UBR	RFC2684- Bridged LlcBridged	Off	-		
bridge_8_35	8/35	UBR	RFC2684- Bridged LlcBridged	Off	-		
bridge_8_81	8/81	UBR	RFC2684- Bridged LlcBridged	Off	-		
bridge_14_34	14/34	UBR	RFC2684- Bridged LlcBridged	Off	-		
bridge_1_41	1/41	UBR	RFC2684- Bridged LlcBridged	Off	-		
R_0_32 Connect >	0/32	UBR	PPPoE LlcBridged	On	Not Assigned		
select all							<input type="checkbox"/>

Add > Delete

Sample 4: PPP over Ethernet for IPv6 (PPPoE IPv6)

Step 1 Select **PPP over Ethernet for IPv6 (PPPoE IPv6)** protocol. Set to **LLC/SNAP** encapsulation type and **Bridged** encapsulation mode. Then click **Next**.

Internet Connection Configuration

Configure Connection Type

Select the protocol and encapsulation type with the ATM PVC that your ISP has instructed you to use.

Protocol:

- PPP over ATM (PPPoA)
- PPP over ATM for IPv6 (PPPoA IPv6)
- PPP over Ethernet (PPPoE)
- PPP over Ethernet for IPv6 (PPPoE IPv6)
- RFC2684 (IPv4)
- RFC2684 (IPv6)
- Bridging

Encapsulation Type:

Encapsulation Mode:

Step 2 In this example, select **Obtain an IP address automatically**, **Enable NAT**, and **Add Default Route**.

Internet Connection Configuration

Configure WAN IP Settings

Enter information provided by your ISP to configure the WAN IP settings.

- Enable/Disable the Access Concentrator option
Access Concentrator :
- Obtain an IP address automatically
- Use the following IP address:
WAN IP Address:
- Enable NAT
- Add Default Route

The following table describes the parameters of this page.

Field	Description
Enable/Disable the Access Concentrator option	Enable or disable the access concentrator.
Access Concentrator	<ul style="list-style-type: none"> ● If select Enable, in the PPPoE Discovery stage, the modem makes a choice according to the AC-Name value after receiving many PADO packets. ● If select Disable, in the PPPoE Discovery stage, the modem makes a choice according other service (such as the service that PADO provides), then it sends PADR packets to each BRAS.
Obtain an IP Address automatically	Through PPP dial-up to obtain an IP address assigned by up-link equipment, such as BRAS.
Use the following IP address	If you want to manually enter the WAN IP address, select it and enter the IP address provided by your ISP.
Enable NAT	Select it to enable network address translation (NAT) function of the modem. If you do not enable NAT and want to the modem to access the Internet normally, you must add a route on the uplink equipment. Otherwise, the access to the Internet fails. Normally, it is required to enable NAT.
Add Default Route	Add a default route in the routing table. Normally, it must be selected. Otherwise, you have to add a default route manually.

Step 3 Enter the correct broadband user name, password and confirm password. Select a proper PPP connection mode. Then click **Next**.

Internet Connection Configuration

Configure Broadband User Name and Password

To use your Broadband service, please verify your Broadband user name and password.

Service Name:

Broadband User Name:

Password:

Confirm Password:

Session established by:

Always On

Dial on Demand

Consider Lanside Traffic Only

Disconnect if no activity for minutes

Manually Connect

Consider Lanside Traffic Only

Disconnect if no activity for minutes

The following table describes the parameters of this page.

Field	Description
Service Name	Enter the service name provided by the ISP. It may not fill.
Broadband User Name	Enter the correct user name provided by your ISP.
Password	Enter the correct password provided by your ISP.
Confirm Password	Confirm the correct password provided by your ISP.
Session established by	<p>Select a PPP connection mode according to your practice.</p> <ul style="list-style-type: none"> ● Always On: After the device is powered on, the system performs PPP dial-up automatically. If the device is powered off, DSLAM or the up-link equipment is abnormal, the PPP connection will not be broken.

Field	Description
	<ul style="list-style-type: none"> <li data-bbox="711 159 1145 439">● Dial on Demand: After the device is powered on, the PPP dial-up performs automatically. If the device does not detect the flow of the user continuously within the preset minutes, the device automatically stops the PPP connection. Once the device detects the data flow (for example, accessing the web page), it restarts the PPP for dial-up. <li data-bbox="711 450 1145 882">● Manually Connect: Choose Configuration > Internet Connection > Connections. Click Connect in the Internet Connection Configuration page to start the PPP connection. If the device does not detect the data-flow of the user continuously within the preset minutes, the device automatically releases the PPP connection. The difference between manually connect and dial on demand is that you must start a PPP connection manually again if you select manually connect. Enter the waiting time in the field.

Step 4 Click **Next** and the following page appears. In this page, you can confirm the modification.

Internet Connection Configuration

Summary
 Make sure that the settings below match the settings provided by your ISP.

Internet(WAN) Configuration:

VPI / VCI	0 / 32
Service Category	UBR With PCR 0 cell/s
Connection Type	PPPoE for IPv6 LLC/SNAP, Always On
NAT	On
WAN IP Address	Automatically Assigned
Default Route	On

Click "Cancel" to discard these settings. Click "Apply" to make modifications.

Sample 5: RFC2684 (IPv4)

Step 1 Select **RFC2684 (IPv4)** protocol. Set to **LLC/SNAP** encapsulation type and **Bridged** encapsulation mode. Then click **Next**.

Internet Connection Configuration

Configure Connection Type

Select the protocol and encapsulation type with the ATM PVC that your ISP has instructed you to use.

Protocol:

- PPP over ATM (PPPoA)
- PPP over ATM for IPv6 (PPPoA IPv6)
- PPP over Ethernet (PPPoE)
- PPP over Ethernet for IPv6 (PPPoE IPv6)
- RFC2684 (IPv4)
- RFC2684 (IPv6)
- Bridging

Encapsulation Type:

Encapsulation Mode:

Step 2 In this example, select **Obtain an IP address automatically**, **Enable NAT**, and **Add Default Route**.

Internet Connection Configuration

Configure WAN IP Settings

Enter information provided by your ISP to configure the WAN IP settings.

Obtain an IP address automatically
 Use the following IP address:

WAN IP Address:
 WAN Subnet Mask:
 Default Gateway:

Enable NAT
 Add Default Route

The following table describes the parameters of this page.

Field	Description
Obtain an IP address automatically	Through PPP dial-up to obtain an IP address assigned by up-link equipment, such as BRAS.
Use the following IP address	If you want to manually enter the WAN IP address, select it and enter the IP address provided by your ISP.
Enable NAT	Select it to enable network address translation (NAT) function of the modem. If you do not enable NAT and want to the modem to access the Internet normally, you must add a route on the uplink equipment. Otherwise, the access to the Internet fails. Normally, it is required to enable NAT.
Add Default Route	Add a default route in the routing table. Normally, it must be selected. Otherwise, you have to add a default route manually.

Step 3 Click **Next** and the following page appears. In this page, you can confirm the modification.

Internet Connection Configuration

Summary
 Make sure that the settings below match the settings provided by your ISP.

Internet(WAN) Configuration:

VPI / VCI	0 / 32
Service Category	UBR With PCR 0 cell/s
Connection Type	rfc2684 IPv4(bridged) LLC/SNAP,
NAT	On
WAN IP Address	Automatically Assigned
Default Route	On

Click "Cancel" to discard these settings. Click "Apply" to make

Sample 6: RFC2684 (IPv6)

Step 1 Select **RFC2684 (IPv6)** protocol. Set to **LLC/SNAP** encapsulation type and **Bridged** encapsulation mode. Then click **Next**.

Internet Connection Configuration

Configure Connection Type

Select the protocol and encapsulation type with the ATM PVC that your ISP has instructed you to use.

Protocol:

- PPP over ATM (PPPoA)
- PPP over ATM for IPv6 (PPPoA IPv6)
- PPP over Ethernet (PPPoE)
- PPP over Ethernet for IPv6 (PPPoE IPv6)
- RFC2684 (IPv4)
- RFC2684 (IPv6)
- Bridging

Encapsulation Type:

Encapsulation Mode:

Step 2 In this example, select **Obtain an IPv6 address automatically** and **Add Default Route**.

Internet Connection Configuration

Configure Rfc2684 IPv6 Configurations

Enter information provided by your ISP to configure the Rfc2684 (DHCPv6 Client) settings.

Obtain an IPv6 address automatically
 Use the following IPv6 address:
 IPv6 Address:
 Default Gateway:
 Add Default Route

By Enabling DHCPv6 the modem can acquire prefixes from DHCP server and delegate the same on the LAN side interface. LAN side hosts can configure their IP address automatically from these advertised prefixes. The modem can also acquire temporary and non temporary IPv6 addresses for its WAN connection by DHCPv6

The following table describes the parameters of this page.

Field	Description
Obtain an IPv6 address automatically	Through PPP dial-up to obtain an IPv6 address assigned by up-link equipment, such as BRAS.
Use the following IPv6 address	If you want to manually enter the WAN IPv6 address, select it and enter the IPv6 address provided by your ISP.
Add Default Route	Add a default route in the routing table. Normally, it must be selected. Otherwise, you have to add a default route manually.

Step 3 Click **Next** and the following page appears. In this page, you can confirm the modification.

Internet Connection Configuration

Summary
 Make sure that the settings below match the settings provided by your ISP.

Internet(WAN) Configuration:

VPI / VCI	0 / 32
Service Category	UBR With PCR 0 cell/s
Connection Type	rfc2684 IPv6(bridged) LLC/SNAP,
WAN IP Address	Automatically Assigned
Default Route	Off

Click "Cancel" to discard these settings. Apply Cancel

Sample 7: Bridging

Step 1 Select **Bridging** protocol. Set to **LLC/SNAP** encapsulation type and **Bridged** encapsulation mode. Then click **Next**.

Internet Connection Configuration

Configure Connection Type

Select the protocol and encapsulation type with the ATM PVC that your ISP has instructed you to use.

Protocol:

- PPP over ATM (PPPoA)
- PPP over ATM for IPv6 (PPPoA IPv6)
- PPP over Ethernet (PPPoE)
- PPP over Ethernet for IPv6 (PPPoE IPv6)
- RFC2684 (IPv4)
- RFC2684 (IPv6)
- Bridging

Encapsulation Type: LLC/SNAP

Encapsulation Mode: Bridged

Next > Cancel

Step 2 In this example, select **Obtain an IP address automatically**, **Enable NAT**, and **Add Default Route**.

Internet Connection Configuration

Configure WAN IP Settings

Enter information provided by your ISP to configure the WAN IP settings.

None
 Obtain an IP address automatically
 Use the following IP address:
 WAN IP Address:
 WAN Subnet Mask:
 Obtain DNS server address automatically
 Use the following DNS server address:
 Primary DNS server:
 Secondary DNS server:

The following table describes the parameters of this page.

Field	Description
Obtain an IP Address automatically	Through PPP dial-up to obtain an IP address assigned by up-link equipment, such as BRAS.
Use the following IP address	If you want to manually enter the WAN IP address, select it and enter the IP address and subnet mask provided by your ISP.
Obtain DNS server address automatically	Select it to obtain DNS server address.
Use the following DNS server address	If you want to manually enter the DNS server address, select it and enter the primary DNS server and secondary DNS server.

Step 3 Click **Next** and the following page appears. In this page, you can confirm the modification.

Internet Connection Configuration

Summary
Make sure that the settings below match the settings provided by your ISP.

Internet(WAN) Configuration:

VPI / VCI	0 / 32
Service Category	UBR With PCR 0 cell/s
Connection Type	Bridging LLC/SNAP,
NAT	Off
WAN IP Address	None
DNS Server	None

Click "Cancel" to discard these settings. Click "Apply" to make

Step 4 Check the configuration according to the requirements. When you ensure that the configuration is correct, click **Apply**. The following page appears.

Internet Connection Configuration

[Connections](#) | [ADSL](#) | [MAC Spoofing](#)

Internet Connection Configuration

Click Add to add Internet connection. Click Delete or Edit link to delete/edit an existing Internet connection.

PVC Name	VPI/VCI	Category	Protocol	NAT	WAN IP Address	Edit	Delete
bridge_0_35	0/35	UBR	RFC2684-Bridged LlcBridged	Off	-		
bridge_8_35	8/35	UBR	RFC2684-Bridged LlcBridged	Off	-		
bridge_8_81	8/81	UBR	RFC2684-Bridged LlcBridged	Off	-		
bridge_0_100	0/100	UBR	RFC2684-Bridged LlcBridged	Off	-		
PppoeUp Connect	0/135	UBR	PPPoE LlcBridged	On	Not Assigned		
R_0_32	0/32	UBR	RFC2684-Bridged LlcBridged	Off	-		

select
all

3.4.2.2 ADSL

Click **ADSL** in the **Internet Connection Configuration** page and the following page appears. In this page, you can modify ADSL parameters.

The screenshot shows a web-based configuration interface for ADSL. At the top, there is a navigation menu with links for 'Connections', 'ADSL', and 'MAC Spoofing'. The main heading is 'Internet Connection Configuration'. Below this, there is a section for 'ADSL Supported Annexes' with a brief description. A 'Common Settings' section contains a link for 'Basic Attributes'. The 'Annex Specific Settings' section lists several capabilities, each with a checked checkbox and a link to its specific attributes: AnnexA, T1413A, A2Plus, A2, M2Plus, and M2. At the bottom of the window are three buttons: 'Apply', 'Start', and 'Defaults'.

Click **Basic Attributes** and the following page appears. It lists all specific ADSL attributes. In this page, you can configure the settings.

Configure ADSL Port

This page lists all Annex specific ADSL attributes. For basic list it displays which are common to all annexes. These attributes can be configured by selecting values and applying submit button

Common Attribute List

Action	Startup
ActivateLine	None
HostControl	Enable
AutoStart	true
ShowtimeLed	3
Retrain	EnableOverallOnly
Defaults	None
ReadMemory	
WriteMemory	
DSPTrace	StopLogging
LoopbackTest	DAC/ADC Lpbk MTS
Whip	Disable
WhipMode	Standalone
DyingGasp	Enable
UtopiaInterface	Levell
PhysicalPort	0
ClockType	Crystal
GenericTrace	DSP
DSPTraceType	DSP Message Trace
debug	disable
MaxRSMemory	32
Profile	MAIN
DetectNoise	Disable
resetDefaults	false

Apply Cancel

Defaults: There are five options. Choose one line mode you need. The default setting checks the most modulation modes. The modem negotiates the modulation mode with the DSLAM.

The following table describes the ADSL data rate standards.

Data rate standard	Uplink	Downlink
--------------------	--------	----------

Data rate standard	Uplink	Downlink
ADSL	1 Mbps	8 Mbps
ADSL2	1 Mbps	12 Mbps
ADSL2+	1 Mbps	24 Mbps

BisA Standard contains Bis/BisPlusAuto/BisPlusOnly/READSL2, AnnexA Standard contains G.dmt/T1.413/G.lite. The difference between Annex M and Annex A is that the uplink of Annex M can reach 2 Mbps, and Annex A can only reach 1 Mbps.

If you want to take the settings effect immediately, you should select **Start** in **ActiveteLine** field.

3.4.2.3 MAC Spoofing

MAC spoofing does not support bridge PVC.

Step 1 Click **MAC Spoofing** in the **Internet Connection Configuration** page and the following page appears. Select **Enabled** (By default, MAC Spoofing is disabled) and click **Next**.

Internet Connection Configuration
[Connections](#) | [ADSL](#) | **MAC Spoofing**

MAC spoofing lets MyDslModem identify itself as another computer or device. You may need to use this depending on your Internet Service Provider.

Select whether you need MAC spoofing enabled from the options below:

Disabled - MAC Spoofing is not used

Enabled - MAC Spoofing will be used with a MAC address you provide

Step 2 Enter the MAC address and click **Next**.

Internet Connection Configuration
MAC Spoofing Setup

You must provide a valid MAC address for MyDslModem to spoof.

MAC Address: : : : : :

Step 3 Check the configuration. If you ensure that your configuration is correct, click **Confirm**.

Internet Connection Configuration
MAC Spoofing Confirm

To confirm these settings, click on the Confirm button below. If you do not wish to apply these settings, click on the Cancel button.

MAC Spoofing will be **enabled**.
 The spoof MAC Address will be **00:1B:77:03:16:2B**

3.4.3 Local Network (LAN)

In this page, you can configure the local network.

3.4.3.1 IPv4 Address

Choose **Configuration > Local Network (LAN)** and the following page appears. In this page, you can set the IP address and subnet mask of LAN.

Local Network Configuration

[IPv4 Address](#) | [IPv6 Address](#) | [DNS Client](#) | [DNS Relay](#) | [DNS LAN Host](#)

LAN side IP Address Settings

Primary IP Address
 Enter here the IP address of your Router. This is the address visible from the computers on your network.

IP Address:
 Subnet Mask:
 Host Name:
 Domain Name:

Virtual IP Address
 Configure Virtual IP address and subnet mask

IP Address:
 Subnet Mask:

MTU (default: 1500)

New settings only take effect after your Router is rebooted. If necessary, reconfigure your PC's IP address to match new settings.

The following table describes the parameters of this page.

Field	Description
Primary IP Address	

Field	Description
IP Address	The management IP address of the LAN on the modem. By default, it is 192.168.1.1.
Subnet Mask	The subnet mask of the IP address. By default, it is 255.255.255.0.
Virtual IP Address	Select it, you can access the Internet through the virtual IP address. By default, it is not selected. After you select it, you are required to enter IP Address and Subnet Mask .
MTU	The maximum transmission unit. By default, it is 1500.

Enter the required parameters and click **Apply** to take it effect.

3.4.3.2 IPv6 Address

Click **IPv6 Address** in the **Local Network Configuration** page and the following page appears. In this page, enter the unicast IPv6 address of the LAN side, which should not begin with fe8.

Local Network Configuration
[IPv4 Address](#) | [IPv6 Address](#) | [DNS Client](#) | [DNS Relay](#) | [DNS LAN Host](#)

IPv6 LAN side configuration

Enable IPv6 Router

Disable IPv6 Router

IPv6 Address

Enter here the Unicast IPv6 address of your Lan Side interface.

IPv6 Address:

Enabling IPv6 Router will result in enabling the modem to act as a router on the LAN interface. The modem will send solicited/unsolicited router advertisements and also process received router advertisements on the LAN interface. It will send redirect messages to LAN side hosts so that routing is optimal on LAN side. It will also enable neighbor discovery protocol on the LAN interface.

3.4.3.3 DNS Client

Click **DNS Client** in the **Local Network Configuration** page and the following page appears. A DNS server is any PC registered to join the DNS. A DNS server

runs special-purpose networking software, features a public IP address, and contains a database of network names and addresses for other Internet hosts.

Local Network Configuration
[IPv4 Address](#) | [IPv6 Address](#) | **DNS Client** | [DNS Relay](#) | [DNS LAN Host](#)

Click Add to add new DNS Server.
Click Delete to delete an existing DNS Server.

IP Address	Delete

IP Address :

3.4.3.4 DNS Relay

Click **DNS Relay** in the **Local Network Configuration** page and the following page appears. The DNS relay responds to DNS requests from the LAN side. Usually it transmits DNS requests to other DNS servers to parse, the addresses of the DNS servers are obtained through the DHCP client.

Local Network Configuration
[IPv4 Address](#) | [IPv6 Address](#) | [DNS Client](#) | **DNS Relay** | [DNS LAN Host](#)

Click Add to add new DNS Relay Server.
Click Delete to delete an existing DNS Relay Server.

IP Address	Delete
172.24.10.10	
172.24.11.10	

Delete All

IPv4 Address IPv6 Address

IP Address :



Note:


Dial-up under bridge mode, the DNS setting is inefficient. When the DNS sends the request, the DNS client parses them by itself. If the parse is failed, it is delivered to a superior DNS server. DNS client can record some domain

information to the buffer. DNS relay does not parse them, and all the requests are transferred to a superior DNS server.


3.4.3.5 DNS LAN Host

When you enter a domain name into a browser, the PC must send a request to a DNS server to obtain the corresponding IP address immediately. The DNS server attempts to look up the domain name in its local host database immediately.

Click **DNS LAN Host** in the **Local Network Configuration** page and the following page appears.



Click **Create a New DNS hostname entry manually** and the following page appears.



The following table describes the parameters of this page.

Field	Description
Host Name	Enter the domain name.
IP Address	Enter the valid IP address of LAN host.

Click **Apply** to add the host name and IP address as DNS server. Then other hosts can access the PC through the domain name.

3.4.4 Voice Configuration

Voice over Internet Protocol (VoIP) is a technology that allows you to make voice calls using a broadband Internet connection instead of a regular phone line.

3.4.4.1 System Settings

Choose **Voice Configuration > System Settings** and the following page appears. In this page, you can view and modify the settings of system wide voice.

Voice Configuration
System Settings | [SIP](#) | [End Points](#) | [Dialing Plan](#)

System Settings
Status: Your VoIP service is enabled now. You can make VoIP phone calls.
[Go To Advanced view](#)

VoIP Functionality: Enable (SIP)
IP Interface Name: pppoe_0_35
Region: INDIA
Cid Type: FSK
DTMF Mode: Inband

[Go To Advanced view](#) Apply

Cid Type: Calling identity delivery (CID) supports field services kit (FSK), dual-tone multi-frequency (DTMF).

Select **Enable (SIP)** from the **VoIP Functionality** drop-down list, select the IP interface name and correct region.

Click **Go To Advanced view** and the following page appears. In this page, you can configure more settings of the VoIP parameter.

Voice Configuration
[System Settings](#) | [SIP](#) | [End Points](#) | [Dialing Plan](#)

System Settings
Status: Your VoIP service is enabled now. You can make VoIP phone calls.
[\[Go To Basic view\]](#)

VoIP Functionality	Enable (SIP) ▾
IP Interface Name	pppoe_0_35 ▾
Region	INDIA ▾
Cid Type	FSK ▾
DTMF Mode	Inband ▾
RFC 2833 Payload Type	101
RTP DSCP	000000
SIG DSCP	000000
Active Channels	1
Local TCP Port	5060
Local UDP Port	5060

[\[Go To Basic view\]](#) Apply

3.4.4.2 SIP

Click **SIP** in the **VoIP Configuration** page and the following page appears. In this page, you can view and modify the related settings of the SIP protocol.

Voice Configuration

[System Settings](#) | [SIP](#) | [End Points](#) | [Dialing Plan](#)

SIP Settings

Enter values for SIP Parameters and press Apply button to save SIP settings

[\[Go To Advanced view\]](#)

Proxy	<input type="text"/>
Proxy Port	<input type="text" value="5060"/>
Proxy Transport Type	<input type="text" value="UDP"/>
Proxy Routing	<input checked="" type="radio"/> Loose <input type="radio"/> Strict
Registrar	<input type="text"/>
Registrar Port	<input type="text" value="5060"/>
Registrar Transport	<input type="text" value="UDP"/>
Outbound Server	<input type="text"/>
Outbound Server Port	<input type="text" value="5060"/>
Outbound Server Transport	<input type="text" value="UDP"/>
User Domain	<input type="text"/>
Registration Expiration Time	<input type="text" value="3600"/>
Silence Suppression	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Echo Cancellation	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Packetization Period	<input type="text" value="20"/>

[\[Go To Advanced view\]](#)

Enter the proxy and the registrar in the corresponding fields. The proxy can be the IP address of the SIP server. Generally, the registrar is as same as proxy. Click **Go To Advanced view** and the following page appears. It provides more parameters for you to modify.

Voice Configuration

[System Settings](#) | [SIP](#) | [End Points](#) | [Dialing Plan](#)

SIP Settings

Enter values for SIP Parameters and press Apply button to save SIP settings


[\[Go To Basic view\]](#)

Proxy	<input type="text"/>
Proxy Port	<input type="text" value="5060"/>
Proxy Transport Type	<input type="text" value="UDP"/>
Proxy Routing	<input checked="" type="radio"/> Loose <input type="radio"/> Strict
Registrar	<input type="text"/>
Registrar Port	<input type="text" value="5060"/>
Registrar Transport	<input type="text" value="UDP"/>
Outbound Server	<input type="text"/>
Outbound Server Port	<input type="text" value="5060"/>
Outbound Server Transport	<input type="text" value="UDP"/>
Message Summary	<input type="text" value="Disable"/>
Subscription Server	<input type="text" value="none"/>
Subscription Port	<input type="text" value="5060"/>
Subscription Transport	<input type="text" value="UDP"/>
Subscription Duration	<input type="text" value="3600"/>
User Domain	<input type="text"/>
Registration Expiration Time	<input type="text" value="3600"/>
T.38 Fax Relay	<input type="text" value="disable"/>
T.38 Fax Max Bit Rate	<input type="text" value="14400"/>
Silence Suppression	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Echo Cancellation	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Packetization Period	<input type="text" value="20"/>


[\[Go To Basic view\]](#)

3.4.4.3 End Points

Click **End Points** in the **VoIP Configuration** page and the following page appears. In this page, you can view and modify end point settings, such as the login name, password. You can also view the registration status.



Click **Go To Advanced view** and the following page appears. It provides more parameters for you to modify.



It provides valid time for forward calling, and it supports three way conferences. Take the basic settings for example. Click and the following page appears. Enter **End Point Name** (such as 755222666, which is the called number) and other parameters. Then boot the system to take the settings effect immediately. The registration status display **Registered** if it is registered in the SIP server successfully.

Voice Configuration
[System Settings](#) | [SIP](#) | [End Points](#) | [Dialing Plan](#)

End Points Settings

[\[Go To Advanced view\]](#)

End Point Name	<input type="text" value="755222666"/>
Login Name	<input type="text" value="test"/>
Password	<input type="password" value="••••"/>
Display Name	<input type="text" value="test"/>
Admin State	<input type="text" value="inservice"/>
Registration Status	Unknown

[\[Go To Advanced view\]](#)

You can dial up the numbers by a call terminal, such as X-Lite or telephone. The number should have been registered in the SIP server to guarantee the conversation goes well.

3.4.4.4 Dialing Plan

Click **Dialing Plan** and the following page appears. In this page, you can view and modify digit map.

Voice Configuration
[System Settings](#) | [SIP](#) | [End Points](#) | [Dialing Plan](#)

Dial Plan Settings

Digit Map	<input type="text" value="(x.I ##S *[268]xS *74x.#S x#S *90x.#S *2x"/>
-----------	--

Digit map allows you to set the various dialing codes that are used to make VoIP calls. You can activate or deactivate certain services. It is recommended not to modify the default digit map, if you want to make VoIP call.

3.4.4.5 VoIP Configuration Example

The following describes the example of the voice configuration:

Step 1 Choose **Configuration > Voice Configuration**. Select a PVC from the **IP Interface Name** drop-down list, such as iplan. Then select the region.

Voice Configuration
System Settings | [SIP](#) | [End Points](#) | [Dialing Plan](#)

System Settings
Status: Your VoIP service is enabled now. You can make VoIP phone calls.
[\[Go To Advanced view\]](#)

VoIP Functionality: Enable (SIP) ▼
IP Interface Name: iplan ▼
Region: CHINA ▼
Cid Type: FSK ▼
DTMF Mode: Inband ▼

[\[Go To Advanced view\]](#) Apply

Step 2 Click **Apply** and the following page appears. Enter the proxy and registrar that are the IP address of the SIP server.

Voice Configuration

[System Settings](#) | [SIP](#) | [End Points](#) | [Dialing Plan](#)

SIP Settings

Enter values for SIP Parameters and press Apply button to save SIP settings

[\[Go To Advanced view\]](#)

Proxy	<input type="text" value="172.24.107.4"/>
Proxy Port	<input type="text" value="5060"/>
Proxy Transport Type	<input type="text" value="UDP"/>
Proxy Routing	<input checked="" type="radio"/> Loose <input type="radio"/> Strict
Registrar	<input type="text" value="172.24.107.4"/>
Registrar Port	<input type="text" value="5060"/>
Registrar Transport	<input type="text" value="UDP"/>
Outbound Server	<input type="text"/>
Outbound Server Port	<input type="text" value="5060"/>
Outbound Server Transport	<input type="text" value="UDP"/>
User Domain	<input type="text"/>
Registration Expiration Time	<input type="text" value="3600"/>
Silence Suppression	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Echo Cancellation	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Packetization Period	<input type="text" value="20"/>

[\[Go To Advanced view\]](#)

Step 3 Click **Apply** to take the settings effect.

Step 4 Click **End Points** in the **Voice Configuration** page and the following page appears.

Voice Configuration
[System Settings](#) | [SIP](#) | **End Points** | [Dialing Plan](#)

End Points Settings

[\[Go To Advanced view\]](#)

End Point Name
 Login Name
 Password
 Display Name
 Admin State
 Registration Status Unknown

[\[Go To Advanced view\]](#)

The following table describes the parameters of this page.

Field	Description
End Point Name	The call-up number.
Login Name	The authentication name for registering VoIP call.
Password	The authentication password for registering VoIP call.
Admin State	The service state. Usually, you should choose inservice .

After finishing the settings, reboot the modem to take the settings effective.
 If the login number is registered successfully, you can view the status.

Voice Configuration
[System Settings](#) | [SIP](#) | **End Points** | [Dialing Plan](#)

End Points Settings

[\[Go To Advanced view\]](#)

End Point Name	Login Name	Display Name	Mode	Registration Status	Detail	Edit
99900888	99900888	99900888	None	Registered		

[\[Go To Advanced view\]](#)

Now, you can make a VoIP call with another effective number that is registered on the SIP server.

3.4.5 DHCP Server

As a DHCP server, the modem maintains a pool of IP address and distributes it to LAN hosts.

3.4.5.1 Global Settings

Choose **Configuration > DHCP Server** and the following page appears. In this page, you can set the status of the DHCP server.

DHCP Server Configuration
[Global Settings](#) | [Server Settings](#) | [Advanced Settings](#)

DHCP Server Configuration
 This page allows you enable and disable the DHCP server. Also you can specify the interfaces that DHCP Server will operate on.

DHCP server status
 DHCP server is currently Enable Disable

DHCP server interfaces
 Use this section to edit the list of IP interfaces that the DHCP server will operate on. DHCP server status must be disabled for adding new DHCP server interface or deleting existing DHCP server interface.

Name	Delete
IP interface <input type="text" value="ip1an"/> <input type="button" value="Add"/>	

The following table describes the parameters of this page.

Field	Description
DHCP server is currently	Select it to enable DHCP server function. When the PC connected to the modem is set to obtain the IP address automatically, the modem takes a valid IP address from the IP address pool and assigns it to the PC. By default, DHCP server is enabled.
DHCP server interfaces	It is used to edit the list of IP address that the DHCP server operates on. DHCP server

Field	Description
	status must be disabled for adding a new DHCP server or deleting an existing DHCP server.

3.4.5.2 Server Settings

Click **Server Settings** and the following page appears. In this page, you can modify the DHCP server settings.

DHCP Server Configuration
[Global Settings](#) | [Server Settings](#) | [Advanced Settings](#)

DHCP Server Configuration
 This page allows creation of DHCP server subnets and DHCP server fixed host IP/MAC mappings.

Existing DHCP server subnets

Subnet Value	Subnet Mask	Use local host address as DNS server	Use local host address as default gateway	Assign Auto Domain Name	Edit	Delete
192.168.1.0	255.255.255.0	true	true	true		

Existing DHCP fixed IP/MAC mappings

IP Address	Mac Address	Max Lease Time	Default Lease Time	Edit	Delete
------------	-------------	----------------	--------------------	------	--------

Click **Add Fixed Host** and the following page appears. In this page, you can set host IP and MAC mapping.

DHCP Server Configuration
[Global Settings](#) | [Server Settings](#) | [Advanced Settings](#)

DHCP server fixed host IP/MAC mapping

Define your new fixed mapping here. The IP address you choose will be given to the host with the MAC address you specify. The IP address must not clash with an IP address already present in a dynamic address range. You should also ensure that there is a suitable subnet defined for the IP address to reside in. The MAC address should be expressed as 6 hexadecimal pairs separated by colons, e.g. 00:20:2b:01:02:03

DHCP server fixed host parameters

IP address

MAC address

Maximum lease time Seconds

Default lease time Seconds

The following table describes the parameters of this page.

Field	Description
Maximum lease time	It is the maximum value to which the default lease time can be set. The unit value is set in second. By default, it is 86400 seconds (24 hour).
Default lease time	It is the time that the DHCP server leases IP address to the DHCP client. After the preset time, the lease IP address is released. The unit value is set in second. By default, it is 43200 seconds (12 hour).

3.4.5.3 Advanced Settings

Click **Advanced Settings** and the following page appears. In this page, you can configure the advanced DHCP server classes and subnet-pools.

DHCP Server Configuration

[Global Settings](#) | [Server Settings](#) | **Advanced Settings**

Advanced DHCP Server Configuration

This page allows you to configure advanced DHCP server classes and subnet-pools

DHCP Classes

Use this section to edit DHCP Classes.

Class Name	Class Type	Class Data	Edit	Delete
Add				

Subnet Pools

Use this section to Add/Edit Subnet Pools.

Subnet	AllowClasses	DenyClasses	PoolRanges	Edit	Delete
192.168.1.0			192.168.1.2-192.168.1.17		 Delete All
Add					

Shared-Networks

Use this section to Add/Edit Shared Networks.

Shared Network Name	Subnet Value/Mask	Edit	Delete
Add			

Click **Add** in the **DHCP Classes** page and the following page appears.

DHCP Server Configuration
[Global Settings](#) | [Server Settings](#) | **Advanced Settings**

Add DHCP server class.
This page allows you to add/edit a DHCP server class.

Class Name:

Class Type: ▼

Class Data: ▼

Enter the class name and class data, and select class type. Click **Add** to show the following page.

DHCP Server Configuration

[Global Settings](#) | [Server Settings](#) | **Advanced Settings**

Advanced DHCP Server Configuration

This page allows you to configure advanced DHCP server classes and subnet-pools

DHCP Classes

Use this section to edit DHCP Classes.

Class Name	Class Type	Class Data	Edit	Delete
test	user-class			
				Delete All

[Add](#)

Subnet Pools

Use this section to Add/Edit Subnet Pools.

Subnet	AllowClasses	Denyclasses	PoolRanges	Edit	Delete
192.168.1.0			192.168.1.2-192.168.1.17		
				Delete All	

[Add](#)

Shared-Networks

Use this section to Add/Edit Shared Networks.

Shared - Network Name	Subnet Value/Mask	Edit	Delete

[Add](#)

Click in the **Subnet Pools** page. You can attach an existent class name, and set its attribute. Click **Apply** and the following page appears. In this page, you can view its status.

DHCP Server Configuration
[Global Settings](#) | [Server Settings](#) | **Advanced Settings**

Advanced DHCP Server Configuration

This page allows you to configure advanced DHCP server classes and subnet-pools

DHCP Classes

Use this section to edit DHCP Classes.

Class Name	Class Type	Class Data	Edit	Delete
test	user-class			Delete All

[Add](#)

Subnet Pools

Use this section to Add/Edit Subnet Pools.

Subnet	AllowClasses	DenyClasses	PoolRanges	Edit	Delete
192.168.1.0	test		192.168.1.2-192.168.1.17		Delete All

[Add](#)

Shared-Networks

Use this section to Add/Edit Shared Networks.

Shared Network Name	Subnet Value/Mask	Edit	Delete
---------------------	-------------------	------	--------

[Add](#)

In the **Shared-Networks** page, you can add or edit the DHCP shared networks.

3.4.6 DHCP Relay

Choose **Configuration > DHCP Relay** and the following page appears. In this page, you can modify the DHCP relay settings or add DHCP server address or interfaces running DHCP relay. DHCP relay is used to send the DHCP client request to other DHCP server across several physical and logical sub-networks. For a DHCP client, the relay acts as a DHCP server, and this operation is

transparent. It is prohibited to run the DHCP server and the DHCP relay simultaneously.

DHCP Relay Configuration

Relay Settings

DHCP Relay Settings

DHCP Relay is currently Enable Disable

DHCP Server Address **Actions**

. . .

Interfaces Running DHCP Relay **Actions**

The following table describes the parameters of this page.

Field	Description
DHCP Server Address	The IP address of the DHCP server to WAN
Interfaces Running DHCP Relay	DHCP request sends out through this interface.



Note:

After entering the effective server address in the DHCP server address in the **DHCP Relay Settings** page, you must list all interfaces that the DHCP relay needs to bind to, for both sending and receiving packets. For example, it is not enough to only bind to a LAN interface (iplan) to receive the requests from the DHCP clients. It is also necessary to bind a WAN interface.

3.4.7 IPv6 Prefix

Choose **Configuration > IPv6 Prefix** and the following page appears. In this page, the prefixes are added to the LAN side interface. Then, the modem advertises these prefixes in router advertisements on the LAN side. LAN side hosts can auto configure them using these prefixes. All prefixes are advertised as on-link and autonomous.

IPv6 Prefix Lan Side Configuration

Current Prefixes:

Prefix	Prefix Length	Prefered Life Time	Valid Life Time	Delete

Add New Prefix:

IPv6 Prefix:

Prefix Length:

Pref Life Time: (In Seconds)

Valid Life Time: (In Seconds)

The prefixes added from this page are added to the LAN side interface. The modem then advertises these prefixes in router advertisements on the LAN side. LAN side hosts can auto configure them using these prefixes. All prefixes are advertised as on-link and autonomous.

3.5 Security

Click **Security** to enter security configuration page. On the left page, there are three options: **IP Filtering**, **Port Forwarding**, and **Virtual Server**.

3.5.1 IP Filtering

Choose **Security > IP Filtering** and the following page appears. In this page, you can specify the IP packet filtering rules to prevent unsolicited access from the Internet or limit the Internet access from PCs on your network.

IP Filter Configuration

IP Filter Settings
This page allows you to specify the IP packet filtering rules to prevent unsolicited access from the Internet or limit the Internet access for computers on your network.

IP Filtering Disable Enable

Port Filters

Filter Name	Policy Name	Protocol	Filter Action	Source IP Range	Source Port Range	Destination IP Range	Destination Port Range	Direction	Status	Delete
				Start End	Start End	Start End	Start End			
all-out	ext-int	ALL	Allow	0.0.0.0 255.255.255.255	0 65535	0.0.0.0 255.255.255.255	0 65535	OutBound	Enabled	
mcast	ext-int	UDP	Allow	0.0.0.0 255.255.255.255	0 65535	224.0.0.1 239.255.255.255	0 65535	Both	Enabled	

The IP filter feature enables you to create rules that control the forwarding of incoming and outgoing data between the LAN and WAN side. When you define an

IP filter rule and enable it, you instruct the modem to examine data packets to determine whether they meet the criteria. The criteria can include the network or Internet protocol, the packet carries, the direction in which it is traveling.

Add an IP filter rule

The procedure for adding an IP filter rule is as follows:

Step 1 Enable **IP Filtering** and click **Add**.

IP Filter Configuration
IP Filter

Add New Outbound IP Filtering Rule

Port Filter Rule

Filter Rule Name:

Select policy:

Select the direction to filter packets: Outbound traffic
 Inbound traffic
 Both

Protocol:

Filter Action:

Source IP Range: Start End
IP/Mask IP/Mask

Destination IP Range: Start End
IP/Mask IP/Mask

Source Port Range: Start End

Destination Port Range: Start End

Status: Enable Disable

Step 2 Enter the filter rule name and other parameters. Click **Apply**. In this example, enter **aa** in the **Filter Rule Name** field. This rule named aa can forbid any application corresponding to port from 1 to 80.

IP Filter Configuration

IP Filter

Add New Outbound IP Filtering Rule

Port Filter Rule

Filter Rule Name:

Select policy:

Select the direction to filter packets: Outbound traffic
 Inbound traffic
 Both

Protocol:

Filter Action:

Source IP Range: Start End
 IP/Mask

Destination IP Range: Start End
 IP/Mask

Source Port Range: Start End

Destination Port Range: Start End

Status: Enable Disable

Step 3 Click **Apply** and the following page appears. In the **IP Filter Configuration** page, you can view the result of the IP filter configuration.

The screenshot shows the 'IP Filter Configuration' page with a sidebar on the left containing navigation links like Home, Overview, System Log, Troubleshooting, Configuration, Security, Services, DSL Home, Port Statistics, and Admin. The main content area is titled 'IP Filter Configuration' and includes 'IP Filter Settings' with a description and a status toggle for 'IP Filtering' set to 'Disable'. Below this is a table of 'Port Filters'.

Filter Name	Policy Name	Protocol	Filter Action	Source IP Range		Source Port Range		Destination IP Range		Destination Port Range		Direction	Status	Delete
				Start	End	Start	End	Start	End	Start	End			
all-out	ext-int	ALL	Allow	0.0.0.0	255.255.255.255	0	65535	0.0.0.0	255.255.255.255	0	65535	OutBound	Enabled	
mcast	ext-int	UDP	Allow	0.0.0.0	255.255.255.255	0	65535	224.0.0.1	239.255.255.255	0	65535	Both	Enabled	
aa	ext-int	TCP	Allow	0.0.0.0	255.255.255.255	1	65535	0.0.0.0	255.255.255.255	1	80	OutBound	Enabled	

3.5.2 Port Forwarding

Choose **Security > Port Forwarding** and the following page appears. In this page, you can create, modify, and delete port forwarding rules. These rules allow applications or software to work on your PCs if the Internet connection uses NAT.

Port Forwarding Configuration

Port Forwarding Settings
 This page allows to create, modify and delete port forwarding rules. These rules allow applications or software to work on your computers if the Internet connection uses NAT.

Name	Protocol	External Port	Internal IP	Internal Port	Edit	Delete
<input type="button" value="Add"/>						

Click **Add** and the following page appears. The IP packages of the Camerades application of Audio/Video service that come from the WAN Interface ipwan is forwarded to the host with IP address 192.168.1.2. If you select **User defined** with a self-defined name, you can configure the parameters in the page.

Port Forwarding

Add New Port Forwarding Rule

Name:
 Pre-defined: Audio/Video Camerades
 User defined:

WAN Interface : ipwan

Forward to Internal Host IP Address:

By using the rules:


Protocol/Type	External Packet		Forward to Internal Host	
	Port Start	Port End	Port Start	Port End
<input type="button" value="v"/> None <input type="button" value="v"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
<input type="button" value="v"/> None <input type="button" value="v"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
<input type="button" value="v"/> None <input type="button" value="v"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>


3.5.3 Virtual Server

Choose **Security > Virtual Server** and the following page appears. A virtual server is a PC on your local network that can be accessed from the Internet. All interfaces for virtual server is listed.

Virtual Server Configuration

DMZ Host
A DMZ host is a computer on your local network that can be accessed from the Internet.

Interface	DMZ Host	Edit
pppoe_0_35	N/A	

Take pppoe_0_35 for example. Click  to show the **DMZ Host Configuration** page. Enter the host address, such as 192.168.1.2. Click **Apply**. Remote user can access the host 192.168.1.2 by the interface pppoe_0_35. IP filter should be disabled or add relevant rule. Otherwise, the access request can not reach the DMZ host.).

Virtual Server Configuration

DMZ Host Configuration
A DMZ host is a computer on your local network that can be accessed from the Internet.

Those IP packets from the interface **pppoe_0_35** that do NOT belong to any applications configured in the port forwarding table will be:

Discarded

Forwarded to the DMZ host

IP address of DMZ host:


3.6 Services

Click **Services** to enter service configuration page. On the left page, there are five options: **IGMP Proxy**, **IPv4 Routing**, **IPv6 Routing**, **Quality of Service**, and **Mac Filtering**.

3.6.1 IGMP Proxy

Choose **Services > IGMP Proxy** and the following page appears. Internet Group Multicast Protocol (IGMP) is used by routers and hosts that support multicasting. All the systems on a physical network identify the multicast grouping of specific hosts through IGMP. The multicast routers learn this information and forward the multicast datagram to the corresponding interfaces. The IGMP proxy holds up the

request of the terminal. After disposing, the information is transmitted to the super-level router. The system acts as a proxy for its hosts after you enable IGMP proxy.



3.6.2 IPv4 Routing

3.6.2.1 Static Routing

Choose **Services > IPv4 Routing** and the following page appears. In this page, you can configure static route and dynamic routing. A default route is used to send IP packages of unknown destination address to the default gateway. The default route defines the IP address where all data is forwarded.



The following table describes the parameters of this page.

Field	Description
Destination	The IP address that packets are sent to.
Netmask	The subnet mask of the destination IP address.
Gateway	The gateway that the packets pass by during

Field	Description
	transmission.
WAN Interface	The WAN interface that the packets pass through on the modem.

Click **Add** in the **Static Routing** page. In this page, you can add static routing. You need to provide the destination IP address and netmask. You also need to enter the gateway IP address or the interface through which the packets are forwarded in the corresponding fields. The interface can be `iplan`, `ipwan` or you can specify the interface that the modem has.

IP Routing Configuration
[Static Routing](#) | [Dynamic Routing](#)

Add New Static Route

Destination For default route, type 0.0.0.0 or leave blank

IP Address:

Netmask:

Forward packets to

Gateway IP address:

Interface:


3.6.2.2 Dynamic Routing

Click **Dynamic Routing** in the **IP Static Route Settings** page. In this page, you can configure the dynamic routing for any existing interface. You can enable or disable operation mode and RIP version for a particular interface.

IP Routing Configuration
[Static Routing](#) | [Dynamic Routing](#)

IP Dynamic Routing Settings
 You can configure dynamic routing for any existing interface using edit image link of the interface.

Interface	RIP Version	Operation Mode	Multicast	Enabled	Edit
pppoe_0_35	N/A	N/A	False	⊘	⋮
iplan	N/A	N/A	False	⊘	⋮

Click  and the following page appears.

IP Routing Configuration

[Static Routing](#) | **Dynamic Routing**

IP Dynamic Routing Configuration

You can enable the function on several interfaces of your Router. Select the desired RIP version and operation mode, then tick the 'Enable' checkbox to enable RIP.

Interface Name:

RIP Version:

Operation Mode:

Multicast Send Type

Enable:

The following table describes the parameters of this page.

Field	Description
RIP Version	There are 1, 2, and Both options in the drop-down list.
Operation Mode	<p>You can choose Provide Active, Passive, and Send only.</p> <ul style="list-style-type: none"> ● Choose Active for transmitting and receiving RIP interactive information. ● Choose Passive for only receiving information. ● Choose Send Only for transmitting information.

Check to enable related interfaces and then click **Apply** to take the settings effect immediately.

3.6.3 IPv6 Routing

Choose **Services > IPv6 Routing** and the following page appears. In this page, you can configure static route and dynamic routing.

IPv6 Routing Configuration
Static IPv6 Routing

Current routes:

Prefix	PrefixLength	Gateway	Interface	Delete

Add IPv6 Route

Prefix:

PrefixLength:

Forward packets to

Gateway address:

Interface:

The following table describes the parameters of this page.

Field	Description
Prefix	Enter the IPV6 IP address.
PrefixLength	Enter the length of the prefix. The prefix length is not larger than 128bit.
Forward packets to	<p>Select the packet route. You can select the packets are forwarded to the gateway or WAN interface.</p> <ul style="list-style-type: none"> ● If set to gateway, you need to enter the gateway address. ● If set to WAN interface, you need to choose the WAN interface.

3.6.4 Quality of Service

Choose **Services > Quality of Service** and the following page appears. This page shows a summary of the QoS and scheduler settings available on the system.

Quality of Service Configuration

Quality of Service
This page shows a summary of the QoS and Scheduler settings available on the system. Click Edit icon to View or Modify the complete QoS rule parameters.

QoS Status: Enabled Disabled

[Apply](#)

QoS Rule	Status	Edit	Delete

[Add](#)

Scheduler Settings
Use this section to configure the Scheduler settings on the system applicable to upstream traffic.

Scheduler Type: Priority Wf2qPlus None

Delaybound (bytes):

Max Rate (kbps):

Max Burst (bytes):

[Advanced Settings](#) [Apply](#)

Click **Add** and the following page appears. In this page, you can specify quality of service (QoS) rules to upstream traffic. All of specified conditions in the traffic rule must be satisfied for the rule to take effect.

Quality of Service Configuration

QoS Rule Configuration

This page allows you to specify Quality of Service (QoS) rules to upstream traffic. All of specified conditions in the traffic rule must be satisfied for the rule to take effect.

Rule Name: Rule Status: Enable Disable

Matching Criteria

Physical Port: ethernet0 ethernet1 ethernet2 ethernet3

Source Mac Address: Destination Mac Address:

802.1p priority: ~ VLAN ID (1 to 4094): ~

Source IP Address: Destination IP Address:

IPP/DS Field: IPP/TOS DSCP

IP Precedence Range: ~ DSCP Range (0 to 63): ~

Type of Service:

Protocol:

Source Port: ~ Destination Port: ~

Actions

Mark 802.1P Priority: Mark VLAN ID (1 to 4094):

Mark Traffic Priority:

Mark IPP/DS: IPP/TOS DSCP

IP Precedence Range: DSCP Range (0 to 63):

Type of Service:

3.6.5 Mac Filtering

Maybe you want to manage the MAC address to block or permit a PC on the LAN. When you enable MAC filter rules, the modem serves as a firewall that works at layer 2. The following describes the example of the Ethernet transport.


3.6.5.1 Rule

Click **Rule** in the **Mac Filter Configuration** page and the following page appears.

Mac Filter Configuration
[Transport](#) | [Profile](#) | [Rule](#)

Rule Settings
 This section allows you to configure filtering rules on the system.

Rule Name	Status	Source Mac match criteria	Destination Mac match criteria	Action	Delete Edit
r1	Enabled				

Click  and the following page appears. In this page, you can configure filtering rules on the system.

Mac Filter Configuration
[Transport](#) | [Profile](#) | [Rule](#)

Add Rule
 Use this page to add or edit a filtering rule

Rule Name:

Status: Enable Disable

Action:

Field	Enable Field	Operator	Value1	Value2
Source Mac:	<input checked="" type="checkbox"/>	<input type="text" value="GT"/>	<input type="text"/>	<input type="text"/>
Destination Mac:	<input checked="" type="checkbox"/>	<input type="text" value="LT"/>	<input type="text"/>	<input type="text"/>

The following table describes the parameters of this page.

Field	Description
GT	Greater than
LT	Less than
GTEQ	Greater than and equal to
LTEO	Less than and equal to
EQ	Equal to
NEQ	Not equal to
INRANGE	Include the range
EXRANGE	Exclude the range

The source MAC value is 00:1E:E3:00:2B:1C, that is the Ethernet physical address. The destination MAC value is 00:1E:E3:00:2D:BC. After finishing the settings of rule status and action, click **Apply** to take it effect.

Mac Filter Configuration

[Transport](#) | [Profile](#) | **Rule**

Rule Settings

This section allows you to configure filtering rules on the system.

Rule Name	Status	Source Mac match criteria	Destination Mac match criteria	Action	Delete Edit
r1	Enabled				
r2	Enabled	GT, 00:1E:E3:00:2B:1C	GT, 00:1E:E3:00:2D:BC	drop	

[Add](#)


3.6.5.2 Profile

Click **Profile** in the **Mac Filter Configuration** page. In this page, you can create and configure filtering profiles.

Mac Filter Configuration
[Transport](#) | **Profile** | [Rule](#)

Profile Settings
 This section allows you to create and configure filtering profiles.

Profile	Rules	Edit	Delete
p1	r1		

Add a profile name as p2, and then click  to edit the p2. In this page, you can attach or detach more than one filtering rules to a profile.

Mac Filter Configuration
[Transport](#) | **Profile** | [Rule](#)

Edit Profile
 Use this page to attach and detach filtering rules to a profile

Rule Name	Detach
<input type="text" value="r1"/> <input type="text" value="r2"/>	<input type="button" value="Attach"/>

[\[Back to profiles\]](#)

3.6.5.3 Transport

Choose **Mac Address > Transport** and the following page appears. In this page, you can attach or detach filtering profiles to a transport. You can also enable or disable filtering on a transport.

Mac Filter Configuration

[Transport](#) | [Profile](#) | [Rule](#)

Transport settings
 This section allows you to attach/detach filtering profiles to a transport and enable/disable filtering on a transport.

Transport	State	Tx Path Profiles	Rx Path Profiles	Edit
wlan	Enabled		p1,	
ethernet0	Enabled		p1,	
ethernet1	Enabled		p1,	
ethernet2	Enabled		p1,	
ethernet3	Enabled		p1,	
bridge_0_35	Disabled			
bridge_8_35	Disabled			
bridge_8_81	Disabled			
bridge_0_100	Disabled			
PppoeUp	Disabled			

Before attaching the filtering profile to the specified transport, the profiles and rules should be configured. For example, click of the Ethernet transport. . You can configure p1 attach Tx Path for the Ethernet transport, and it matches the corresponding settings of rule1.

Mac Filter Configuration

[Transport](#) | [Profile](#) | [Rule](#)

Attach or Detach Filtering Profiles
 Use this page to enable or disable filtering on ethernet0 transport and attach or detach filtering profiles to it.

Profile	Tx/Rx Path	Detach
p1 <input type="text" value="p1"/>	Rx <input type="text" value="Tx"/>	 <input type="button" value="Attach"/>

L2 Filter must be enabled on ethernet0 transport to view profiles.

L2 Filter Enabled

[\[Back to Transport settings\]](#)

Select **L2 Filter Enabled** and ping the IP address of the modem as 192.168.1.1 from PC. It is failed, because the tx path attaches to the rule1 and no rx path returns back. If enter the CLI commands: **transports detach ethernet l2 filter profile profile1 Rx** by serial port to detach the rx path, it succeeds to ping.



Note:

when you configure the MAC filtering for the first time, refer to the following procedure: Firstly, adding the rules. Secondly, attaching them to the profile. Then, attaching the profiles to the specified transport.


3.7 DSL Home

Click **DSL Home** to enter DSL home page. On the left page, there are two options: **Management Server** and **CWM Parameters**.

3.7.1 Management Server

TR069 is a popular network management protocol, and its connecting way is TCP, carrier is HTTP, MIF (information format) is XML, SSL as optional encrypt method. It provides the management of software, firmware by mirrors, status and capability monitor, diagnosis, and Web supervision to the user equipment.

Choose **DSL Home > Management Server** and the following page appears. In this page, you can configure the parameters of the management server.



The following table describes the parameters of this page.

Field	Description
URL	URL for the modem to connect to the ACS using CPE WAN Management Protocol (CWMP). This parameter must be in the form of a valid HTTP or HTTPS URL. HTTPS URL indicates that the ACS supports SSL. The host portion of this URL is used by the modem to validate the certificate from the ACS when using the certificate-based authentication.
Username	Username is used to authenticate the modem when establishing a connection to the ACS using the CWMP. This username is used only for HTTP-based authentication of the modem.
Password	The password is used to authenticate the modem when establishing a connection to the ACS using CWMP. This password is used only for HTTP-based authentication of the modem. When read, this parameter returns an empty string, regardless of the actual value.
Periodic Inform	If you select Enable , the modem must periodically

Field	Description
	send the modem information to server using the inform method call.
Periodic Inform Interval	The duration in seconds of the interval for which the modem must attempt to connect with the ACS and call the inform method if periodic inform is enabled.
Periodic Inform Time	An absolute time reference in UTC to determine when the modem should initiate the inform method calls. Each inform call must occur at this reference time plus or minus an integer multiple of the periodic inform interval. A zero date time value (0000-00-00T00:00:00) indicates that no particular time reference is specified. That is, the modem may locally choose the time reference, required only to adhere to the specified periodic inform interval.
Parameter Key	The value of the parameter key argument from the most recent set parameter values, add object, or delete object method call from the server. If there do not have such calls, this value is empty.
Connection Request URL	HTTP URL for an ACS to make a connection request notification to the modem.
Connection Request Username	Username is used to authenticate an ACS. It makes a connection request to the modem.
Connection Request Password	Password is used to authenticate an ACS making a connection request to the modem. When read, this parameter returns an empty string, regardless of the actual value.
Upgrades Managed	It indicates whether or not the ACS will manage upgrades for the modem. If it is true, the modem only uses ACS to seek out available upgrades. If it is false, the modem may use other means for this purpose.
ACS Discovery	Whether or not the modem must enable ACS discovery from DHCP.

3.7.2 CWM Parameters

Choose **DSL Home > CWM Parameters** and the following page appears. In this page, you can modify the customer premise equipment WAN management (CWM) parameters. It displays the CWM parameters received from CWMP application.

DSL Home
CWM Parameters

CWM Parameters configuration
This page allows you to configure CWMPParameters's parameter.

Configure the parameters of CWMPParameters here.

CRN Auth Type :

CWM : Enable Disable

The following are the Read-Only Parameters of CWM.

Bootstrap : true

Trigger Set : 0

Reboot Command Key :

Command Key	Fault Code	Start Time	Complete Time	Is Download	Request Id
-------------	------------	------------	---------------	-------------	------------

3.8 Port Statistics

Click **Port Statistics** to enter port statistics page. On the left page, there are eight options: **Voipfex0**, **Voipcmdstat**, **DSL**, **Ethernet0**, **Ethernet1**, **Ethernet2**, **Ethernet3**, and **Wireless**.

3.8.1 Voipfex0

This page displays the current status and configuration of the FXS port.

3.8.1.1 Basic

Choose **Port Statistics > Voipfex0** and the following page appears. In this page, you can view the information of the FXS port.

Port Configuration
[Basic](#) | [Advanced](#)

Voipfxs0 Port Configuration
 This page allows you to view the values of port parameters.

Generate SID	false
Coder Type Upstream	G711U
Jitter Max Delay	200
Jitter Nominal	40
Jitter Dynamic	true
Dtmf Relay	0
Echo Control	true
Packet Rate	20
Gain Ctrl Up	0
Gain Ctrl Dn	0
Fxs Seize Time	100
Fxs Release Time	900
Fxs Hf Max Time	900
Fxs Hf Min Time	300
Fxs Min Pulse	20
Fxs Max Pulse	110
Fxs Pulse Pause	300
Reset Defaults	false

[\[Go To Advanced View\]](#)

The following table describes the parameters of this page.

Field	Description
Jitter Dynamic	Provide jitter buffer adjustment if it is true.
Reset Defaults	Reset to the default values after rebooting.

3.8.1.2 Advanced

Click **Advanced** in the **Voipfxs0 Port Configuration** page and the following page appears. In this page, you can view the information of the FXS port.

Port Configuration[Basic](#) | [Advanced](#)**Voipfxs0 Port Configuration**

This page allows you to view the values of port parameters.

Dsp Id	0
Dsp Port Id	0
Dsp Version	
Port Type	fxs
Generate SID	false
Coder Type Upstream	G711U
Jitter Max Delay	200
Jitter Nominal	40
Jitter Dynamic	true
Dtmf Relay	0
Echo Control	true
Use JB	true
Packet Rate	20
Gain Ctrl Up	0
Gain Ctrl Dn	0
Out Of Service	false
Fxs Seize Time	100
Fxs Release Time	900
Fxs Hf Max Time	900
Fxs Hf Min Time	300
Fxs Min Pulse	20
Fxs Max Pulse	110
Fxs Pulse Pause	300
Cid Type	3
Ring Type	1
Default Jitter Max Delay	200
Default Jitter Nominal	40
Default Jitter Dynamic	true
Default Generate SID	false
Default Coder Type Upstream	G711U
Default Dtmf Relay	false
Default Use JB	true
Default Echo Control	true
Default Packet Rate	20
Default Gain Ctrl Up	0
Default Gain Ctrl Dn	0
Default Fxs Seize Time	100
Default Fxs Release Time	900
Default Fxs Hf Max Time	900
Default Fxs Hf Min Time	300
Default Fxs Min Pulse	20
Default Fxs Max Pulse	110
Default Fxs Pulse Pause	300
Reset Defaults	false
Port Snmp If Index	0
Port Snmp If Type	0

The following table describes the parameters of this page.

Field	Description
Cid Type	Calling identity delivery (CID) type.
Reset Defaults	Reset to the default values after rebooting.



Note:

Some of the attributes displayed in the **Voipfxs0 Port Configuration** page can be set from the CLI. Enter **port voipfxs0 set ?**. The attributes is displayed as the output of this command. Its function depends on the configuration of the DSLAM and the capability of the central office the modem connected to.

3.8.2 Voipcmdstat

This page displays the current status and configuration of the voipcmdstat port.

3.8.2.1 Basic

Choose **Port Statistics > Voipcmdstat** and the following page appears. In this page, you can view the the information of voipcmdstat port.

Port Configuration
[Basic](#) | [Advanced](#)

Voipcmdstat Port Configuration
 This page allows you to view the values of port parameters.

Generate SID	false
Coder Type Upstream	G711U
Jitter Max Delay	200
Jitter Nominal	40
Jitter Dynamic	true
Dtmf Relay	0
Echo Control	true
Packet Rate	20
Gain Ctrl Up	0
Gain Ctrl Dn	0
Fxs Seize Time	100
Fxs Release Time	900
Fxs Hf Max Time	900
Fxs Hf Min Time	300
Fxs Min Pulse	20
Fxs Max Pulse	110
Fxs Pulse Pause	300
Reset Defaults	false

[\[Go To Advanced View\]](#)

3.8.2.2 Advanced

Click **Advanced** in the **Voipcmdstat Port Configuration** page and the following page appears. In this page, you can view the the information of voipcmdstat port.

Port Configuration	
Basic Advanced	
Voipcmdstat Port Configuration	
This page allows you to view the values of port parameters.	
Dsp Id	0
Dsp Port Id	0
Dsp Version	
Port Type	cmdstat
Generate SID	false
Coder Type Upstream	G711U
Jitter Max Delay	200
Jitter Nominal	40
Jitter Dynamic	true
Dtmf Relay	0
Echo Control	true
Use JB	true
Packet Rate	20
Gain Ctrl Up	0
Gain Ctrl Dn	0
Out Of Service	false
Fxs Seize Time	100
Fxs Release Time	900
Fxs Hf Max Time	900
Fxs Hf Min Time	300
Fxs Min Pulse	20
Fxs Max Pulse	110
Fxs Pulse Pause	300
Cid Type	2
Ring Type	1
Default Jitter Max Delay	200
Default Jitter Nominal	40
Default Jitter Dynamic	true
Default Generate SID	false
Default Coder Type Upstream	G711U
Default Dtmf Relay	false
Default Use JB	true
Default Echo Control	true
Default Packet Rate	20
Default Gain Ctrl Up	0
Default Gain Ctrl Dn	0
Default Fxs Seize Time	100
Default Fxs Release Time	900
Default Fxs Hf Max Time	900
Default Fxs Hf Min Time	300
Default Fxs Min Pulse	20
Default Fxs Max Pulse	110
Default Fxs Pulse Pause	300
Reset Defaults	false
Port Snmp If Index	0
Port Snmp If Type	0



Note:

Some of the attributes displayed in the voipcmdstat port configuration page can be set from the CLI. Enter **port voipcmdstat set ?**. The attributes is displayed as the output of this command. Its function depends on the configuration of the DSLAM and the capability of the central office the modem connected to.

3.8.3 DSL

This page displays the current status and configuration of the DSL port.

3.8.3.1 Basic

Choose **Port Statistics > DSL** and the following page appears. In this page, you can view the the following information. The attributes and values are displayed as the output depending on the configuration of the DSLAM that the modem is connected with.

Port Configuration
[Basic](#) | [Advanced](#)

DSL Port Configuration
 This page allows you to view the values of port parameters.

Driver Version	1.75
APIVersion	GS_API_650
Firmware Version	E.25.41.57 A
Dsp Version	0x00000000
Common Handshake	Enable
Connected	false
Operational Mode	Inactive
State	HandShake
Watchdog	0x00000000
Operation Progress	0x00000018
Last Failed	0x00000000
Tx Bit Rate	0
Rx Bit Rate	0
Rx ATTNR	
Tx ATTNR	
Annex Type	
Tx Cell Rate	0
Rx Cell Rate	0
Overall Failure	0
Data Boost	
Local ITUCountry Code	
INPup	0.00
INPdown	0.00
PMStatus	Unknown (3182)
PSDMask Status	
Status Fail Count	0
Profile Status	
Action	Startup
Activate Line	None
Host Control	Enable
Auto Start	true
Failsafe	true
Showtime Led	3
Retrain	EnableOverallOnly
Defaults	None
Whip	Disable
Whip Active	Inactive
Whip Mode	Standalone
Dying Gasp	Enable
Utopia Interface	Level1
Physical Port	0
Clock Type	Crystal
Generic Trace	DSP
Debug	disable
Max RSMemory	32
Profile	MAIN
Detect Noise	Disable
Port Speed	20000
Reset Defaults	false

[\[Go To Advanced View\]](#)

The following table describes the parameters of this page.

Field	Description
Driver Version	The information of driver version.
APIVersion	Application program interface (API) version.

Field	Description
Firmware Version	The modem version.
Dsp Version	Digital signal processor (DSP) version
Operational Mode	The synchronism mode.
Watchdog	Inspect the running estate of the application program.
Reset Defaults	Reset to the default values after rebooting.

3.8.3.2 Advanced

Click **Advanced** in the **DSL Port Configuration** page and the following page appears.

Port Configuration
[Basic](#) | [Advanced](#)

DSL Port Configuration
 This page allows you to view the values of port parameters.

Driver Version	1.75
APIVersion	GS_API_650
Firmware Version	E.25.41.57 A
Dsp Version	0x00000000
Common Handshake	Enable
Connected	false
Operational Mode	Inactive
State	HandShake
Watchdog	0x00000000
Operation Progress	0x00000018
Last Failed	0x00000000
Tx Bit Rate	0
Rx Bit Rate	0
Delt ACTATPds	+0.0 dB
Delt ACTATPus	+0.0 dB
Delt HLINscds	0
ACTPSDDs	
ACTPSDUd	
Bis TEQError	
Rx ATTNDR	

The following table describes the parameters of this page.

Field	Description
CACMode	Connection admission control (CAC) mode.
Traffic Shaping	The volume of adapter communication.
Is Dsl Dma Up	Direct memory access supported high broadband.

Field	Description
Reset Defaults	Reset to the default values after rebooting.

**Note:**

Some of the attributes displayed in the **DSL Port Configuration** page can be set from the CLI. Enter **port a1 set ?**. The attributes is displayed as the output of this command. Its function depends on the configuration of the DSLAM and the capability of the central office the modem connected to.

3.8.4 Ethernet0/1/2/3

This page displays the current status and configuration of the Ethernet port. The modem has four Ethernet ports. Because they are similar, we describe the example of one Ethernet port. If the Ethernet port is working currently, the connected status displays true. On the contrary, it displays false. the Mac value is different if the Ethernet port is not same.

3.8.4.1 Basic

Choose **Port Statistics > Ethernet0** and the following page appears. In this page, you can view the the information of Ethernet port.

Port Configuration
[Basic](#) | [Advanced](#)

Ethernet0 Port Configuration
 This page allows you to view the values of port parameters.

MAC	00:10:20:30:40:50
Connected	true
Link Speed	100M
Reset Defaults	false

[\[Go To Advanced View\]](#)

The following table describes the parameters of this page.

Field	Description
MAC	The network adapter interface identifier with 48 bits unique global address.
Connected	It displays the connection status.

Field	Description
Reset Defaults	Reset to the default values after rebooting.

3.8.4.2 Advanced

Click **Advanced** in the **Ethernet0 Port Configuration** page and the following page appears. In this page, you can view the following information of the Ethernet port.

Port Configuration

[Basic](#) | **Advanced**

Ethernet0 Port Configuration

This page allows you to view the values of port parameters.

MAC	00:10:20:30:40:50
Lower Port	port=raw_ethernet/promiscuousenable=true
TAG	2
Connected	true
Link Speed	100M
Map Port	raw_ethernet
Map Port Connected	PortLinkStatus
Map Port Link Speed	LinkSpeed
Map Port Link Speed Mult	1
Map Port Link Speed Div	1
Map Port Index	0
Global Port	0x00aef118
No Rx Demux	false
No Tx Tag	false
Promiscuous Enable	true
Rx Errored	0
Rx Global LUTFail	1
Rx Global No8021Q	0
Rx Too Short	0
Rx Wrong MAC	0
Reset Defaults	false
Port Snmp If Index	0
Port Snmp If Type	0

[\[Go To Basic View\]](#)

Note:

Some of the attributes displayed in the **Ethernet0 Port Configuration** page can be set from the CLI. Enter **ethernet set ?**. The attributes is displayed as the output of this command. Its function depends on the configuration of the DSLAM and the capability of the central office the modem connected to.

3.8.5 Wireless

This page displays the current status and configuration of the wireless port.

3.8.5.1 Basic

Choose **Port Statistics > Wireless** and the following page appears. In this page, you can view the the information of wireless port.

Port Configuration
[Basic](#) | [Advanced](#)

Wireless Port Configuration
 This page allows you to view the values of port parameters.

Authentication	Open
Encryption	WEP128
Auto Channel	true
Connected	false
Current Country	INI
Default Channel	1
Default Tx Key	0
Disable	true
ESSID	BSNL_AP
Link Speed	0
MAC	00:15:e9:00:00:02
Mode128Key0	12-34-56-78-90-12-34-56-78-90-12-34-56
Mode128Key1	00-00-00-00-00-00-00-00-00-00-00-00
Mode128Key2	00-00-00-00-00-00-00-00-00-00-00-00
Mode128Key3	00-00-00-00-00-00-00-00-00-00-00-00
Mode64Key0	00-00-00-00-00
Mode64Key1	00-00-00-00-00
Mode64Key2	00-00-00-00-00
Mode64Key3	00-00-00-00-00
Profile	MIXED_G_WIFI
Transmit Rate	Automatic
WPAEnable WPA1	false
WPAEnable WPA2	false
WPA	false
Reset Defaults	false

[\[Go To Advanced View\]](#)

3.8.5.2 Advanced

Click **Advanced** in the **Wireless Port Configuration** page and the following page appears. In this page, you can view the following information of the wireless port.

Port Configuration[Basic](#) | **Advanced****Wireless Port Configuration**

This page allows you to view the values of port parameters.

Authentication	Open
Encryption	WEP128
Port Class802_11	true
Vap Id	0
BMACVersion	2.1.41.0
LMACVersion	2.17.36.0
UMACVersion	2.20.24.0
State	GotMac
Allowed Channels	1,2,3,4,5,6,7,8,9,10,11,12,13
Antenna Diversity	0
Authenticate STA	00:00:00:00:00:00
Auto Channel	true
Collect Stats	true
Connected	false
Current Country	INI
De Authenticate STA	00:00:00:00:00:00
Default Channel	1
Default Max Queue	32
Default Tx Key	0
Disable	true
ESSID	BSNL_AP
Fragmentation Threshold	2346
Hide SSID	false
IEEE802_11_Event Sink	/task/i802_1x
Intra BSSRelay	1
WMM	false
WMMPs	false
Link Speed	0
MAC	00:15:e9:00:00:02
Mac Address Auth	disabled
Mac Mode	AP
Max Associated Stations	32
Max Frame Burst	1500
Mode128Key0	12-34-56-78-90-12-34-56-78-90-12-34-56
Mode128Key1	00-00-00-00-00-00-00-00-00-00-00-00
Mode128Key2	00-00-00-00-00-00-00-00-00-00-00-00
Mode128Key3	00-00-00-00-00-00-00-00-00-00-00-00
Mode64Key0	00-00-00-00-00

**Note:**


Some of the attributes displayed in the **Wireless Port Configuration** page can be set from the CLI. Enter **port wireless set ?**. The attributes is displayed as the output of this command. Its function depends on the configuration of the DSLAM and the capability of the central office the modem connected to.

3.9 Admin

Click **Admin** to enter system admin page. On the left page, there are seven options: **Firmware Upgrade, Back & Restore, Reboot, Remote Access, Lan Access, Change Password, and Time Zone.**

3.9.1 Firmware Upgrade

Choose **Admin > Firmware Upgrade** and the following page appears. In this page, you can upgrade the software of the modem by TEImage.bin file.



Click **Browse** to select the upgrade file. The upgrade process may take several minutes.




Note:


If it is not upgraded successfully, do not restart the modem or switch off the modem. Try to upgrade the image file again until it is successful. If it is upgraded successfully, restart the modem immediately to take the new software effect.

3.9.2 Back & Restore

Choose **Admin > Back & Restore** and the following page appears.



Click **Backup** to save the current system configuration. Conexant.icf is the default file.






Note:

The restore configuration file should be with "icf" format.

3.9.3 Reboot

Choose **Admin > Reboot** and the following page appears. In this page, you can reboot the modem in two ways.



- **Last:** Reboot from the last revisal.
- **Factory:** Reboot from the factory default configuration.

3.9.4 Remote Access

Choose **Admin > Remote Access** and the following page appears. you can open the remote access port for someone to login. Remote access, a management station that is a host or range of hosts that can remotely access .Once the modem has been configured to allow to remote access, the management station sends IP traffic on a specific transport or port to the external port of the device. Any NAT or firewall configuration is bypassed. This allows a network administrator access to the configuration of the device without having to visit the site.

Remote Access

Enable remote access from management stations to let an expert, e.g. helpdesk, configure your Router remotely.

To allow remote access to your router via

Application	Start IP Address	End IP Address	Firewall Interface
<input type="checkbox"/> Web Browser	<input type="text"/>	<input type="text"/>	<input type="text"/>
Web Server Port On Wan Interface		<input type="text" value="80"/>	
<input type="checkbox"/> Telnet	<input type="text"/>	<input type="text"/>	<input type="text"/>
<input type="checkbox"/> FTP	<input type="text"/>	<input type="text"/>	<input type="text"/>
<input checked="" type="checkbox"/> PING	<input type="text" value="0. 0. 0. 0"/>	<input type="text" value="255. 255. 255. 255"/>	<input type="text"/>

After a remote access session, you should come back to this page and disable access.

3.9.5 Lan Access

Choose **Admin > Lan Access** and the following page appears. It is used to enable or restrict LAN side management access to the modem.

Lan Access

Enable or restrict Lan side management access to the DSL router.

Allow or restrict Lan side management access to your router via

Application	Start IP Address	End IP Address
<input checked="" type="checkbox"/> Web Browser	<input type="text"/>	<input type="text"/>
<input checked="" type="checkbox"/> Telnet	<input type="text"/>	<input type="text"/>
<input checked="" type="checkbox"/> FTP	<input type="text"/>	<input type="text"/>

Lan Access rules must be re-applied if the Lan side IP address of the router is changed.

3.9.6 Change Password

Choose **Admin > Change Password** and the following page appears. If logging in to the modem as a super user, you can modify the password of the modem. It is advisable that the password should be changed to keep the system secure. Keep the your password. If you forget the password, you need to reset the modem and reset to the factory defaults.

Administration Password

It is advisable that the password is changed to keep your system secure. Keep a copy of your password somewhere safe. If you forget your password, your Router will need to be reset and all settings will be lost.

User name:

Current password for admin:

New password:

Confirm new password:

Make a note of your new password somewhere safe for future reference

3.9.7 Time Zone

This page displays the current time configuration of the system.

3.9.7.1 SNTP Client

Click **SNTP Client** in the **SNTP Client Configuration** page. In this page, you can modify the SNTP client configuration. By default, the time zone is configured as UTC.

SNTP Client Configuration
[SNTP Server](#) | **SNTP Client**

SNTP Client Configuration

System Clock : YYYY : MM : DD : HH : MM : SS
 1970 01 03 00 14 28

TimeZone: UTC(Universal,Coordinated) ▼

DayLightSaving:

Mode: None ▼

Retries: 2 (0 - 10)

Timeout: 5 (0 - 30 Sec)

PollInterval: 1 (0 - 30 Min)

Apply

3.9.7.2 SNTP Server

Click **SNTP Server** in the **SNTP Client Configuration** page. In this page, you can modify the SNTP server settings.

SNTP Server Configuration
[SNTP Server](#) | [SNTP Client](#)

SNTP Server Settings
 Allows to add a new SNTP Server or delete the existing servers.

Hostname	IP Address	Delete

Host Name:

IP Address:

Add

You can add a server by using host name or IP address. It starts the synchronization process automatically if it exists a effective server in the association list.

Sample 1: Add a host Name of the SNTP server. (The hostname: time.nist.gov, which belongs to American time server).

SNTP Server Configuration
SNTP Server | [SNTP Client](#)

SNTP Server Settings
Allows to add a new SNTP Server or delete the existing servers.

Hostname	IP Address	Delete
time.nist.gov	N/A	

Host Name:
 IP Address:

Before adding a host name, you should ping the host name of the SNTP Server. It takes effective if the ping is successful.

Click to delete a single server association from the client list.

Sample 2: Add IP address of the SNTP server.

SNTP Server Configuration
SNTP Server | [SNTP Client](#)

SNTP Server Settings
Allows to add a new SNTP Server or delete the existing servers.

Hostname	IP Address	Delete
N/A	192.43.244.18	

Host Name:
 IP Address:


Before adding IP address, you should ping the IP address of the SNTP server. It takes effective if ping successes.

Click to delete a single server association from the client list.

4 Network Topology

Before configuring the modem, you must determine if the modem is used in the Bridging mode or Routing mode. This chapter describes some applications. For detailed configuration, refer to Chapter 3 Web Configuration Management.

4.1 PPP over ATM (PPPoA) Mode



Description

In this example, the modem is connected with the DSLAM through PVC 8/81 and the access mode is the built-in PPPoA + NAT. The encapsulation of the BRAS downlink port is PPP over ATM. The authentication is CHAP PAP. The IP address is 136.1.1.1. The IP pool is 136.1.1.* and the IP address of uplink port is 10.61.92.157. The IP address of the WAN port on the modem is assigned by BRAS through the built-in PPPoA dial-up dynamically. The PC that the modem is connected with is assigned with a private IP address (in the same segment as the management IP address of the modem). The NAT function of the modem is enabled and the private PC address is translated to the public address 136.1.1.* (2 ~ 254) assigned by BRAS dynamically for access to ISP.

The IP address of the PC can be fixed (as in this example) or assigned through DHCP server of the modem. If it is assigned by DHCP server, the DHCP function of the modem must be enabled. The IP address of the DHCP address pool is

192.168.1.* (2~254). The functions are enabled by default and the PC is configured to obtain IP and DNS addresses dynamically.


Setting

- (1) Open the network browser and enter **192.168.1.1** in the address bar to log in to the modem.
- (2) Choose **Configuration > Internet Connection > Connections**. Set VPI/VCI to 8/81, and click **Next**.
- (3) In the **Configure Connection Type** page, select **PPP over ATM (PPPoA)** protocol and set the encapsulation type to **VC MUX**. Click **Next**.
- (4) In the **Configure WAN IP Settings** page, select **Obtain an IP address automatically** and **Enable NAT**. Click **Next**.
- (5) In the **Configure Broadband User Name and Password** page, enter the **Broadband User Name** and **Password** provided by your ISP. Select a **Session established by** according to your practices. In this example, select **Always on**. Then click **Next**.
- (6) Check the network configuration and ensure that all the settings are consistent consistent with the data provided by your ISP. Then click **Apply**.

After the dial-up is successful, the IP address that the modem obtains at the WAN-side port R_0_32 is 136.1.1.3.

If NAT is disabled during the configuration, you must configure the modem on the BRAS. Otherwise, you cannot access your ISP. In actual applications, **Enable NAT** must be selected.

4.2 PPP over Ethernet (PPPoE) Mode



Description

In this example, the modem is connected to the DSLAM through PVC 8/81 and the access mode is the built-in PPPoE+NAT. The encapsulation of the BRAS downlink port is PPP over Ethernet. The authentication is CHAP PAP. The IP address is 136.1.1.1. The IP pool is 136.1.1.* and the IP address of uplink port is 10.61.92.157. The IP address of the WAN port on the modem is assigned by BRAS through the built-in PPPoE dial-up dynamically. The PC that the modem is to is assigned with a private IP address (in the same segment as the management IP of the modem). The NAT function of the modem is enabled and the private PC address is translated to the public address 136.1.1.* (2 ~ 254) assigned by BRAS dynamically for access to ISP.

The IP address of the PC can be fixed (as in this example) or assigned through DHCP server of the modem. If it is assigned by DHCP server, the DHCP function of the modem must be enabled. The IP address of the DHCP address pool is 192.168.1.* (2~254). The functions are enabled by default and the PC is configured to obtain IP and DNS addresses dynamically.


Setting

- (1) Open the network browser and enter **192.168.1.1** in the address bar to log in to the modem.
- (2) Choose **Configuration > Internet Connection > Connections**. Set VPI/VCI to 8/81, and click **Next**.
- (3) In the **Configure Connection Type** page, select **PPP over Ethernet(PPPoE)** protocol and set the encapsulation type to **LLC/SNAP**. Click **Next**.
- (4) In the **Configure WAN IP Settings** page, select **Obtain an IP address automatically** and **Enable NAT**. Click **Next**.
- (5) In the **Configure Broadband User Name and Password** page, enter the **Broadband User Name** and **Password** provided by your ISP. Select a **Session established by** according to your practices. In this example, select **Always on**. Then click **Next**.
- (6) Check the network configuration and ensure that all the settings are consistent with the data provided by your ISP. Then click **Apply**.

After the dial-up is successful, the IP address that the modem obtains at the WAN side port R_0_32 is 136.1.1.2.

If **Enable NAT** is disabled during the configuration, you must configure the modem on the BRAS. Otherwise, you can not access your ISP. In actual applications, **Enable NAT** must be selected.

4.3 RFC2684 (Bridged) + Fixedly-Assigned IP Address Mode



Description

In this example, the modem is connected to the DSLAM through PVC 8/81 and the access mode is the RFC2684 (bridged) +NAT. The down link port of DSLAM is encapsulated in 1483B. The IP address is 20.1.1.1. The IP address of the uplink port is 10.61.92.157. The WAN IP address of the modem is assigned as 20.1.1.112 and the gateway is 20.1.1.1. The PC to the modem is assigned with a private IP address (in the same segment as the management IP address 192.168.1.1). The NAT function of the modem is enabled and the private address of the PC is translated to the public address of 20.1.1.112 for accessing the ISP. The IP address of the PC can be fixed (as in this example) or assigned through DHCP server of the modem. If it is assigned by DHCP server, the DHCP function of the modem must be enabled. The IP address of the DHCP address pool is 192.168.1.* (2~254). The functions are enabled by default and the PC is configured to obtain IP and DNS addresses dynamically.

Setting

- (1) Open the network browser and enter **192.168.1.1** in the address bar to log in to the modem.
- (2) Choose **Configuration > Internet Connection > Connections**. Set VPI/VCI to 8/81, and click **Next**.
- (3) In the **Configure Connection Type** page, select **RFC 1483** protocol. Set the encapsulation type to **LLC/SNAP** and the encapsulation mode to **Bridged**. Click **Next**.
- (4) In the **Configure WAN IP Settings** page, enter WAN IP Address, WAN Subnet Mask, and Default Gateway provided by your ISP. Select **Enable NAT** and **Add Default Route**, and click **Next**.


- **WAN IP Address:** 20.1.1.112
 - **WAN Subnet Mask:** 255.255.255.0
 - **Default Gateway:** 20.1.1.1
- (5) Check the network configuration and ensure that all the settings are consistent with the data provided by your ISP. Then click **Apply**.

You can also modify the PVC 8/81 in “Internet Connection”. And the steps are the same as in “Connections”.

After the configuration is done, the modem WAN-side interface is B_0_32.

If **Enable NAT** is disabled during the configuration, you must configure the modem on the BRAS. Otherwise, you can not access your ISP. In actual applications, **Enable NAT** must be selected.

4.4 RFC2684 (Bridged) + DHCP Mode



Description

In this example, the modem is connected to the DSLAM through PVC 8/81 and the access mode is the MER+NAT. The downlink port of DSLAM is encapsulated in 1483B. The IP address is 139.1.1.1 and the DHCP server is enabled. The address pool is 139.1.1.* (2~254). The IP address of the uplink port is 10.61.92.157. The WAN IP address of the modem is automatically obtained through DHCP. The PC to the modem is assigned with a private IP address (in the same segment as the management IP address 192.168.1.1). The NAT function of the modem are enabled and the private address of the PC is translated to the public address 139.1.1.* (2~254) dynamically assigned by BRAS for accessing the ISP.

The IP address of the PC can be fixed (as in this example) or assigned through DHCP server of the modem. If it is assigned by the DHCP server, the DHCP function of the modem must be enabled. The IP address of the DHCP address pool

is 192.168.1.* (2~254). The functions are enabled by default and the PC is configured to obtain IP and DNS addresses dynamically.

Setting

- (1) Open the network browser and enter **192.168.1.1** in the address bar to log in to the modem.
- (2) Choose **Configuration > Internet Connection > Connections**. Set VPI/VCI to 8/81, and click **Next**.
- (3) In the **Configure Connection Type** page, select **RFC 1483** protocol. Set the encapsulation type to **LLC/SNAP** and the encapsulation mode to **Bridged**. Click **Next**.
- (4) In the **Configure WAN IP Settings** page, select **Obtain an IP address automatically** and **Enable NAT**. Click **Next**.
- (5) Check the network configuration and ensure that all the settings are consistent with the data provided by your ISP. Then click **Apply**.

After the configuration is successful, the IP address that the modem obtains at the WAN-side port B_0_35 is "136.1.1.2".


If **Enable NAT** is disabled during the configuration, you must configure the modem on the BRAS. Otherwise, you can not access your ISP. In actual applications, **Enable NAT** must be selected.



Note:

The DNS server address can be configured manually.

4.5 RFC2684 (Routed) + NAT Mode



Description

In this example, the modem is connected to the DSLAM through PVC 8/81 and the access mode is the IPOA+NAT. The downlink port of DSLAM is encapsulated in

1483R. The IP address is 20.1.1.1. The IP address of the uplink port is 10.61.92.157. The WAN IP address of the modem is assigned as 20.1.1.2. The PC to the modem is assigned with a private IP address (in the same segment as the management IP address 192.168.1.1). The NAT function of the modem is enabled and the private address of the PC is translated to the public address 139.1.1.* (2~254) dynamically assigned by BRAS for access to ISP.

The IP address of the PC can be fixed (as in this example) or assigned through DHCP server of the modem. If it is assigned by DHCP server, the DHCP functions of the modem must be enabled. The IP address of the DHCP address pool is 192.168.1.* (2~254). The functions are enabled by default and the PC is configured to obtain IP and DNS addresses dynamically.


Setting

- 1) Open the network browser and enter **192.168.1.1** in the address bar to log in to the modem.
- 2) Choose **Configuration > Internet Connection > Connections**. Set VPI/VCI to 8/81, and click **Next**.
- 3) In the **Configure Connection Type** page, select **RFC 1483** protocol. Set the encapsulation type to **LLC/SNAP** and the encapsulation mode to **Routed**. Click **Next**.
- 4) In the **Configure WAN IP Settings** page, enter WAN IP Address, WAN Subnet Mask, and Default Gateway provided by your ISP. Select **Enable NAT** and **Add Default Route**, and click **Next**.
 - **WAN IP Address:** 20.1.1.2
 - **WAN Subnet Mask:** 255.255.255.0
 - **Default Gateway:** 20.1.1.1
- 5) Check the network configuration and ensure that all the settings are consistent with the data provided by your ISP. Then click **Apply**.

In **Configure WAN IP Settings** page, besides entering WAN IP address, WAN subnet mask, DNS server addresses, and selecting enable NAT, you must select **Add Default Route**. Otherwise, you have to add the static modem manually. If you need to modify the LAN IP address and DHCP server information, you can operate in the **Local Network (LAN)** page and **DHCP Server** page.

After the configuration is done, WAN-side interface of the the modem is R_0_32.

4.6 External PPPoE Dial-up Mode



Description

In this example, the modem is connected to the DSLAM through PVC 8/81 and the access mode is pure Bridging. The encapsulation of the downlink port of BRAS is PPP over Ethernet. The authentication is CHAP PAP. The IP address is 136.1.1.1. The IP pool is 136.1.1.*. The IP address of the uplink port is 10.61.62.157. The PC to the modem obtains its public address dynamically assigned by BRAS through PPPoE dial-up.

Setting

- 1) Open the network browser and enter **192.168.1.1** in the address bar to log in to the modem.
- 2) Choose **Configuration > Internet Connection > Connections**. Set VPI/VCI to 8/81, and click **Next**.
- 3) In the **Configure Connection Type** page, select **Bridging** protocol. Set the encapsulation type to **LLC/SNAP**. Click **Next**.
- 4) Check the network configuration and ensure that all the settings are consistent with the data provided by your ISP. Then click **Apply**.



Note:

In the pure Bridging mode, there is no interface at the WAN side of the modem.

Help Desk

Contact: { **1800 - 424 - 1600** Post Paid
1800 - 424 - 1601 Prepaid
1500 Callcentre

Visit us at : www.bsnl.co.in