



# My Net™ Wi-Fi Range Extender

Dual-Band N Range Extender

**Expand your Wi-Fi™  
to out-of-reach areas  
of your home.**

Expand the coverage of your existing wireless network

Fast HD speeds with 3 X 3 antenna array

Stress-free setup with WPS (Wireless Protected Setup)



Expanding your Wi-Fi to out-of-reach areas of your home, even your backyard or garage, has never been easier. Setup is simple, just press two buttons and you're done. The 3x3 antenna array provides faster, stronger and more reliable network coverage in more places in your home. Customize your coverage by switching between the 2.4 or the 5 GHz bands with the flip of a switch. No software or PC required.





# My Net Wi-Fi Range Extender

## Dual-Band N Range Extender



### Product Features

#### More coverage

Get the coverage you need in areas of your home that have a weak or missing signal – even in the backyard or garage. Stream HD video seamlessly and game at winning speeds in even those hard-to-reach areas of your home.

#### More speed

Provides faster Wi-Fi speeds at further distances with a 3 X 3 antenna array on either the 2.4 or the 5 GHz bands. With more antennas you get faster, stronger and more reliable network coverage in more places in your home.\*

#### Signal strength indicator lights

The convenient Wi-Fi signal strength indicator lights on the front of the range extender make it easy to find the optimal location in your home. If only a few lights are on, your wireless signal is strong enough for Internet use. In the middle range, the signal is strong enough for backup and watching low resolution videos. If all the lights are lit you found your optimal location to enjoy anything from, downloading files, and streaming HD entertainment.

#### Selectable Dual-Bands

Easily choose between the 2.4 and 5 GHz bands with the flip of a switch. No software or PC required. The 2.4 GHz band gives you a wider range and the 5 GHz band increases your throughput and reduces interference for faster performance. Now you can stream videos, download music or chat with loved ones in areas of your home that once didn't have connection.

#### Easy setup

No CD or software is needed. With a hassle-free setup that is as easy as pushing two buttons (WPS- Wireless Protected Setup) you can extend the reach of your network in your home, in minutes.

#### Network ID and security

After adding the range extender, your current network name will not change. This makes it less confusing when you add new devices. The extended range in your network will also have the same virus and firewall protection so you will be streaming care-free throughout your home.

#### Push button setup (WPS\*)

Easily connect new devices to your wireless network with the push of a button using WPS (wireless protected setup).

### Product Specifications

#### INTERFACE

1 Gigabit Ethernet port

#### DIMENSIONS

Length: 6.0 in (153.48 mm)  
Depth: 2.0 in (51 mm)  
Width: 5.2 in (132 mm)  
Weight: 0.44 lb (198 g)

#### SYSTEM REQUIREMENTS

CD setup for PC: Windows® 7, Windows Vista®, Windows XP (SP3)

Web setup for Mac®: Safari® 2 or higher and type in //wdrouter or 192.168.1.1

Supported browsers: Internet Explorer® 7, Safari® 2, Firefox® 2, Google® Chrome™ 7 or higher

Web setup type in <http://wdrangeextender> or 192.168.1.230

#### MODEL NUMBER

WDBAPK0000NCH

#### KIT CONTENTS

Dual-Band N range extender  
AC Adapter  
Ethernet Cable  
Quick Install Guide

#### LIMITED WARRANTY

Pan Americas 1 year  
EMEA 2 years  
Asia Pacific 3 years



\* Maximum wireless performance rate derived from IEEE standard 802.11 specifications. Actual wireless repeater speeds can vary based on the router the range extender is connected to, the distance between range extender and the client, and other environmental factors.

\*\* Push-button setup works with devices that support Wi-Fi Protected Setup (WPS) like WD My Net routers and others.