

User's Guide



**TRENDNET**<sup>®</sup>



**N300 Wireless 12dBi Outdoor  
5GHz PoE Access Point**

**TEW-676APBO**

Contents

- Introduction ..... 5**
  - Features ..... 5
  - Package Contents ..... 5
  - Hardware Feature ..... 6
- System Concept..... 7**
  - Product Benefit ..... 8
  - Installation Considerations ..... 8
  - Installation ..... 9
  - Configuration ..... 9
- Applications ..... 10**
  - Router AP Mode (Gateway + Access Point + WDS) ..... 10
  - AP Mode (including Access Point + WDS) ..... 10
  - WDS Mode (Pure WDS) ..... 11
  - CPE Mode ..... 12
  - Client Bridge + Universal Repeater Mode ..... 12
  - CPE + AP Mode (Router Client + Access Point) ..... 12
- Web Management Interface Instructions ..... 13**
- AP Mode Configuration ..... 13**
  - External Network Connection ..... 14
  - Network Requirement ..... 14
    - Configure LAN IP ..... 14
  - Wireless LAN Network ..... 16
    - Wireless General Setup ..... 16
    - Wireless Advanced Setup ..... 16
    - Create Virtual AP (VAP) ..... 20
    - Virtual AP Setup ..... 21
    - Wireless MAC Filter Setup ..... 23
    - Wireless Network Expansion ..... 24
  - System Status ..... 24
    - System Overview ..... 24

- Associated Clients Status ..... 25
- Show WDS Link Status ..... 26
- Extra Information ..... 26
- Event Log ..... 28
- WDS Mode Configuration..... 29**
  - External Network Connection ..... 29
    - Network Requirement ..... 29
    - Configure LAN IP ..... 29
  - Wireless Network Expansion ..... 30
    - General Setup ..... 30
    - Wireless Advanced Setup ..... 31
    - WDS Setup ..... 34
  - System Status ..... 34
    - System Overview ..... 34
    - WDS List ..... 35
    - Extra Information ..... 36
    - Event Log ..... 37
- CPE Mode Configuration ..... 38**
  - External Network Connection ..... 38
    - Network Requirement ..... 38
    - Configure WAN Setup ..... 39
    - Configure DDNS Setup ..... 41
    - Configure LAN Setup ..... 41
  - Access Point Association ..... 42
    - Configure Wireless General Setting ..... 42
    - Configure Wireless Advanced Setting ..... 43
    - Site Survey ..... 43
    - Create Wireless Profile ..... 44
  - Access Control List ..... 45
    - IP Filter Setup ..... 45
    - MAC Filter Setup ..... 46
    - Parental Control Setup ..... 47

QoS Setup.....	48	Virtual Server (Port Forwarding).....	76
Resource Sharing.....	50	System Status.....	77
DMZ.....	50	Overview.....	77
Virtual Server (Port Forwarding).....	51	Associated Clients Status.....	79
System Status.....	53	Remote AP.....	80
Overview.....	53	Extra Info.....	80
Station Statistics.....	54	QoS Plot.....	82
Extra Info.....	55	Event Log.....	82
QoS Plot.....	57	<b>Client Bridge + Universal Repeater Configuration..... 82</b>	
Event Log.....	57	External Network Connection.....	83
<b>CPE + AP Mode Configuration..... 58</b>		Network Requirement.....	83
External Network Connection.....	58	Configure LAN IP.....	83
Network Requirement.....	58	Access Point Association.....	84
Configure WAN Setup.....	59	Configure Wireless General Setting.....	84
Configure DDNS Setup.....	60	Wireless Advanced Setup.....	85
Configure LAN Setup.....	61	Site Survey.....	89
Access Point Association.....	62	Create Wireless Profile.....	89
Configure Wireless General Setting.....	62	Wireless LAN Network Creation.....	90
Wireless Advanced Setup.....	63	Repeater AP Setup.....	90
Site Survey.....	66	Wireless MAC Filter Setup.....	93
Create Wireless Profile.....	66	System Status.....	93
Wireless LAN Network Creation.....	68	System Overview.....	93
Repeater AP Setup.....	68	Associated Clients Status.....	95
Wireless MAC Filter Setup.....	70	Remote AP.....	95
Access Control List.....	70	Extra Information.....	95
IP Filter Setup.....	70	Event Log.....	97
MAC Filter Setup.....	71	<b>Router AP Mode Configuration..... 98</b>	
Parental Control Setup.....	72	External Network Connection.....	98
QoS Setup.....	73	Network Requirement.....	98
Resource Sharing.....	75	Configure WAN Setup.....	99
DMZ.....	75	Configure DDNS Setup.....	101
		Configure LAN Setup.....	101

- Wireless LAN Network Creation ..... 102
  - Wireless General Setup ..... 102
  - Wireless Advanced Setup ..... 103
  - Create Virtual AP (VAP) ..... 107
  - Wireless MAC Filter Setup ..... 110
- Wireless Network Expansion ..... 111
- Access Control List ..... 112
  - IP Filter Setup ..... 112
  - MAC Filter Setup ..... 113
  - Parental Control Setup ..... 113
  - QoS Setup ..... 115
- Resource Sharing ..... 117
  - DMZ ..... 117
  - Virtual Server (Port Forwarding) ..... 117
- System Status ..... 118
  - Overview ..... 118
  - Associated Clients ..... 120
  - Show WDS Link ..... 121
  - Extra Info ..... 121
  - QoS Plot ..... 123
  - Event Log ..... 123
- System Management ..... 123**
  - Configure Management ..... 123
  - Configure System Time ..... 125
  - Configure UPnP ..... 126
  - Configure SNMP Setup ..... 126
  - Backup / Restore and Reset to Factory ..... 127
  - Firmware Upgrade ..... 128
  - Network Utility ..... 128
  - Reboot ..... 129
- Mounting bracket installation ..... 129**
  - Package contents ..... 129
  - Install mounting triangle ..... 129

- Wall mount bracket ..... 130
- Pole mount bracket ..... 130
- Installing brackets ..... 130
- Appendix ..... 131**
  - WEB GUI Valid Characters ..... 131
  - MCS Data Rate ..... 139
  - System Manager Privileges ..... 140
  - Windows TCP/IP Settings ..... 141
  - Enabling UPnP in Windows XP ..... 142
  - Specification ..... 144
  - Limited Warranty ..... 145

## Introduction

The N300 Wireless 12dBi Outdoor 5GHz PoE Access Point, model TEW-676APBO, provides high speed point-to-point building connectivity. It supports a variety of installation scenarios with Access Point, Router Access Point, Wireless Distribution System (WDS), Customer Premises Equipment (CPE), and Repeater modes.

An IP-66/67 weather rating and rugged aluminum housing ensures the highest level of protection against extreme weather. An outdoor mounting kit is included and weatherproof LED indicators expedite product installation and troubleshooting.

No need to install this access point near a power source—PoE technology transmits both power and data over an Ethernet cable. Support for the latest wireless security protocols ensures the highest level of network protection. Install this access point with TRENDnet's Outdoor Lightning Arrestor Kit, model TEW-ASAL1, to protect your entire network from catastrophic lightning strikes.

## Features

- PoE compliant device
- 1 x 10/100Mbps PoE Auto-MDIX LAN port
- 1 x reset button
- LED indicators: Power, WLAN, LAN, Internal high powered 12dBi patch antenna (polarization: V30°, H30°)
- Compliant with 802.11n/a technology (5 GHz spectrum) with data rates up to 300Mbps
- Rugged IP66/67 rated weather proof aluminum housing
- Supports Router Access Point (AP), Access Point (AP), Wireless Distribution System (WDS), Customer Premises Equipment (CPE), Client Bridge + Repeater, and CPE + AP modes
- Multiple SSID or Virtual Access Points with Layer 2 VLAN client isolation
- Access restriction with Internet Access Control, MAC, and IP filtering
- Universal Plug and Play (UPnP) for auto discovery and support for device configuration of Internet applications

- Complete wireless security with WPA/WPA2-RADIUS, WPA /WPA2-PSK, and WEP
- Multiple pass-through sessions for popular VPN applications (IPSec, L2TP, and PPTP)
- Quality of Service technology: IEEE 802.11p COS, IEEE 802.11q Tag VLAN priority control and Wi-Fi Multimedia (WMM)
- Supports IEEE 802.11f IAPP (Inter Access Point Protocol), IEEE 802.11h (Transmission Power Control) and IEEE 802.11d (Multi-country roaming)
- Easy setup via Web browser using the latest versions of Internet Explorer, FireFox, and Safari
- Supports SNMP (v2c and v3), Telnet, SSH, and HTTP/HTTPS management
- Surface mounting hardware
- Electrical ground cable
- 3-year limited warranty

## Package Contents

The standard package contents

- TEW-676APBO
- Multi-Language Quick Installation Guide
- CD-ROM (User's Guide)
- PoE Injector & Power cord (All in one type)
- Mounting Kit
- Grounding wire
- Waterproof kit

## Hardware Feature

### Front Panel



- **Housing** - IP 66/67 housing

### Bottom Panel



- **LED**
  - **LAN** – Turns on when there is a LAN connection and blinks when data is running through the LAN port.
  - **WLAN** – Turns on when wireless is enabled and blinks during wireless transmission occur.
  - **PWR** – Indicates the unit is powered on.
- **Reset Button (unscrew cap)**
  - **Reboot** – Press and hold the reset button for 2 seconds to restart the unit. All LEDs except PWR will turn off before the unit turns back on. All transmission occur.
  - **Reset** – Press and hold the reset button for more than 10 seconds to restore the unit back to factory default settings.
- **PoE Port (unscrew cap)** – Connect the network cable that is connected to the provided PoE injector to power and configure the unit.

## System Concept

The TEW-676APBO is not only designed and used as a traditional outdoor AP, but also with rich features tailored for WISP applications. The two-level management capability and access control ease WISP and owners to maintain and manage wireless network in a more controllable fashion. Main applications are listed as follows with illustration:

- Wireless CPE for Multi Dwelling Unit/Multi-Tenant Unit(MDU/MTU) complexes including apartments, dormitories, and office complexes.
- Outdoor Access Point for school campuses, enterprise campuses, or manufacture plants.
- Indoor Access Point for hotels, factories, or warehouses where industrial grade devices are preferred.
- Public hotspot operation for café, parks, convention centers, shopping malls, or airports.
- Wireless coverage for indoor and outdoor grounds in private resorts, home yards, or gulf course communities.



## **Product Benefit**

The N300 Wireless 12dBi Outdoor 5GHz PoE Access Point is the point of connection to Wireless Outdoor Network for service provider deploying last mile services to business or residential broadband subscribers.. Network administrators can create multiple subscriber service tier using per-subscriber rate limiting features, and manage centrally. TEW-676APBO outdoor bridge utilizes a 200mW output Tx Power to connect to the WiFi mesh or WDS infrastructure and provides the subscriber with an Ethernet connection for a local access.

The N300 Wireless 12dBi Outdoor 5GHz PoE Access Point can be used for nine different purposes in six different modes, the Router AP mode , AP mode, the WDS mode, the CPE mode, Client Bridge + Universal Repeater mode and CPE + AP mode,

## **Installation Considerations**

There are a number of factors that can impact the range of wireless devices.


1. Adjust your wireless devices so that the signal is traveling in a straight path, rather than at an angle. The more material the signal has to pass through the more signal you will lose.
2. Keep the number of obstructions to a minimum. Each obstruction can reduce the range of a wireless device. Position the wireless devices in a manner that will minimize the amount of obstructions between them.
3. Building materials can have a large impact on your wireless signal. In an indoor environment, try to position the wireless devices so that the signal passes through less dense material such as dry wall. Dense materials like metal, solid wood, glass or even furniture may block or degrade the signal.
4. Antenna orientation can also have a large impact on your wireless signal. Use the wireless adapter's site survey tool to determine the best antenna orientation for your wireless devices.
5. Interference from devices that produce RF (radio frequency) noise can also impact your signal. Position your wireless devices away from anything that generates RF noise, such as microwaves, radios and baby monitors.

If you are still experiencing low or no signal consider repositioning the wireless devices or installing additional access points. The use of higher gain antennas may also provide the necessary coverage depending on the environment.




## Installation


1. Unscrew the black cap covering the PoE port of the TEW-676APBO
2. Install the waterproof kit and insert one end of an Ethernet cable through the kit.




3. Connect the Ethernet cable to the **PoE** port of the TEW-676APBO



4. Tighten and secure the seal nut of the waterproof kit.
5. Connect the other end of the Ethernet cable to the **P+DATA Out** port on the PoE injector.




6. Using another Ethernet cable, connect one end to the **DATA IN** port of the injector.



7. Connect the other end of the Ethernet cable to the LAN port of your network.
8. Plug the power cord into the injector. Then connect the plug into a power outlet.

## Configuration


1. Open a web browser, type the IP address of the Access Point and then press **Enter**. The default IP address is **192.168.10.100**.



2. Enter the **Username** and **Password** and click **OK**. By default the Username: **root** and Password: **root**.
3. Click the **Wizard** button and follow the setup wizard instructions. Click **Finish** to complete installation.

## Applications



TEW-676APBO is multiple mode system which can be configured either as a wireless gateway or an access point as desired. It also can be used as a WDS link for Ethernet network expansion. This section depicts different applications on **Router AP Mode**, **AP Mode**, **WDS Mode**, **CPE Mode**, **Client Bridge + Universal Repeater Mode** and **CPE + AP Mode**.



### Router AP Mode (Gateway + Access Point + WDS)

#### Example 1 : Router AP without WDS

- ✓ It can be deployed as a gateway with wireless Access Point



#### → Example 2 : Router AP with WDS


- ✓ It can be deployed as a gateway with wireless Access Point and provides WDS link for network extension.

### AP Mode (including Access Point + WDS)

An access point can be either a main, relay or remote base station. A main base station is typically connected to a wired network via the Ethernet port. A relay base station relays data between main base stations and relay stations or remote base stations with clients. A remote base station is the end point to accept connections from wireless clients and pass data upwards to a network wirelessly.


#### → Example 1 : Access Point without WDS

- ✓ It can be deployed as a tradition fixed wireless Access Point



→ **Example 2 : Access Point with WDS**


- ✓ It can be deployed as a tradition fixed wireless Access Point and provides WDS link to expand network




**WDS Mode (Pure WDS)**

An access point can be either a main, relay or remote base station. A main base station is typically connected to a wired network via the Ethernet port. A relay base station relays data between main base stations and relay stations or remote base stations with clients. A remote base station is the end point to accept connections from wireless clients and pass data upwards to a network wirelessly. In this mode, it can support single or multiple WDS links and no wireless clients **can** associate with it.


**Example 1 : Point-to-Point**



**Example 2 : Point-to-Multi-Point**




→ Example 3 : Multi-Point Repeating bridge




**CPE Mode**

It can be used as an Outdoor Customer Premises Equipment (CPE) to receive wireless signal over last mile application, helping WISPs deliver wireless broadband Internet service to residents and business customers. In the CPE mode, TEW-676APBO is a gateway enabled with NAT and DHCP Server functions. The wired clients connected to TEW-676APBO are in different subnet from those connected to Main Base Station, and, in CPE mode, it does not accept wireless association from wireless clients.




**Client Bridge + Universal Repeater Mode**

It can be used as an Client Bridge + Universal Repeater to receive wireless signal over last mile applications, helping WISPs deliver wireless broadband Internet service to new residential and business customers. In this mode, TEW-676APBO is enabled with DHCP Server functions. The wired clients of TEW-676APBO are in **the same subnet** from Main Base Station and it **accepts** wireless connections from client devices.



**CPE + AP Mode (Router Client + Access Point)**

It can be used as an Outdoor Customer Premises Equipment(CPE) to receive wireless signal over the last mile, helping WISPs deliver wireless broadband Internet service to new residential and business customers. In this mode, the TEW-676APBO is a gateway with NAT and DHCP Server functions. The wireless and wired clients of TEW-676APBO are on the **different subnet** from Main Base Station and it **accepts** wireless connections from client devices.



## Web Management Interface Instructions

TEW-676APBO supports web-based configuration. Upon the completion of hardware installation, TEW-676APBO can be configured through a PC/NB by using its web browser such as Internet Explorer version 6.0.

- **Default IP Address :** 192.168.10.100
- **Default IP Netmask :** 255.255.255.0
- **Default User Name and Password :** root/root

The default user name and password for both root manager account and admin manager account are as follows:

Mode	Router AP	CPE		AP	WDS	UR + CB	CPE + AP	
<b>Management Account</b>	Root	Root	Admin	Root	Root	Root	Root	Admin
<b>User Name</b>	root	root	admin	root	root	root	Root	admin
<b>Password</b>	default	default	admin	default	default	default	default	admin

### Step

#### ■ IP Segment Set-up for Administrator's PC/NB

Set the IP segment of the administrator's computer to be in the same range as TEW-676APBO for accessing the system. Do not duplicate the IP Address used here with IP Address of TEW-676APBO or any other device within the network

#### **Example of Segment :**

The valid range is 1 ~ 254 and 192.168.10.254 shall be avoided because it is already assigned to TEW-676APBO . 192.168.10.10 is used in the example below.

- IP Address : 192.168.10.10
- IP Netmask : 255.255.255.0

#### ■ Launch Web Browser

Launch web browser to access the web management interface of system by

entering the default IP Address, <http://192.168.10.254>, in the URL field, and then press **Enter**.

#### ■ System Login

The system manager Login Page then appears.

Enter "**root**" as **User name** and "**root**" as **Password**, and then click OK to login to the system; the root manager account is used as an example here.

#### ■ Login Success

System Overview page will appear after successful login.

## AP Mode Configuration

When AP mode is chosen, the system can be configured as an Access Point. This section provides detailed explanation for users to configure in the AP mode with help of illustrations. In the AP mode, functions listed in the table below are also available from the Web-based GUI interface.


Option	System	Wireless	Utilities	Status
Functions	Operating Mode	General Setup	Profiles Settings	System Overview
	LAN	Advanced Setup	Firmware Upgrade	Clients
	Management	Virtual AP	Network Utility	WDS Status
	Time Server	WDS Setup	Reboot	Extra Info
	SNMP			Event Log

**AP Mode Functions**

## External Network Connection

### Network Requirement

Normally, TEW-676APBO connects to a wired LAN and provides a wireless connection point to associate with wireless client as shown in Figure 3-1. Then, Wireless clients could access to LAN or Internet by associating themselves with TEW-676APBO set in AP mode.



## Configure LAN IP

Here are the instructions to setup the local IP Address and Netmask. Please click on **System** -> **LAN** and follow the below setting.

Ethernet Connection Type	
Mode :	<input checked="" type="radio"/> Static IP <input type="radio"/> Dynamic IP
Static IP	
IP Address :	192.168.10.101
IP Netmask :	255.255.255.0
IP Gateway :	192.168.10.1

- **Mode** : Check either “Static IP” or “Dynamic IP” button as desired to set up the system IP of LAN port .
  - ➔ **Static IP** : The administrator can manually setup the LAN IP address when static IP is available/ preferred.
    - ✓ **IP Address** : The IP address of the LAN port; default IP address is 192.168.2.254
    - ✓ **IP Netmask** : The Subnet mask of the LAN port; default Netmask is 255.255.255.0

- ✓ **IP Gateway** : The default gateway of the LAN port; default Gateway is 192.168.2.1

- ➔ **Dynamic IP** : This configuration type is applicable when the TEW-676APBO is connected to a network with the presence of a DHCP server; all related IP information will be provided by the DHCP server automatically.

Dynamic IP	
Hostname :	<input type="text"/>

- ✓ **Hostname** : The Hostname of the LAN port



- **DNS** : Check either “No Default DNS Server” or “Specify DNS Server IP” button as desired to set up the system DNS.
  - ➔ **Primary** : The IP address of the primary DNS server.
  - ➔ **Secondary** : The IP address of the secondary DNS server.

### 802.1d Spanning Tree

STP :  Enable  Disable

- **802.1d Spanning Tree**  
The spanning tree network protocol provides a loop free topology for a bridged LAN between LAN interface and 4 WDS interfaces from wds0 to wds3. The Spanning Tree Protocol, which is also referred to as STP, is defined in the IEEE Standard 802.1d. The Spanning tree always enabled on TEW-676APBO. Below Figures depict a loop for a bridged LAN between LAN and WDS link

Click **Save** button to save your changes. Click **Reboot** button to activate your changes





## Wireless LAN Network

The network manager can configure related wireless settings, **General Settings**, **Advanced Settings**, **Virtual AP(VAP) Setting**, **Security Settings** and **MAC Filter Settings**.

### Wireless General Setup

The administrator can change the data transmission, channel and output power settings for the system. Please click on **Wireless -> General Setup** and follow the below setting.

- **MAC Address** : The MAC address of the Wireless interface is displayed here.
- **Band Mode** : Select an appropriate wireless band; bands available are **801.11a** or **802.11a/n mixed mode**.
- **AP Isolation** : Select **Enable**, all clients will be isolated from each VAP, that means different VAP's clients can not reach to each other.
- **Transmit Rate Control** : Select the desired rate from the drop-down list; the options are auto or ranging from **6** to **54Mbps** only for **802.11a** mode.
- **Tx Power** : You can adjust the output power of the system to get the appropriate coverage for your wireless network. Specify digit numbers between **1** to **100** (the

unit is %) for your environment. If you are not sure which setting to choose, then keep the default setting, **100%**.

When **Band Mode** select in **802.11a only mode**, the **HT(High Throughput)** settings should be hidden immediately.

- **HT TxStream/RxStream** : By default, it's **2**.
- **Operating Mode** : By default, it's **Mixed Mode**.
  - ➔ **Mixed Mode** : In this mode packets are transmitted with a preamble compatible with the legacy 802.11a/g, the rest of the packet has a new format. In this mode the receiver shall be able to decode both the Mixed Mode packets and legacy packets.
  - ➔ **Green Field** : In this mode high throughput packets are transmitted without a legacy compatible part.
- **Channel Bandwidth** : The **"20/40"** MHz option is usually best. The other option is available for special circumstances.
- **Guard Interval** : Using **"Auto"** option can increase throughput. However, it can also increase error rate in some installations, due to increased sensitivity to radio-frequency reflections. Select the option that works best for your installation.
- **MCS** : This parameter represents transmission rate. By default (Auto) the fastest possible transmission rate will be selected. You have the option of selecting the speed if necessary. (Refer to **Appendix C. MCS Data Rate**)
- **Reverse Direction Grant(RDG)** : Disable or enable reserve direction grant. Default is enabled.
- **A-MSDU** : Aggregated Mac Service Data Unit. Select **Enable** to allow aggregation for multiple MSDUs in one MPDU Default is disabled.
- **Auto Block ACK** : Disable or enable auto block ACK. Default is enabled.
- **Decline BA Request** : Disable or enable decline BA request. Default is disabled.


Change these settings as described here and click **Save** button to save your changes. Click **Reboot** button to activate your changes. The items in this page are for AP's RF general settings and will be applied to **all VAPs** and **WDS Links**.

### Wireless Advanced Setup

To achieve optimal wireless performance, it is necessary to tweak advance setting per requirements properly, not necessary higher the better or lower.

The administrator can change the RTS threshold and fragmentation threshold settings for the system. Please click on **Wireless -> Advanced Setup** and follow the below setting.





- **Short Slot** : By default, it's "Enable" for reducing the slot time from the standard 20 microseconds to the 9 microsecond short slot time

Slot time is the amount of time a device waits after a collision before retransmitting a packet. Reducing the slot time decreases the overall back-off, which increases throughput. Back-off, which is a multiple of the slot time, is the random length of time a station waits before sending a packet on the LAN. For a sender and receiver own right of the channel the shorter slot time help manage shorter wait time to re-transmit from collision because of hidden wireless clients or other causes. When collision sources can be removed sooner and other senders attempting to send are listening the channel(CSMA/CA) the owner of the channel should continue ownership and finish their transmission and release the channel. Then, following ownership of the channel will be sooner for the new pair due to shorter slot time. However, when long duration of existing collision sources and shorter slot time exist the owners might experience subsequent collisions. When adjustment to longer slot time can't improve performance then RTS/CTS could supplement and help improve performance.

- **Extra Slot Time** : Slot time is in the range of 1~255 and set in unit of *microsecond*. The default value is 9 microsecond.
- **ACK Timeout** : ACK timeout is in the range of 1~255 and set in unit of *microsecond*. The default value is 32 microsecond.

All data transmission in 802.11b/g request an "Acknowledgement" (ACK) send by

receiving radio. The transmitter will resend the original packet if correspondent ACK failed to arrive within specific time interval, also refer to as "ACK Timeout". ACK Timeout is adjustable due to the fact that distance between two radio links may vary in different deployment. ACK Timeout makes significant influence in performance of long distance radio link. If ACK Timeout is set too short, transmitter will start to "Resend" packet before ACK is received, and throughputs become low due to excessively high re-transmission.

ACK Timeout is best determined by distance between the radios, data rate of average environment. The Timeout value is calculated based on round-trip time of packet with a little tolerance, So, if experiencing re-transmissions or poor performance the ACK Timeout could be made longer to accommodate.

- **Beacon Interval** : Beacon Interval is in the range of 20~1024 and set in unit of *millisecond*. The default value is 100 msec.

Access Point (AP) in IEEE 802.11 will send out a special approximated 50-byte frame, called "Beacon". Beacon is broadcast to all the stations, provides the basic information of AP such as SSID, channel, encryption keys, signal strength, time stamp, support data rate.

All the radio stations received beacon recognizes the existence of such AP, and may proceed next actions if the information from AP matches the requirement. Beacon is sent on a periodic basis, the time interval can be adjusted.

By increasing the beacon interval, you can reduce the number of beacons and associated overhead, but that will likely delay the association and roaming process because stations scanning for available access points may miss the beacons. You can decrease the beacon interval, which increases the rate of beacons. This will make the association and roaming process very responsive; however, the network will incur additional overhead and throughput will go down.

- **DTIM Interval** : The DTIM interval is in the range of 1~255. The default is 1.

DTIM is defined as *Delivery Traffic Indication Message*. It is used to notify the wireless stations, which support power saving mode, when to wake up to receive multicast frame. DTIM is necessary and critical in wireless environment as a mechanism to fulfill power-saving synchronization.

A DTIM interval is a count of the number of beacon frames that must occur before the access point sends the buffered multicast frames. For instance, if DTIM Interval is set to 3, then the Wi-Fi clients will expect to receive a multicast frame after receiving three Beacon frame. The higher DTIM interval will help power saving and possibly decrease wireless throughput in multicast applications.

- Fragment Threshold** : The Fragment Threshold is in the range of 256~2346 byte. The default is 2346 byte.

Each Wi-Fi packet can be divided into smaller packets, marked with a sequential fragment number and re-assemble in the receiving ends. The purpose is to make a short frame, instead of long frame, transmitting by radio in a heavy noisy environment. Because of sending smaller frames, corruptions are much less likely to occur. The pros is obvious, the cons is the overhead for transmission. So, in a clean environment, higher fragment threshold can be an option to increase throughput.

Fragmentation will be triggered by setting the Fragment Threshold, usually in Byte-length. Only when the frame size is over the Threshold, fragmentation will take place automatically.
- RTS Threshold** : TRTS Threshold is in the range of 1~2347 byte. The default is 2347 byte.

The main purpose of enabling RTS by changing RTS threshold is to reduce possible collisions due to hidden wireless clients. RTS in AP will be enabled automatically if the packet size is larger than the Threshold value. By default, RTS is disabled in a normal environment supports non-jumbo frames.
- Short Preamble** : By default, it's "Enable". To **Disable** is to use Long 128-bit Preamble Synchronization field.

The preamble is used to signal "here is a train of data coming" to the receiver. The short preamble provides 72-bit Synchronization field to improve WLAN transmission efficiency with less overhead.
- Tx Burst** : By default, it's "Enable". To **Disable** is to deactivate Tx Burst.

With TX burst enabled, AP will send many packets in a burst, without collision detection and RTS/CTS for each packet. TX Burst have better throughput but cause interference with other APs in channel.
- Pkt\_Aggregate** : By default, it's "Enable"

Increase efficiency by aggregating multiple packets of application data into a single transmission frame. In this way, 802.11n networks can send multiple data packets with the fixed overhead cost of just a single frame.
- WMM** : By default, it's "Disable". To **Enable** is to use WMM and the WMM parameters should appears.

WMM Parameters of Access Point						
	Aifsn	CWMin	CWMax	Txop	ACM	AckPolicy
AC_BE	3	15	63	0	<input type="checkbox"/>	<input type="checkbox"/>
AC_BK	7	15	1023	0	<input type="checkbox"/>	<input type="checkbox"/>
AC_VI	1	7	15	94	<input type="checkbox"/>	<input type="checkbox"/>
AC_VO	1	3	7	47	<input type="checkbox"/>	<input type="checkbox"/>

WMM Parameters of Station					
	Aifsn	CWMin	CWMax	Txop	ACM
AC_BE	3	15	1023	0	<input type="checkbox"/>
AC_BK	7	15	1023	0	<input type="checkbox"/>
AC_VI	2	7	15	94	<input type="checkbox"/>
AC_VO	2	3	7	47	<input type="checkbox"/>

→ **WMM Parameters of Access Point** : This affects traffic flowing from the access point to the client station

Queue	Data Transmitted AP to Clients	Priority	Description
AC_BK	Background.	Low	High throughput. Bulk data that requires maximum throughput and is not time-sensitive is sent to this queue (FTP data, for example).
AC_BE	Best Effort	Medium	Medium throughput and delay. Most traditional IP data is sent to this queue
AC_VI	Video	High	Minimum delay. Time-sensitive video data is automatically sent to this queue
AC_VO	Voice	High	Time-sensitive data like VoIP and streaming media are automatically sent to this queue

Configuring QoS options consists of setting parameters on existing queues for different types of wireless traffic. You can configure different minimum and maximum wait times for the transmission of packets in each queue based on the requirements of the media being sent. Queues automatically provide minimum transmission delay for Voice, Video, multimedia, and mission critical

applications, and rely on best-effort parameters for traditional IP data. As an Example, time-sensitive Voice & Video, and multimedia are given effectively higher priority for transmission (lower wait times for channel access), while other applications and traditional IP data which are less time-sensitive but often more data-intensive are expected to tolerate longer wait times.

- ✓ **Aifsn** : The Arbitration Inter-Frame Spacing Number specifies a wait time (in milliseconds) for data frames
- ✓ **CWmin** : Minimum Contention Window. This parameter is input to the algorithm that determines the initial random back-off wait time ("window") for retry of a transmission. The value specified here in the Minimum Contention Window is the upper limit (in milliseconds) of a range from which the initial random back-off wait time is determined.
- ✓ **CWmax** : Maximum Contention Window. The value specified here in the Maximum Contention Window is the upper limit (in milliseconds) for the doubling of the random back-off value. This doubling continues until either the data frame is sent or the Maximum Contention Window size is reached. Once the Maximum Contention Window size is reached, retries will continue until a maximum number of retries allowed is reached. Valid values for the "cwmax" are 1, 3, 7, 15, 31, 63, 127, 255, 511, or 1024. The value for "cwmax" must be higher than the value for "cwmin".
- ✓ **Txop** : Transmission Opportunity is an interval of time when a WME AP has the right to initiate transmissions onto the wireless medium (WM). This value specifies (in milliseconds) the Transmission Opportunity (TXOP) for AP; that is, the interval of time when the WMM AP has the right to initiate transmissions on the wireless network.
- ✓ **ACM** : Admission Control Mandatory, ACM only takes effect on AC\_VI and AC\_VO. When you do not click Checkbox, it means that the ACM is controlled by the connecting AP. If you click Checkbox, it means that the Client is in charge.
- ✓ **AckPolicy** : Acknowledgment Policy, WMM defines two ACK policies: **Normal ACK** and **No ACK**. Click "**Checkbox**" indicates "**No ACK**" When the no acknowledgment (No ACK) policy is used, the recipient does not acknowledge received packets during wireless packet exchange. This policy is suitable in the environment where communication quality is fine and interference is weak. While the No ACK policy helps improve transmission efficiency, it can cause increased packet loss when communication quality deteriorates. This is because when this policy is

used, a sender does not retransmit packets that have not been received by the recipient.

When the Normal ACK policy is used, the recipient acknowledges each received unicast packet.

➔ **WMM Parameters of Station** : *This affects traffic flowing from the client station to the access point.*


- ✓ **Aifsn** : The Arbitration Inter-Frame Spacing Number specifies a wait time (in milliseconds) for data frames
- ✓ **CWmin** : Minimum Contention Window. This parameter is input to the algorithm that determines the initial random backoff wait time ("window") for retry of a transmission. The value specified here in the Minimum Contention Window is the upper limit (in milliseconds) of a range from which the initial random backoff wait time is determined.
- ✓ **CWmax** : Maximum Contention Window. The value specified here in the Maximum Contention Window is the upper limit (in milliseconds) for the doubling of the random backoff value. This doubling continues until either the data frame is sent or the Maximum Contention Window size is reached. Once the Maximum Contention Window size is reached, retries will continue until a maximum number of retries allowed is reached. Valid values for the "cwmax" are 1, 3, 7, 15, 31, 63, 127, 255, 511, or 1024. The value for "cwmax" must be higher than the value for "cwmin".
- ✓ **Txop** : Transmission Opportunity is an interval of time when a WME AP has the right to initiate transmissions onto the wireless medium (WM). This value specifies (in milliseconds) the Transmission Opportunity (Txop) for AP; that is, the interval of time when the WMM AP has the right to initiate transmissions on the wireless network.
- ✓ **ACM** : Admission Control Mandatory, ACM only takes effect on AC\_VI and AC\_VO. When you do not click Checkbox, it means that the ACM is controlled by the connecting AP. If you click Checkbox, it means that the Client is in charge.

Queue	Data Transmitted Clients to AP	Priority	Description
AC_BK	Background.	Low	High throughput. Bulk data that requires maximum throughput and is not time-sensitive is sent to this queue (FTP data, for example).
AC_BE	Best Effort	Medium	Medium throughput and delay. Most traditional IP data is sent to this queue
AC_VI	Video	High	Minimum delay. Time-sensitive video data is automatically sent to this queue
AC_VO	Voice	High	Time-sensitive data like VoIP and streaming media are automatically sent to this queue

Click **Save** button to save your changes. Click **Reboot** button to activate your changes. The items in this page are for AP's RF advanced settings and will be applied to **all VAPs** and **WDS Links**.

### Create Virtual AP (VAP)

The TEW-676APBO support broadcasting multiple SSIDs, allowing the creation of Virtual Access Points, partitioning a single physical access point into 7 logical access points, each of which can have a different set of security, VLAN Tag(ID) and network settings. **Figure 3-2** shows multiple SSIDs with different security type and VLAN settings.



Multiple SSIDs with different Security Type and VLAN Tag

### Virtual AP Overview

The administrator can view all of the Virtual AP's settings via this page. Please click on **Wireless -> Virtual AP Setup** and the Virtual AP Overview Page appears.


VAP	ESSID	MAC Address	Status	Security Type	MAC Filter	Edit
Primary AP	TRENDnet676	00:11:A3:07:03:48	On	Disable	Disable	Edit
VAP1		00:00:00:00:00:00	Off	Disable	Disable	Edit
VAP2		00:00:00:00:00:00	Off	Disable	Disable	Edit
VAP3		00:00:00:00:00:00	Off	Disable	Disable	Edit
VAP4		00:00:00:00:00:00	Off	Disable	Disable	Edit
VAP5		00:00:00:00:00:00	Off	Disable	Disable	Edit
VAP6		00:00:00:00:00:00	Off	Disable	Disable	Edit

- **VAP** : Indicate the system's Virtual AP.
- **ESSID** : Indicate the ESSID of the respective Virtual AP
- **MAC Address** : The MAC address of the VAP Interface is displayed here. When you enable AP and reboot system, the MAC address will display here.
- **Status** : Indicate the Status of the respective Virtual AP. The **Primary AP** always on.
- **Security Type** : Indicate an used security type of the respective Virtual AP.
- **MAC Filter** : Indicate an used MAC filter of the respective Virtual AP.
- **Edit** : Click **Edit** button to configure Virtual AP's settings, including security type and MAC Filter.

### Virtual AP Setup

For each Virtual AP, administrators can configure SSID, VLAN tag(ID), SSID broadcasting, Maximum number of client associations, security type settings. Click **Edit** button on the Edit column, and then a Virtual AP setup page appears.

- **Enable AP** : By default, it's "**Disable**" for VAP1 ~ VAP6. **The Primary AP always enabled.**  
Select "**Enable**" to activate VAP or click "**Disable**" to deactivate this function
- **ESSID** : Extended Service Set ID, When clients are browsing for available wireless networks, this is the SSID that will appear in the list. ESSID will determine the service type available to AP's clients associated with the specified VAP.
- **Client Isolation** : Select **Enable**, all clients will be isolated from each other, that means all clients cannot reach to other clients. Below Figures depict Client Isolation and AP Isolation



- **Hidden SSID** : By default, it's "**Disable**".  
Enable this option to stop the SSID broadcast in your network. When disabled, people could easily obtain the SSID information with the site survey software and get access to the network if security is not turned on. When enabled, network security is enhanced. It's suggested to enable it after AP security settings are archived and setting of AP clients could make to associate to it.
- **Maximum Clients** : The default value is **32**. You can enter the number of wireless clients that can associate to a particular SSID. When the number of client is set to 5, only 5 clients at most are allowed to connect to this VAP.
- **VLAN Tag(ID)** : By default, it's selected "**Disable**".  
This system supports tagged Virtual LAN(VLAN). A valid number of **1** to **4094** can be entered after it's enabled. If your network utilize VLANs you could tie a VLAN Tag to a specific SSID, and packets from/to wireless clients belonging to that SSID will be tagged with that VLAN Tag. This enables security of wireless applications by applying VLAN Tag.



- **Security Type** : Select the desired security type from the drop-down list; the options are **Disable**, **WEP**, **WPA-PSK**, **WPA2-PSK**, **WPA-Enterprise**, **WPA2-Enterprise** and **WEP 802.1X**.

- ➔ **Disable** : Data are unencrypted during transmission when this option is selected.
- ➔ **WEP** : Wired Equivalent Privacy(WEP) is a data encryption mechanism based on a 64-bit or 128-bit shared key.

- **Authentication Method** : Enable the desire option among **OPEN**, **SHARED** or **WEPAUTO**.

- ➔ **Key Index** : Key index is used to designate the WEP key during data transmission. 4 different WEP keys can be entered at the same time, but only one is chosen.
- ➔ **WEP Key #** : Enter **HEX** or **ASCII** format WEP key value; the system supports up to 4 sets of WEP keys.

Key Length	Hex	ASCII
64-bit	10 characters	5 characters
128-bit	26 characters	13 characters

- ➔ **WPA-PSK (or WPA2-PSK)** : WPA (or WPA2) Algorithms, allows the system accessing the network by using the WPA-PSK protected access.

- ✓ **Cipher Suite** : By default, it is **AES**. Select either AES or TKIP cipher suites
- ✓ **Pre-shared Key** : Enter the pre-shared key; the format shall go with the selected key type.
- ✓ **Group Key Update Period** : By default, it is **3600** seconds. This time interval for rekeying GTK, broadcast/multicast encryption keys, in seconds. Entering the time-length is required.

- ➔ **WPA-Enterprise (or WPA2-Enterprise)**: The RADIUS authentication and encryption will be both enabled if this is selected.

- ✓ **WPA General Settings** :
  - **Cipher Suite** : By default, it is AES. Select either AES or TKIP cipher suites
  - **Group Key Update Period** : By default, it's **3600** seconds. This time interval for rekeying GTK, broadcast/multicast encryption keys, in seconds. Entering the time-length is required.
  - **PMK Cache Period** : By default, it's 10 minutes. Set **WPA2** PMKID cache timeout period, after time out, the cached key will be deleted.
  - **Pre-Authentication** : By default, it's "Disable". To Enable is use to speed up roaming before pre-authenticating IEEE 802.1X/EAP part of the full RSN authentication and key handshake before actually associating with a new AP.
- ✓ **Radius Server Settings** :
  - **IP Address** : Enter the IP address of the Authentication RADIUS server.
  - **Port** : By default, it's **1812**. The port number used to communicate with RADIUS server.
  - **Shared secret** : A secret key used between system and RADIUS server. Supports **8** to **64** characters.

- **Session Timeout** : The Session timeout is in the range of **0~60 seconds**. The default is **0** to disable re-authenticate service.
- Amount of time before a client will be required to re-authenticate.
- ➔ **WEP 802.1X** : When WEP 802.1x Authentication is enabled, please refer to the following Dynamic WEP and RADIUS settings to complete configuration.

**802.1x WEP**

Dynamic WEP : Enable

**Authentication RADIUS Server**

Authentication Server :   
 Port : 1812  
 Shared Secret :   
 Session Timeout : 0

- ✓ **Radius Server Settings** :
- **IP Address** : Enter the IP address of the Authentication RADIUS server.
- **Port** : By default, it's **1812**. The port number used to communicate with RADIUS server.
- **Shared secret** : A secret key used between system and RADIUS server. Supports **8 to 64** characters.
- **Session Timeout** : The Session timeout is in the range of **0~60 seconds**. The default is **0** to disable re-authenticate service.
- Amount of time before a client will be required to re-authenticate.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes

## Wireless MAC Filter Setup

Continue **Virtual AP Setup** section. For each Virtual AP setting, the administrator can allow or reject clients to access each Virtual AP.

- **MAC Filter Setup** : By default, it's **“Disable”**. Options are **Disable, Only Deny List MAC or Only Allow List MAC**.

Two ways to set MAC filter rules :

- ➔ **Only Allow List MAC.**

The wireless clients in the **“Enable”** list will be **allowed** to access the Access Point; All others or clients in the **“Disable”** list will be **denied**.

- ➔ **Only Deny List MAC.**

The wireless clients in the **“Enable”** list will be **denied** to access the Access Point; All others or clients in the **“Disable”** list will be **allowed**.


**Add a station MAC** : Enter MAC address (e.g. aa:bb:cc:00:00:0a) and click **“Add”** button, then the MAC address should display in the **“Enable”** List.

There are a maximum of **20** clients allowed in this **“Enable”** List. The MAC addresses of the wireless clients can be added and removed to the list using the **Add** and **Remove** buttons.

Click **Reboot** button to activate your changes

## Wireless Network Expansion

The administrator could create WDS Links to expand wireless network. When WDS is enabled, access point functions as a wireless bridge and is able to communicate with other access points via WDS links. A WDS link is **bidirectional** and **both side must support WDS**. Access points know each other by **MAC Address**. In other words, each access point needs to include **MAC address of its peer**. Ensure all access points are configured with the same channel and own same security type settings.



Please click on **Wireless -> WDS Setup** and follow the below setting.

### WDS Setup

#### Security

Security Type : AES

AES Key : 1234567890

#### WDS MAC List

Enable	WDS Peer's MAC Address	Description
<input checked="" type="checkbox"/>	01. 00 : 11 : A3 : 07 : 03 : 60	<input style="width: 95%;" type="text"/>
<input type="checkbox"/>	02. <input style="width: 20px;" type="text"/> : <input style="width: 20px;" type="text"/> : <input style="width: 20px;" type="text"/> : <input style="width: 20px;" type="text"/> : <input style="width: 20px;" type="text"/> : <input style="width: 20px;" type="text"/>	<input style="width: 95%;" type="text"/>
<input type="checkbox"/>	03. <input style="width: 20px;" type="text"/> : <input style="width: 20px;" type="text"/> : <input style="width: 20px;" type="text"/> : <input style="width: 20px;" type="text"/> : <input style="width: 20px;" type="text"/> : <input style="width: 20px;" type="text"/>	<input style="width: 95%;" type="text"/>
<input type="checkbox"/>	04. <input style="width: 20px;" type="text"/> : <input style="width: 20px;" type="text"/> : <input style="width: 20px;" type="text"/> : <input style="width: 20px;" type="text"/> : <input style="width: 20px;" type="text"/> : <input style="width: 20px;" type="text"/>	<input style="width: 95%;" type="text"/>

Save

- **Security Type** : Option is "Disable", "WEP", "TKIP" or "AES" from drop-down list. Needs the same type to build WDS links. Security type takes effect when WDS is enabled.
  - **WEP Key** : Enter 5 / 13 ASCII or 10 / 26 HEX format WEP key.
  - **TKIP Key** : Enter 8 to 63 ASCII or 64 HEX format TKIP key.
  - **AES Key** : Enter 8 to 63 ASCII or 64 HEX format AES key.
- **WDS MAC List**
  - **Enable** : Click **Enable** to create WDS link.
  - **WDS Peer's MAC Address** : Enter the MAC address of WDS peer.
  - **Description** : Description of WDS link.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes

## System Status

This section breaks down into subsections of **System Overview**, **Associated Clients Status**, **WDS Link Status**, **Extra Information** and **Event Log**.

### System Overview

Display detailed information of **System**, **Network**, **LAN and Wireless** in the System Overview page.

- **System** : Display the information of the system.

System	
Host Name	: TEW-676APBO
Operating Mode	: AP Mode
Location	:
Description	: Wireless Outdoor PoE Access Point
Firmware Version	: Cen-CPE-N5H5R V1.0.15
Firmware Date	: 2010-12-16 02:52:11
Device Time	: 2000-01-01 00:06:07
System Up Time	: 06:07

- **System Name** : The name of the system.
- **Operating Mode** : The mode currently in service.
- **Location** : Deployed geographical location.



- **Description** : A description of the system.
- **Firmware Version** : The current installed firmware version.
- **Firmware Date** : The build time of installed firmware.
- **Device Time** : The current time of the system.
- **System Up Time** : The time period that system has been in service since last reboot.

- **Network Information** : Supports Static or Dynamic modes on the LAN interface.

Network	
Mode	: Static IP Mode
IP Address	: 192.168.10.101
IP Netmask	: 255.255.255.0
IP Gateway	: 192.168.10.1
Primary DNS	:
Secondary DNS	:

- **IP Address** : The management IP of system. By default, it's 192.168.2.254.
- **IP Netmask** : The network mask. By default, it's 255.255.255.0.
- **IP Gateway** : The gateway IP address and by default, it's 192.168.2.1.
- **Primary DNS** : The primary DNS server in service.
- **Secondary DNS** : The secondary DNS server in service.

- **LAN Information** : Display total received and transmitted statistics on the LAN interface.

LAN Information	
MAC Address	: 00:11:A3:07:03:47
Receive Bytes	: 19491
Receive Packets	: 156
Transmit Bytes	: 95168
Transmit Packets	: 155

- **MAC Address** : The MAC address of the LAN port.
- **Receive bytes** : The total received packets in bytes on the LAN port.
- **Receive packets** : The total received packets of the LAN port.
- **Transmit bytes** : The total transmitted packets in bytes of the LAN port.
- **Transmit packets** : The total transmitted packets of the LAN port.

- **Wireless Information** : Display total received and transmitted statistics on available Virtual AP.

Wireless Information	
MAC Address	: 00:11:A3:07:03:48
Channel	: 44
Rate	: 300 Mb/s
Receive Bytes	: 685129
Receive Packets	: 4111
Transmit Bytes	: 4074
Transmit Packets	: 46

- **MAC Address** : The MAC address of the Wireless port.
- **Channel** : The current channel on the Wireless port.
- **Rate** : The current Bit Rate on the Wireless port.
- **Receive bytes** : The total received packets in bytes on the Wireless port.
- **Receive packets** : The total received packets on the Wireless port.
- **Transmit bytes** : The total transmitted packets in bytes on the Wireless port.
- **Transmit packets** : The total transmitted packets on the Wireless port.

## Associated Clients Status

It displays ESSID, on/off Status, Security Type, total number of wireless clients associated with all Virtual AP.

Wireless Clients <span style="float: right;">Refresh</span>					
VAP Information					
VAP	ESSID	MAC Address	Status	Security Type	Clients
Primary AP	TRENDnet676	00:11:A3:07:03:48	On	Disable	0
VAP1		00:00:00:00:00:00	Off	Disable	0
VAP2		00:00:00:00:00:00	Off	Disable	0
VAP3		00:00:00:00:00:00	Off	Disable	0
VAP4		00:00:00:00:00:00	Off	Disable	0
VAP5		00:00:00:00:00:00	Off	Disable	0
VAP6		00:00:00:00:00:00	Off	Disable	0

- **VAP Information** : Highlights key VAP information.
  - ➔ **VAP** : Available VAP from Primary AP to VAP6.
  - ➔ **ESSID** : Display name of ESSID for each VAP.
  - ➔ **MAC Address** : Display MAC address for each VAP.
  - ➔ **Status** : On/Off
  - ➔ **Security Type** : Display chosen security type; WEP, WPA/WPA2-PSK, WPA/WPA2-Enterprise.
  - ➔ **Clients** : Display total number of wireless connections for each VAP.
- **VAP Clients** : Display all associated clients on each Virtual AP.
  - ➔ **MAC Address** : MAC address of associated clients
  - ➔ **Signal Strength ANT0/ANT1** : Signal Strength of from associated clients.
  - ➔ **Bandwidth** : Channel bandwidth of from associated clients
  - ➔ **Idle Time** : Last inactive time period in seconds for a wireless connection.
  - ➔ **Connect Time** : Total connection time period in seconds for a wireless connection.
  - ➔ **Disconnect** : Click "Delete" button to manually disconnect a wireless client in a Virtual AP.

### Show WDS Link Status

Peers MAC Address, antenna 0/1 received signal strength, phy mode and channel bandwidth for each WDS are available.

WDS Information <span style="float: right;">Refresh</span>					
WDS Link Status					
MAC Address	Signal Strength ANT0	Signal Strength ANT1	Phy Mode	Bandwidth	MCS SGI
00:11:A3:07:03:60	no signal	no signal	HTMIX	40M	15 0

- **MAC Address** : Display MAC address of WDS peer.
- **Signal Strength ANT0/ANT1** : Indicate the signal strength of the respective WDS links.
- **Phy Mode** : Indicate the phy mode of the respective WDS linked.
- **BandWidth** : Indicate the channel bandwidth of the respective WDS linked.
- **MCS** : Indicate the MCS of the respective WDS linked.
- **SGI** : Indicate the SGI (Short Guard Interval) of the respective WDS linked. "1" indicate the Short Guard Interval, "0" indicate the Long Guard Interval.

### Extra Information

Users could pull out information such as Route table, ARP table, MAC table, Bridge table or STP available in the drop-down list from system. The "Refresh" button is used to retrieve latest table information.

Extra Information <span style="float: right;">Refresh</span>			
Information : <input type="text" value="Route Information"/>			
Route Information			
Destination	Gateway	Netmask	Interface
192.168.10.0	0.0.0.0	255.255.255.0	bre0
0.0.0.0	192.168.10.1	0.0.0.0	bre0

- **Route table information** : Select "Route table information" on the drop-down list to display route table.

TEW-676APBO could be used as a L2 or L3 device. It doesn't support dynamic routing protocols such as RIP or OSPF. Static routes to specific hosts, networks or default gateway are set up automatically according to the IP configuration of system's interfaces. When used as a L2 device, it could switch packets and, as L3 device, it's capable of being a gateway to route packets inward and outward.

Route Information			
Destination	Gateway	Netmask	Interface
192.168.10.0	0.0.0.0	255.255.255.0	bre0
0.0.0.0	192.168.10.1	0.0.0.0	bre0

- **ARP table Information** : Select “**ARP Table Information**” on the drop-down list to display ARP table.

ARP associates each IP address to a unique hardware address (MAC) of a device. It is important to have a unique IP address as final destination to switch packets to.

ARP Table Information		
IP Address	MAC Address	Interface
192.168.10.143	00:26:2D:5B:46:53	bre0

- **Bridge table information** : Select “**Bridge Table information**” on the drop-down list to display bridge table.

Bridge table will show Bridge ID and STP's Status on the each Ethernet bridge and its attached interfaces, the Bridge Port should be attached to some interfaces (e.g. eth2, ra0~ra6 and wds0~wds3).

Bridge Table Information			
Bridge Port	Bridge ID	STP Enabled	Interface
bre0	8000.0011a3070347	no	eth2 ra0 wds0

- **Bridge MAC information** : Select “**Bridge MACs Information**” on the drop-down list to display MAC table.

Bridge MACs Information			
Port	MAC Address	Local	Ageing Timer
LAN	00:11:a3:07:03:47	yes	0.00
PrimaryAP	00:11:a3:07:03:48	yes	0.00
LAN	00:26:2d:5b:46:53	no	0.11

This table displays local MAC addresses associated with wired or wireless interfaces, but also remember non-local MAC addresses learned from wired or wireless interfaces.

Ageing timers will be reset when existing MAC addresses in table are learned again or added when new MAC addresses are seen from wired or wireless interfaces as well. When time runs out for a particular entry, it will be pruned from the table. In that situation, switching packet to that particular MAC address will be dropped.

- **Bridge STP Information** : Select “**Bridge STP Information**” on the drop-down list to display a list of bridge STP information.

Bridge STP Information			
<b>br0</b>			
bridge id	8000.0011a3070347		
designated root	8000.0011a3070347		
root port	0	path cost	0
max age	20.00	bridge max age	20.00
hello time	2.00	bridge hello time	2.00
forward delay	15.00	bridge forward delay	15.00
ageing time	300.00		
hello timer	1.91	ton timer	0.00
topology change timer	0.00	gc timer	3.91
flags			
<b>eth2 (1)</b>			
port id	8001	state	forwarding
designated root	8000.0011a3070347	path cost	100
designated bridge	8000.0011a3070347	message age timer	0.00
designated port	8001	forward delay timer	0.00
designated cost	0	hold timer	0.00
flags			
<b>ra0 (2)</b>			
port id	8002	state	forwarding
designated root	8000.0011a3070347	path cost	100
designated bridge	8000.0011a3070347	message age timer	0.00
designated port	8002	forward delay timer	0.00
designated cost	0	hold timer	0.00
flags			
<b>wd0 (3)</b>			
port id	8003	state	forwarding
designated root	8000.0011a3070347	path cost	100
designated bridge	8000.0011a3070347	message age timer	0.00
designated port	8003	forward delay timer	0.00
designated cost	0	hold timer	0.00
flags			

## Event Log

The Event log displays system events when system is up and running. Also, it becomes very useful as a troubleshooting tool when issues are experienced in system.

System Log				Refresh	Clear
<b>Result</b>					
Time	Facility	Severity	Message		
2000-01-01 00:00:09	System	Info	dnsmasq[109]: started, version 2.40 cachesize 150		
2000-01-01 00:00:09	System	Info	dnsmasq[109]: compile time options: no-IPv6 GNU-getopt no-RTC no-MMU no-ISC-leasefile no-DBus no-I18N TFTP		
2000-01-01 00:00:09	System	Warn	dnsmasq[109]: failed to access /etc/resolv.conf: No such file or directory		
2000-01-01 00:00:09	System	Info	dnsmasq[109]: cleared cache		
2000-01-01 00:00:23	System	Info	Authentication successful for root from 192.168.10.143		

- **Time** : The date and time when the event occurred.
- **Facility** : It helps users to identify source of events such “System” or “User”
- **Severity** : Severity level that a specific event is associated such as “info”, “error”, “warning”, etc.
- **Message** : Description of the event.

Click **Refresh** button to renew the log, or click **Clear** button to clear all the record.

## WDS Mode Configuration

Please refer to illustrations of the section 1.3 for possible applications in the WDS mode. This section provides detailed explanation for users to configure in the WDS mode with help of illustrations. In the WDS mode, functions listed in the table below are also available from the Web-based GUI interface.


Option	System	Wireless	Utilities	Status
Functions	Operating	General Setup	Profiles Settings	System
	LAN	Advanced Setup	Firmware	WDS Status
	Management	WDS Setup	Network Utility	Extra Info
	Time Server		Reboot	Event Log
	SNMP			

*WDS Mode Functions*

## External Network Connection

### Network Requirement

You could expand your Ethernet network via WDS link. In this mode, the TEW-676APBO connects directly to a wired LAN, and wirelessly bridges to a remote access point via a WDS link as shown in Figure 4-1. In the mode, it can't associate with any wireless clients.



Point to Point network Configuration

## Configure LAN IP

Here are the instructions for how to setup the local IP Address and Netmask. Please click on **System -> LAN** and follow the below setting.

Ethernet Connection Type	
Mode :	<input checked="" type="radio"/> Static IP <input type="radio"/> Dynamic IP
Static IP	
IP Address :	<input type="text" value="192.168.10.101"/>
IP Netmask :	<input type="text" value="255.255.255.0"/>
IP Gateway :	<input type="text" value="192.168.10.1"/>

- **Mode** : Check either “Static IP” or “Dynamic IP” button as desired to set up the system IP of LAN port .
    - ➔ **Static IP** : The administrator can manually setup the LAN IP address when static IP is available/ preferred.
      - ✓ **IP Address** : The IP address of the LAN port; default IP address is 192.168.2.254
      - ✓ **IP Netmask** : The Subnet mask of the LAN port; default Netmask is 255.255.255.0
      - ✓ **IP Gateway** : The default gateway of the LAN port; default Gateway is 192.168.2.1
    - ➔ **Dynamic IP** : This configuration type is applicable when the TEW-676APBO is connected to a network with the presence of a DHCP server; all related IP information will be provided by the DHCP server automatically.
      - ✓ **Hostname** : The Hostname of the LAN port
- | Dynamic IP |                      |
|------------|----------------------|
| Hostname : | <input type="text"/> |
- **DNS** : Check either “No Default DNS Server” or “Specify DNS Server IP” button as desired to set up the system DNS.
    - ➔ **Primary** : The IP address of the primary DNS server.
    - ➔ **Secondary** : The IP address of the secondary DNS server.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes

## Wireless Network Expansion

The network manager can configure related wireless settings, **General Settings**, **Advanced Settings** and **WDS Settings**.

### General Setup

The administrator can change the data transmission, channel and output power settings for the system. Please click on **Wireless** -> **General Setup** and follow the below setting.

General Setup	
MAC Address :	00:11:A3:07:03:48
Band Mode :	802.11 a/n mixed mode ▼
Country :	NONE ▼
Channel/ Frequency :	44 (5220MHz) ▼
Tx Power :	10 %

- **MAC Address** : The MAC address of the Wireless interface is displayed here.
- **Band Mode** : Select an appropriate wireless band; bands available are **801.11a** or **802.11a/n mixed mode**.
- **Transmit Rate Control** : Select the desired rate from the drop-down list; the options are auto or ranging from **6** to **54Mbps** only for **802.11a** mode.
- **Tx Power** : You can adjust the output power of the system to get the appropriate coverage for your wireless network. Specify digit number between **1** to **100** (the unit is %) for your environment. If you are not sure which setting to choose, then keep the default setting, **100%**.

HT Other	
HT Tx Stream :	2 ▼
HT Rx Stream :	2 ▼

When **Band Mode** select in **802.11a only mode**, the **HT(High Throughput)** settings should be hidden immediately.

- **HT TxStream/RxStream** : By default, it's **2**.

HT Physical Mode	
Operating Mode :	<input checked="" type="radio"/> Mixed Mode <input type="radio"/> Green Field
Channel BandWidth :	<input type="radio"/> 20 <input checked="" type="radio"/> 20/40
Guard Interval :	<input type="radio"/> Long <input checked="" type="radio"/> Auto
MCS :	Auto ▼
Reverse Direction Grant (RDG) :	<input type="radio"/> Disable <input checked="" type="radio"/> Enable
A-MSDU :	<input checked="" type="radio"/> Disable <input type="radio"/> Enable
Auto Block ACK :	<input type="radio"/> Disable <input checked="" type="radio"/> Enable
Decline BA Request :	<input checked="" type="radio"/> Disable <input type="radio"/> Enable

- **Operating Mode** : By default, it's Mixed mode
  - ➔ **Mixed Mode** : In this mode packets are transmitted with a preamble compatible with the legacy 802.11a/g, the rest of the packet has a new format. In this mode the receiver shall be able to decode both the Mixed Mode packets and legacy packets.
  - ➔ **Green Field** : In this mode high throughput packets are transmitted without a legacy compatible part.
- **Channel Bandwidth** : The "20/40" MHz option is usually best. The other option is available for special circumstances.
- **Guard Interval** : Using "Auto" option can increase throughput. However, it can also increase error rate in some installations, due to increased sensitivity to radio-frequency reflections. Select the option that works best for your installation.
- **MCS** : This parameter represents transmission rate. By default (Auto) the fastest possible transmission rate will be selected. You have the option of selecting the speed if necessary. (Refer to **Appendix C. MCS Data Rate**)
- **Reverse Direction Grant(RDG)** : Disable or enable reserve direction grant. Default is enabled.
- **A-MSDU** : Aggregated Mac Service Data Unit . Select **Enable** to allow aggregation for multiple MSDUs in one MPDU Default is disabled.
- **Auto Block ACK** : Disable or enable auto block ACK. Default is enabled.
- **Decline BA Request** : Disable or enable decline BA request. Default is disabled.


Change these settings as described here and click **Save** button to save your changes. Click **Reboot** button to activate your changes. The items in this page are for AP's RF general settings and will be applied to **all WDS Links**.



## Wireless Advanced Setup

To achieve optimal wireless performance, it is necessary to tweak advance setting per requirements properly, not necessary higher the better or lower.

The administrator can change the RTS threshold and fragmentation threshold settings for the system. Please click on **Wireless** -> **Advanced Setup** and follow the below setting.



- **Short Slot** : By default, it's "Enable" for reducing the slot time from the standard **20 microseconds** to the **9 microsecond** short slot time

Slot time is the amount of time a device waits after a collision before retransmitting a packet. Reducing the slot time decreases the overall back-off, which increases throughput. Back-off, which is a multiple of the slot time, is the random length of time a station waits before sending a packet on the LAN. For a sender and receiver own right of the channel the shorter slot time help manage shorter wait time to re-transmit from collision because of hidden wireless clients or other causes. When collision sources can be removed sooner and other senders attempting to send are listening the channel (CSMA/CA) the owner of the channel should continue ownership and finish their transmission and release the channel. Then, following ownership of the channel will be sooner for the new pair due to shorter slot time. However, when long duration of existing collision sources and shorter slot time exist the owners might experience subsequent collisions. When adjustment to longer slot time can't improve performance then RTS/CTS could supplement and help

improve performance.

- **Extra Slot Time** : Slot time is in the range of **1~255** and set in unit of **microsecond**. The default value is **9** microsecond.
- **ACK Timeout** : ACK timeout is in the range of **1~255** and set in unit of **microsecond**. The default value is **32** microsecond.

All data transmission in 802.11b/g request an "Acknowledgement" (ACK) send by receiving radio. The transmitter will resend the original packet if correspondent ACK failed to arrive within specific time interval, also refer to as "ACK Timeout".

ACK Timeout is adjustable due to the fact that distance between two radio links may vary in different deployment. ACK Timeout makes significant influence in performance of long distance radio link. If ACK Timeout is set too short, transmitter will start to "Resend" packet before ACK is received, and throughputs become low due to excessively high re-transmission.

ACK Timeout is best determined by distance between the radios, data rate of average environment. The Timeout value is calculated based on round-trip time of packet with a little tolerance, So, if experiencing re-transmissions or poor performance the ACK Timeout could be made longer to accommodate.

- **Beacon Interval** : Beacon Interval is in the range of **20~1024** and set in unit of **millisecond**. The default value is **100** msec.

Access Point (AP) in IEEE 802.11 will send out a special approximated 50-byte frame, called "Beacon". Beacon is broadcast to all the stations, provides the basic information of AP such as SSID, channel, encryption keys, signal strength, time stamp, support data rate.

All the radio stations received beacon recognizes the existence of such AP, and may proceed next actions if the information from AP matches the requirement. Beacon is sent on a periodic basis, the time interval can be adjusted.

By increasing the beacon interval, you can reduce the number of beacons and associated overhead, but that will likely delay the association and roaming process because stations scanning for available access points may miss the beacons. You can decrease the beacon interval, which increases the rate of beacons. This will make the association and roaming process very responsive; however, the network will incur additional overhead and throughput will go down.

- **DTIM Interval** : The DTIM interval is in the range of **1~255**. The default is **1**. DTIM is defined as *Delivery Traffic Indication Message*. It is used to notify the wireless stations, which support power saving mode, when to wake up to receive multicast frame. DTIM is necessary and critical in wireless environment as a

mechanism to fulfill power-saving synchronization.

A DTIM interval is a count of the number of beacon frames that must occur before the access point sends the buffered multicast frames. For instance, if DTIM Interval is set to 3, then the Wi-Fi clients will expect to receive a multicast frame after receiving three Beacon frame. The higher DTIM interval will help power saving and possibly decrease wireless throughput in multicast applications.

- **Fragment Threshold** : The Fragment Threshold is in the range of **256~2346** byte. The default is **2346** byte.

Each Wi-Fi packet can be divided into smaller packets, marked with a sequential fragment number and re-assemble in the receiving ends. The purpose is to make a short frame, instead of long frame, transmitting by radio in a heavy noisy environment. Because of sending smaller frames, corruptions are much less likely to occur. The pros is obvious, the cons is the overhead for transmission. So, in a clean environment, higher fragment threshold can be an option to increase throughput.

Fragmentation will be triggered by setting the Fragment Threshold, usually in Byte-length. Only when the frame size is over the Threshold, fragmentation will take place automatically.

- **RTS Threshold** : TRTS Threshold is in the range of **1~2347** byte. The default is **2347** byte.

The main purpose of enabling RTS by changing RTS threshold is to reduce possible collisions due to hidden wireless clients. RTS in AP will be enabled automatically if the packet size is larger than the Threshold value. By default, RTS is disabled in a normal environment supports non-jumbo frames.

- **Short Preamble** : By default, it's "**Enable**". To **Disable** is to use Long 128-bit Preamble Synchronization field.

The preamble is used to signal "here is a train of data coming" to the receiver. The short preamble provides 72-bit Synchronization field to improve WLAN transmission efficiency with less overhead.

- **Tx Burst** : By default, it's "**Enable**". To **Disable** is to deactivate Tx Burst.

With TX burst enabled, AP will send many packets in a burst, without collision detection and RTS/CTS for each packet. TX Burst have better throughput but cause interference with other APs in channel.

- **Pkt\_Aggregate** : By default, it's "**Enable**"

Increase efficiency by aggregating multiple packets of application data into a single transmission frame. In this way, 802.11n networks can send multiple data packets

with the fixed overhead cost of just a single frame.

- **WMM** : By default, it's "**Disable**". To **Enable** is to use WMM and the WMM parameters should appears.

WMM Parameters of Access Point						
	Aifsn	CWMin	CWMax	Txop	ACM	AckPolicy
AC_BE	3	15	63	0	<input type="checkbox"/>	<input type="checkbox"/>
AC_BK	7	15	1023	0	<input type="checkbox"/>	<input type="checkbox"/>
AC_VI	1	7	15	94	<input type="checkbox"/>	<input type="checkbox"/>
AC_VO	1	3	7	47	<input type="checkbox"/>	<input type="checkbox"/>

WMM Parameters of Station					
	Aifsn	CWMin	CWMax	Txop	ACM
AC_BE	3	15	1023	0	<input type="checkbox"/>
AC_BK	7	15	1023	0	<input type="checkbox"/>
AC_VI	2	7	15	94	<input type="checkbox"/>
AC_VO	2	3	7	47	<input type="checkbox"/>

➔ **WMM Parameters of Access Point** : This affects traffic flowing from the access point to the client station

Queue	Data Transmitted AP to Clients	Priority	Description
AC_BK	Background.	Low	High throughput. Bulk data that requires maximum throughput and is not time-sensitive is sent to this queue (FTP data, for example).
AC_BE	Best Effort	Med	Medium throughput and delay. Most traditional IP data is sent to this queue
AC_VI	Video	High	Minimum delay. Time-sensitive video data is automatically sent to this queue
AC_VO	Voice	High	Time-sensitive data like VoIP and streaming media are automatically sent to this queue

Configuring QoS options consists of setting parameters on existing queues for different types of wireless traffic. You can configure different minimum and maximum wait times for the transmission of packets in each queue based on the requirements of the media being sent. Queues automatically provide



minimum transmission delay for Voice, Video, multimedia, and mission critical applications, and rely on best-effort parameters for traditional IP data. As an Example, time-sensitive Voice & Video, and multimedia are given effectively higher priority for transmission (lower wait times for channel access), while other applications and traditional IP data which are less time-sensitive but often more data-intensive are expected to tolerate longer wait times.

- ✓ **Aifsn** : The Arbitration Inter-Frame Spacing Number specifies a wait time (in milliseconds) for data frames
- ✓ **CWmin** : Minimum Contention Window. This parameter is input to the algorithm that determines the initial random backoff wait time ("window") for retry of a transmission. The value specified here in the Minimum Contention Window is the upper limit (in milliseconds) of a range from which the initial random backoff wait time is determined.
- ✓ **CWmax** : Maximum Contention Window. The value specified here in the Maximum Contention Window is the upper limit (in milliseconds) for the doubling of the random backoff value. This doubling continues until either the data frame is sent or the Maximum Contention Window size is reached. Once the Maximum Contention Window size is reached, retries will continue until a maximum number of retries allowed is reached. Valid values for the "cwmax" are 1, 3, 7, 15, 31, 63, 127, 255, 511, or 1024. The value for "cwmax" must be higher than the value for "cwmin".
- ✓ **Txop** : Transmission Opportunity is an interval of time when a WME AP has the right to initiate transmissions onto the wireless medium (WM). This value specifies (in milliseconds) the Transmission Opportunity (TXOP) for AP; that is, the interval of time when the WMM AP has the right to initiate transmissions on the wireless network.
- ✓ **ACM** : Admission Control Mandatory, ACM only takes effect on AC\_VI and AC\_VO. When you do not click Checkbox, it means that the ACM is controlled by the connecting AP. If you click Checkbox, it means that the Client is in charge.
- ✓ **AckPolicy** : Acknowledgment Policy, WMM defines two ACK policies: **Normal ACK** and **No ACK**. Click "**Checkbox**" indicates "**No ACK**" When the no acknowledgment (No ACK) policy is used, the recipient does not acknowledge received packets during wireless packet exchange. This policy is suitable in the environment where communication quality is fine and interference is weak. While the No ACK policy helps improve transmission efficiency, it can cause increased packet loss when

communication quality deteriorates. This is because when this policy is used, a sender does not retransmit packets that have not been received by the recipient.

When the Normal ACK policy is used, the recipient acknowledges each received unicast packet.

Queue	Data Transmitted Clients to AP	Priority	Description
AC_BK	Background.	Low	High throughput. Bulk data that requires maximum throughput and is not time-sensitive is sent to this queue (FTP data, for example).
AC_BE	Best Effort	Medium	Medium throughput and delay. Most traditional IP data is sent to this queue
AC_VI	Video	High	Minimum delay. Time-sensitive video data is automatically sent to this queue
AC_VO	Voice	High	Time-sensitive data like VoIP and streaming media are automatically sent to this queue

➔ **WMM Parameters of Station** : *This affects traffic flowing from the client station to the access point.*

- ✓ **Aifsn** : The Arbitration Inter-Frame Spacing Number specifies a wait time (in milliseconds) for data frames

**CWmin** : Minimum Contention Window. This parameter is input to the algorithm that determines the initial random backoff wait time ("window") for retry of a transmission. The value specified here in the Minimum Contention Window is the upper limit (in milliseconds) of a range from which the initial random backoff wait time is determined.

**CWmax** : Maximum Contention Window. The value specified here in the Maximum Contention Window is the upper limit (in milliseconds) for the doubling of the random backoff value. This doubling continues until either the data frame is sent or the Maximum Contention Window size is reached. Once the Maximum Contention Window size is reached, retries will continue until a maximum number of retries allowed is reached. Valid values for the "cwmax" are 1, 3, 7, 15, 31, 63, 127, 255, 511, or 1024. The value for "cwmax" must be higher than the value for "cwmin".


**Txop** : Transmission Opportunity is an interval of time when a WME AP has the right to initiate transmissions onto the wireless medium (WM). This value specifies (in

milliseconds) the Transmission Opportunity (Txop) for AP; that is, the interval of time when the WMM AP has the right to initiate transmissions on the wireless network.  
**ACM** : Admission Control Mandatory, ACM only takes effect on AC\_VI and AC\_VO. When you do not click Checkbox, it means that the ACM is controlled by the connecting AP. If you click Checkbox, it means that the Client is in charge.

Change these settings as described here and click **Save** button to save your changes. Click **Reboot** button to activate your changes. The items in this page are for AP's RF advanced settings and will be applied to **all WDS Links**.

### WDS Setup

The administrator could create WDS Links to expand wireless network. When WDS is enabled, access point functions as a wireless bridge and is able to communicate with other access points via WDS links. **A WDS link is bidirectional and both side must support WDS. Access points know each other by MAC Address. In other words, each access point needs to include MAC address of its peer. Ensure all access points are configured with the same channel and own same security type settings.**



- **Security Type** : Option is "Disable", "WEP", "TKIP" or "AES" from drop-down list. Needs the same type to build WDS links. Security type takes effect when WDS is

enabled.

- ➔ **WEP Key** : Enter **5 / 13 ASCII** or **10 / 26 HEX** format WEP key.
- ➔ **TKIP Key** : Enter **8 to 63 ASCII** or **64 HEX** format TKIP key.
- ➔ **AES Key** : Enter **8 to 63 ASCII** or **64 HEX** format AES key.

- **WDS MAC List**

- ➔ **Enable** : Click **Enable** to create WDS link.
- ➔ **WDS Peer's MAC Address** : Enter the MAC address of WDS peer.
- ➔ **Description** : Description of WDS link.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes


### System Status

This section breaks down into subsections of **System Overview**, **WDS Link Status**, **Extra Information** and **Event Log**.

### System Overview

Detailed information on **System**, **Network**, **LAN Information** and **Wireless Information** can be reviewed via this page.

- **System** : Display the information of the system.



- ➔ **System Name** : The name of the system.
- ➔ **Operating Mode** : The mode currently in service.

- **Location** : The reminding note on the geographical location of the system.
- **Description** : The reminding note of the system.
- **Firmware Version** : The current firmware version installed.
- **Firmware Date** : The build time of the firmware installed.
- **Device Time** : The current time of the system.
- **System Up Time** : The time period that system has been in service since last reboot.

■ **Network Information** : Display the information of the Network.

Network	
Mode	: Static IP Mode
IP Address	: 192.168.10.101
IP Netmask	: 255.255.255.0
IP Gateway	: 192.168.10.1
Primary DNS	:
Secondary DNS	:

- **Mode** : Supports Static or Dynamic modes on the LAN interface.
- **IP Address** : The management IP of system. By default, it's 192.168.2.254.
- **IP Netmask** : The network mask. By default, it's 255.255.255.0.
- **IP Gateway** : The gateway IP address and by default, it's 192.168.2.1.
- **Primary DNS** : The primary DNS server in service.
- **Secondary DNS** : The secondary DNS server in service.

■ **LAN Information** : Display total received and transmitted statistics on the LAN interface.

LAN Information	
MAC Address	: 00:11:A3:07:03:47
Receive Bytes	: 24234
Receive Packets	: 197
Transmit Bytes	: 113002
Transmit Packets	: 197

- **MAC Address** : The MAC address of the LAN port.
- **Receive bytes** : The total received packets in bytes on the LAN port.

- **Receive packets** : The total received packets of the LAN port.
- **Transmit bytes** : The total transmitted packets in bytes of the LAN port.
- **Transmit packets** : The total transmitted packets of the LAN port.

■ **Wireless Information** : Display the detailed receive and transmit statistics of Wireless interface.

Wireless Information	
MAC Address	: 00:11:A3:07:03:48
Channel	: 44
Rate	: 300 Mb/s
Receive Bytes	: 1560711
Receive Packets	: 7255
Transmit Bytes	: 7055
Transmit Packets	: 18

- **MAC Address** : The MAC address of the Wireless port.
- **Channel** : The current channel on the Wireless port.
- **Rate** : The current Bit Rate on the Wireless port.
- **Receive bytes** : The total received packets in bytes on the Wireless port.
- **Receive packets** : The total received packets of the Wireless port.
- **Transmit bytes** : The total transmitted packets in bytes of the Wireless port.
- **Transmit packets** : The total transmitted packets of the Wireless port.

**WDS List**


Peers MAC Address, antenna 0/1 received signal strength, phy mode and channel bandwidth for each WDS are available.

WDS Information <span style="float: right;">Refresh</span>						
WDS Link Status						
MAC Address	Signal Strength ANT0	Signal Strength ANT1	Phy Mode	Bandwidth	MC S	SGI
00:11:A3:07:03:60	no signal	no signal	HTMIX	40M	15	0

- **MAC Address** : Display MAC address of WDS peer.
- **Signal Strength ANT0/ANT1** : Indicate the signal strength of the respective WDS links.
- **Phy Mode** : Indicate the phy mode of the respective WDS linked.
- **BandWidth** : Indicate the channel bandwidth of the respective WDS linked.
- **MCS** : Indicate the MCS of the respective WDS linked.
- **SGI** : Indicate the SGI (Short Guard Interval) of the respective WDS linked. "1" indicate the Short Guard Interval, "0" indicate the Long Guard Interval.

### Extra Information

Users could pull out information such as Route table, ARP table, MAC table, Bridge table or STP available in the drop-down list from system. The "Refresh" button is used to retrieve latest table information.



- **Route table information** : Select "Route table information" on the drop-down list to display route table.

TEW-676APBO could be used as a L2 or L3 device. It doesn't support dynamic routing protocols such as RIP or OSPF. Static routes to specific hosts, networks or default gateway are set up automatically according to the IP configuration of system's interfaces. When used as a L2 device, it could switch packets and, as L3 device, it's capable of being a gateway to route packets inward and outward.

Destination	Gateway	Netmask	Interface
192.168.10.0	0.0.0.0	255.255.255.0	bre0
0.0.0.0	192.168.10.1	0.0.0.0	bre0

- **ARP table Information** : Select "ARP Table Information" on the drop-down list to display ARP table. ARP associates each IP address to a unique hardware address (MAC) of a device. It is important to have a unique IP address as final destination to switch packets to.

IP Address	MAC Address	Interface
192.168.10.143	00:26:2D:5B:46:53	bre0

- **Bridge table information** : Select "Bridge Table information" on the drop-down list to display bridge table.

Bridge table will show Bridge ID and STP's Status on the each Ethernet bridge and its attached interfaces, the Bridge Port should be attached to some interfaces (e.g. eth2, ra0 and wds0~wds3).

Bridge Port	Bridge ID	STP Enabled	Interface
bre0	8000.0011a3070347	no	eth2 ra0 wds0

- **Bridge MAC information** : Select "Bridge MACs Information" on the drop-down list to display MAC table.

This table displays local MAC addresses associated with wired or wireless interfaces, but also remember non-local MAC addresses learned from wired or wireless interfaces.

Ageing timers will be reset when existing MAC addresses in table are learned again or added when new MAC addresses are seen from wired or wireless interfaces as well. When time runs out for a particular entry, it will be pruned from the table. In that situation, switching packet to that particular MAC address will be discontinued.

Port	MAC Address	Local	Ageing Timer
LAN	00:11:a3:07:03:47	yes	0.00
LAN	00:26:2d:5b:46:53	no	0.10

- **Bridge STP Information** : Select “**Bridge STP Information**” on the drop-down list to display a list of bridge STP information.

Bridge STP Information			
<b>br0</b>			
bridge id	8000.0011a3070347		
designated root	8000.0011a3070347		
root port	0	path cost	0
max age	20.00	bridge max age	20.00
hello time	2.00	bridge hello time	2.00
forward delay	15.00	bridge forward delay	15.00
ageing time	300.00		
hello timer	0.39	tcn timer	0.00
topology change timer	0.00	gc timer	0.39
flags			
<b>eth2 (1)</b>			
port id	8001	state	forwarding
designated root	8000.0011a3070347		
designated bridge	8000.0011a3070347		
designated port	8001	forward delay timer	0.00
designated cost	0	hold timer	0.42
flags			
<b>ra0 (2)</b>			
port id	8002	state	forwarding
designated root	8000.0011a3070347		
designated bridge	8000.0011a3070347		
designated port	8002	forward delay timer	0.00
designated cost	0	hold timer	0.44
flags			
<b>wd0 (3)</b>			
port id	8003	state	forwarding
designated root	8000.0011a3070347		
designated bridge	8000.0011a3070347		
designated port	8003	forward delay timer	0.00
designated cost	0	hold timer	0.47
flags			

## Event Log

The Event log displays system events when system is up and running. Also, it becomes very useful as a troubleshooting tool when issues are experienced in system.

Result			
Time	Facility	Severity	Message
2000-01-01 00:00:09	System	Info	dnsmasq[109]: started, version 2.40 cachesize 150
2000-01-01 00:00:09	System	Info	dnsmasq[109]: compile time options: no-IPv6 GNU-getopt no-RTC no-MMU no-ISC-leasefile no-DBus no-I18N TFTP
2000-01-01 00:00:09	System	Warn	dnsmasq[109]: failed to access /etc/resolv.conf: No such file or directory
2000-01-01 00:00:09	System	Info	dnsmasq[109]: cleared cache
2000-01-01 00:00:23	System	Info	Authentication successful for root from 192.168.10.143

- **Time** : The date and time when the event occurred.
- **Facility** : It helps users to identify source of events such “System” or “User”
- **Severity** : Severity level that a specific event is associated such as “info”, “error”, “warning”, etc.
- **Message** : Description of the event.

Click **Refresh** button to renew the log, or click **Clear** button to clear all the record.

## CPE Mode Configuration


When CPE mode is chosen, the system can be configured as a Customer Premises Equipment(CPE). This section provides detailed explanation for users to configure in the CPE mode with help of illustrations. In the CPE mode, functions listed in the table below are also available from the Web-based GUI interface.

OPTION	System	Wireless	Advance	Utilities	Status
Functions	Operating Mode	General Setup	DMZ	Profiles Settings	System Overview
	WAN	Wireless Profile	IP Filter	Firmware Upgrade	Station Statistics
	LAN	Site Survey	MAC Filter	Network Utility	Extra Info
	DDNS		Virtual Server	Reboot	QoS Plot
	Management		Parental Control		Event Log
	Time Server		QoS		
	UPNP				
	SNMP				

*CPE Mode Functions*

## External Network Connection Network Requirement

It can be used as an Outdoor Customer Premises Equipment (CPE) to receive wireless signal over last mile application, helping WISPs deliver wireless broadband Internet service to residents and business customers. In the CPE mode, TEW-676APBO is a gateway enabled with NAT and DHCP Server functions. The wired clients connected to TEW-676APBO are in **different** subnet from those connected to Main Base Station, and, in CPE mode, it **does not** accept wireless association from wireless clients.



CPE mode network configuration

## Configure WAN Setup

There are three connection types for the WAN port : **Static IP**, **Dynamic IP**, **PPPoE** and **PPTP**.

Please click on **System** -> **WAN** and follow the below setting.

- **Mode** : By default, it's "**Static IP**". Check "Static IP", "Dynamic IP", "PPPoE" or "PPTP" to set up system WAN IP.

- ➔ **Static IP** : Users can manually setup the WAN IP address with a static IP provided by WISP.
  - ✓ **IP Address** : The IP address of the WAN port; default IP address is 192.168.1.254
  - ✓ **IP Netmask** : The Subnet mask of the WAN port; default Netmask is 255.255.255.0
  - ✓ **IP Gateway** : The default gateway of the WAN port; default Gateway is 192.168.1.1

- ➔ **Dynamic IP** : Please consult with WISP for correct wireless settings to associate with WISP AP before a dynamic IP, along with related IP settings including DNS can be available from DHCP server. If IP Address is not assigned, please double check with your wireless settings and ensure successful association. Also, you may go to "**WAN Information**" in the Overview page to click **Release** button to release IP address and click **Renew** button to renew IP address again.

- ✓ **Hostname** : The Hostname of the WAN port

- ➔ **PPPoE** : To create wireless PPPoE WAN connection to a PPPoE server in network.
  - ✓ **User Name** : Enter User Name for PPPoE connection
  - ✓ **Password** : Enter Password for PPPoE connection
  - ✓ **Reconnect Mode** :
    - **Always on** – A connection to Internet is always maintained.
    - **On Demand** – A connection to Internet is made as needed.
    - **Manual** – Click the "**Connect**" button on "**WAN Information**" in the Overview page to connect to the Internet.
  - ✓ **Idle Time** : Time to last before disconnecting PPPoE session when it is idle. Enter preferred Idle Time in minutes. Default is "0", indicates disabled. When Idle time is disabled, the "**Reconnect Mode**" will turn out "**Always on**"
  - ✓ **MTU** : By default, it's **1492** bytes. MTU stands for Maximum Transmission Unit. Consult with WISP for a correct MTU setting.



- ➔ **PPTP** : The Point-to-Point Tunneling Protocol (PPTP) mode enables the implementation of secure multi-protocol Virtual Private Networks (VPNs) through public networks.

- ✓ **IP Address** : The IP address of the WAN port
- ✓ **IP Netmask** : The Subnet mask of the WAN port
- ✓ **PPTP Server IP Address** : The IP address of the PPTP server
- ✓ **User Name** : Enter User Name for PPTP connection
- ✓ **Password** : Enter Password for PPTP connection
- ✓ **Reconnect Mode** :
  - **Always on** – A connection to Internet is always maintained.
  - **On Demand** – A connection to Internet is made as needed.
  - **Manual** – Click the “**Connect**” button on “**WAN Information**” in the Overview page to connect to the Internet.
- ✓ **Idle Time** : Time to last before disconnecting PPPoE session when it is idle. Enter preferred Idle Time in minutes. Default is “0”, indicates disabled. When Idle time is disabled, the “**Reconnect Mode**” will turn out “**Always on**”
- ✓ **MTU** : By default, it's **1460** bytes. MTU stands for Maximum Transmission Unit. Consult with WISP for a correct MTU setting.
- ✓ **MPPE Encryption** : Microsoft Point-to-Point Encryption (MPPE) encrypts data in Point-to-Point Protocol(PPP)-based dial-up connections or Point-to-Point Tunneling Protocol (PPTP) virtual private network (VPN) connections. **128-bit** key (strong) and **40-bit** key (standard) MPPE encryption schemes are supported. MPPE provides data security for the PPTP connection that is between the VPN client and the VPN server.

- **DNS** : Check “No Default DNS Server” or “Specify DNS Server IP” radial button as desired to set up system DNS.
  - ➔ **Primary** : The IP address of the primary DNS server.
  - ➔ **Secondary** : The IP address of the secondary DNS server.
- **MAC Clone** : The MAC address is a 12-digit HEX code uniquely assigned to hardware as identification. Some ISPs require you to register a MAC address in order to access to Internet. If not, you could use default MAC or clone MAC from a PC. (CPE+AP Mode does not support MAC Clone function)

- ➔ **Keep Default MAC Address** : Keep the default MAC address of WAN port on the system.
- ➔ **Clone MAC Address** : If you want to clone the MAC address of the PC, then click the **Clone MAC Address** button. The system will automatically detect your PC's MAC address.
- ➔ **Manual MAC Address** : Enter the MAC address registered with your ISP.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes



## Configure DDNS Setup

Dynamic DNS allows you to map domain name to dynamic IP address. Please click on **System -> DDNS Setup** and follow the below setting.

- **Enabled:** By default, it's **“Disable”**. The mapping domain name won't change when dynamic IP changes. The beauty of it is no need to remember the dynamic WAP IP while accessing to it.
- **Service Provider:** Select the preferred Service Provider from the drop-down list including *dyndns*, *dhs*, *ods* and *tzo*
- **Hostname:** Host Name that you register to Dynamic-DNS service and export.
- **User Name & Password:** User Name and Password are used to login DDNS service.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes.

## Configure LAN Setup

Here are the instructions for how to setup the local IP Address and Netmask. Please click on **System -> LAN** and follow the below setting.

- **LAN IP :** The administrator can manually setup the LAN IP address.
  - ➔ **IP Address :** The IP address of the LAN port; default IP address is 192.168.2.254
  - ➔ **IP Netmask :** The Subnet mask of the LAN port; default Netmask is 255.255.255.0
- **DHCP Setup :** Devices connected to the system can obtain an IP address automatically when this service is enabled.

- ➔ **DHCP :** Check **Enable** button to activate this function or **Disable** to deactivate this service.
- ➔ **Start IP / End IP:** Specify the range of IP addresses to be used by the DHCP server when assigning IP address to clients. The default range IP address is 192.168.2.10 to 192.168.2.70, the netmask is 255.255.255.0
- ➔ **DNS1 IP :** Enter IP address of the first DNS server; this field is required.
- ➔ **DNS2 IP :** Enter IP address of the second DNS server; this is optional.
- ➔ **WINS IP :** Enter IP address of the Windows Internet Name Service (WINS)


server; this is optional.

- ➔ **Domain** : Enter the domain name for this network.
- ➔ **Lease Time** : The IP addresses given out by the DHCP server will only be valid for the duration specified by the lease time. Increasing the time ensure client operation without interruptions, but could introduce potential conflicts. Lowering the lease time will avoid potential address conflicts, but might cause more interruptions to the client while it will acquire new IP addresses from the DHCP server. Default is **86400** seconds

Click **Save** button to save your changes. Click **Reboot** button to activate your changes

## Access Point Association Configure Wireless General Setting

The administrator can change the data transmission, channel and output power settings for the system. Please click on **Wireless -> General Setup** and follow the below setting.



- **Band Mode** : Select an appropriate wireless band; bands available are **801.11a** or **802.11a/n mixed mode**.
- **Tx Power** : You can adjust the output power of the system to get the appropriate coverage for your wireless network. Specify digit number between **1** to **100** (the unit is %) for your environment. If you are not sure of which setting to choose, then keep the default setting, **100%**.

When **Band Mode** select in **802.11a only mode**, the **HT(High Throughput) Physical Mode and 11n Configuration** settings should be hidden immediately.


- **Operating Mode** : By default, it's Mixed Mode.
  - ➔ **Mixed Mode** : In this mode packets are transmitted with a preamble compatible with the legacy 802.11a/g, the rest of the packet has a new format. In this mode the receiver shall be able to decode both the Mixed Mode packets and legacy packets.
  - ➔ **Green Field** : In this mode high throughput packets are transmitted without a legacy compatible part.
- **Channel Bandwidth** : The "Auto" MHz option is usually best. The other option is available for special circumstances.
- **Guard Interval** : Using "Auto" option can increase throughput. However, it can also increase error rate in some installations, due to increased sensitivity to radio-frequency reflections. Select the option that works best for your installation.
- **MCS** : This parameter represents transmission rate. By default (Auto) the fastest possible transmission rate will be selected. You have the option of selecting the speed if necessary. (Refer to **Appendix C. MCS Data Rate**)
- **MPDU Enable** : Check **Enable** button to activate this function, and **Disable** to deactivate.
- **A-MPDU** : A-MPDU (Aggregated Mac Protocol Data Unit) allows the transmissions of multiple Ethernet frames to a single location as burst of up to 64kbytes This is performed on the hardware itself. Select "Manual" to set "MPDU Density"
- **MPDU Density** : Minimum separation of MPDUs in an A-MPDU.

0	1	2	3	4	5	6	7
No Restriction	¼ µs	½ µs	1 µs	2 µs	4 µs	8 µs	16 µs

- **A-MSDU** : Aggregated Mac Service Data Unit, A-MSDU. Select **Enable** to allows aggregation for multiple MSDUs in one MPDU. Default is disabled.
- Click **Save** button to save your changes. Click **Reboot** button to activate your changes.

## Configure Wireless Advanced Setting

To achieve optimal wireless performance, it is necessary to tweak advance setting per requirements properly, not necessary higher the better or lower. The administrator can change the RTS threshold and fragmentation threshold settings for the system. Please click on **Wireless -> Advanced Setup** and follow the below setting.



- Fragment Threshold** : The Fragment Threshold is in the range of **256~2346** byte. The default is **2346** byte.  
 Each Wi-Fi packet can be divided into smaller packets, marked with a sequential fragment number and re-assemble in the receiving ends. The purpose is to make a short frame, instead of long frame, transmitting by radio in a heavy noisy environment. Because of sending smaller frames, corruptions are much less likely to occur. The pros is obvious, the cons is the overhead for transmission. So, in a clean environment, higher fragment threshold can be an option to increase throughput.  
 Fragmentation will be triggered by setting the Fragment Threshold, usually in Byte-length. Only when the frame size is over the Threshold, fragmentation will take place automatically.
- RTS Threshold** : RTS Threshold is in the range of **1~2347** byte. The default is **2347** byte.  
 The main purpose of enabling RTS by changing RTS threshold is to reduce possible collisions due to hidden wireless clients. RTS in AP will be enabled automatically if the packet size is larger than the Threshold value. By default, RTS is disabled in a normal environment supports non-jumbo frames.
- Short Preamble** : By default, it's **"Auto"**. To **Disable** is to use Long 128-bit Preamble

Synchronization field.


The preamble is used to signal "here is a train of data coming" to the receiver. The short preamble provides 72-bit Synchronization field to improve WLAN transmission efficiency with less overhead.

- Tx Burst** : By default, it's **"Enable"**. To **Disable** is to deactivate Tx Burst.  
 With TX burst enabled, AP will send many packets in a burst, without collision detection and RTS/CTS for each packet. TX Burst have better throughput but cause interference with other APs in channel.
- WMM** : By default, it's **"Disable"**. Select Enable, the packets with QoS WMM will have higher priority.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes.

## Site Survey

Use this tool to scan and locate WISP Access Points and select one to associate with. Please click on **Wireless -> Site Survey**. Below depicts an example for site survey.



- ESSID** : **Available** Extend Service Set ID of surrounding Access Points.
- MAC Address** : MAC addresses of surrounding Access Points.
- Signal** : Received signal strength of all found Access Points.
- Channel** : Channel numbers used by all found Access Points.
- Security** : Security type by all found Access Points.
- Band** : Wireless band used by all found Access Points.
- Network Type** : Network type used by all found Access Points.
- Select** : Click **"Select"** to configure settings and associate with chosen AP.

## Create Wireless Profile

The administrator can configure station profiles via this page. Please click on **Wireless -> Wireless Profile** and follow the below setting.

**Station Profile**

**System Configuration**

MAC Address : 00:11:A3:07:03:48

Profile Name :

ESSID : TRENDnet692\_5GHz

**Security Policy**

Security Type : NONE

**Save**

**Profile List**

Active	#	Profile Name	ESSID	Security Type	Delete	Edit
<input checked="" type="checkbox"/>	1	AP_Profile0	TRENDnet676	NONE	<a href="#">Delete</a>	<a href="#">Edit</a>

**Connect**

- **MAC Address** : The MAC address of the Wireless Station is displayed here.
- **Profile Name** : Set different profiles for quick connection uses.
- **ESSID** : Assign Service Set ID for the wireless system.
- **Security Type** : Select an appropriate security type for association, the Security Type can be selected in “NONE”, “OPEN”, “SHARED”, “WPA-PSK”, or “WPA2-PSK” from drop-down list; the type needs to be the same as that associated access point.
  - ➔ **OPEN / SHARED** : OPEN and SHARED require the user to set a WEP key to exchange data.

**WEP**

Key Index : 1

WEP Key 1 :

WEP Key 2 :

WEP Key 3 :

WEP Key 4 :

- ✓ **Key Index** : key index is used to designate the WEP key during data transmission. 4 different WEP keys can be entered at the same time, but only one is chosen.
- ✓ **WEP Key #** : Enter **HEX** or **ASCII** format WEP key value; the system supports up to 4 sets of WEP keys.

Key Length	Hex	ASCII
64-bit	10 characters	5 characters
128-bit	26 characters	13 characters

- ➔ **WPA-PSK (or WPA2-PSK)** : WPA (or WPA2) Algorithms, allows the system accessing the network by using the WPA-PSK protected access.

**WPA**

Cipher Suite : AES

Pre-shared Key :

- ✓ **Cipher Suite** : Select the desired cipher suite from the drop-down list; the options are **AES** and **TKIP**
- ✓ **Pre-shared Key** : Enter the information for pre-shared key; the key can be either entered as a 256-bit secret in **64 HEX** digits format, or **8 to 63 ASCII** characters.

- **Profile List** : The user can manage the created profiles for home, work or public areas. Below depict an example for Profile List



- ➔ Click **"Edit"** an exist profile on the Profile List. The field of System Configuration and Security Policy will display profile's content. Edit profile's content and then click **"Save"** button to save the profile.
- ➔ Click **"Delete"** to remove profile.
- ➔ Click and Select a profile from list, then click the **"Connect"** button to connecting to the wireless network with the profile setting. After clicking **"Connect"** button, the system should be jump to **Station Statistic Page**, you can verify connecting status on **Station Statistic Page**.


Click **Save** button to save your changes. Click **Reboot** button to activate your changes

## Access Control List

### IP Filter Setup

Allows to create deny or allow rules to filter ingress or egress packets from specific source and/or to destination IP address on wired (LAN) or Wireless (WAN) ports. Filter rules could be used to filter unicast or multicast packets on different protocols as shown in the IP Filter Setup. Important to note that IP filter rules has precedence over Virtual server rules.

Please click on **Advance -> IP Filter Setup** and follow the below setting.



- **Source Address/Mask** : Enter desired source IP address and netmask; i.e. 192.168.2.10/32.
- **Source Port** : Enter a port or a range of ports as **start:end**; i.e. port 20:80
- **Destination Address/Mask** : Enter desired destination IP address and netmask; i.e. 192.168.1.10/32
- **Destination Port** : Enter a port or a range of ports as **start:end**; i.e. port 20:80
- **In/Out** : Applies to Ingress or egress packets
- **Protocol** : Supports **TCP, UDP** or **ICMP**.
- **Listen** : Click **Yes** radial button to match TCP packets only with the SYN flag.
- **Action** : **Deny** to drop and **Pass** to allow per filter rules
- **Interface** : The interface that a filter rule applies

Click **"Save"** button to add IP filter rule. Total of **20** rules maximum allowed in the IP Filter List. All rules can be edited or removed from the List. Click **Reboot** button to activate your changes.

When you create rules in the IP Filter List, the prior rules maintain higher priority. To allow limited access from a subnet to a destination network manager needs to create allow rules first and followed by deny rules. So, if you just want one IP address to access

the system via telnet from your subnet, not others, the Example 1 demonstrates it, not rules in the Example 2.

➔ **Example 1** : Create a higher priority rule to allow IP address 192.168.2.2 Telnet access from LAN port first, and deny Telnet access from remaining IP addresses in the same subnet.

Rule	Source		Destination		I/O	Protocol	L	Act	Side
	IP/Mask	Port	IP/Mask	Port					
1	192.168.2.2/32		192.168.2.254/32	22	In	TCP	n	Pass	LAN
2	192.168.2.0/24		192.168.2.254/32	22	In	TCP	n	Deny	LAN


➔ **Example 2** : All Telnet access to the system from the IP addresses of subnet 192.168.2.x works with the rule 1 of Example 2. The rule 2 won't make any difference.

Rule	Source		Destination		I/O	Protocol	L	Action	Side
	IP/Mask	Port	IP/Mask	Port					
1	192.168.2.0/24		192.168.2.254/32	22	In	TCP	n	Deny	LAN
2	192.168.2.2/32		192.168.2.254/32	22	In	TCP	n	pass	LAN

### MAC Filter Setup

Allows to create MAC filter rules to allow or deny unicast or multicast packets from limited number of MAC addresses. Important to note that MAC filter rules have precedence over IP Filter rules.

Please click on **Advance -> MAC Filter Setup** and follow the below setting.



- **MAC Filter Rule** : By default, it's **“Disable”**. Options are **Disabled, Only Deny List MAC** or **Only Allow List MAC**. Click **Save** button to save your change.

Two ways to set the MAC Filter List:

➔ **Only Allow List MAC.**

The wireless clients in the MAC Filter List will be **allowed** to access to Access Point; All others will be denied.

➔ **Only Deny List MAC.**

The wireless clients in the MAC Filter List will be **denied** to access to Access Point; All others will be allowed.

- **MAC Address** : Enter MAC address (e.g. aa:bb:cc:00:00:0a) and click **“Add”** button, then the MAC address should display in the MAC Filter List.


There are a maximum of **20** clients allowed in this MAC Filter List. The MAC addresses of the wireless clients can be added and removed to the list using the **Add** and **Delete** buttons.

Click **Reboot** button to activate your changes



## Parental Control Setup

Parental Control allows you to block or allow specific kinds of Internet usage and traffic, such as Internet access, designated services, and websites.



Please click on **Advance** -> **Parental Control** and follow the below setting.

### Parental Control

#### Rules

Comment :

MAC Address :

Local IP :  -

Destination IP :  -

Protocol :

Local Port :

Destination Port :

Active :  Enable  Disable

#### Parental Control List

#	Comment Rule	Active	Delete	Edit
No Rule in the List!				

- **Rules** : control can be managed by a rule. Use the settings on this screen to establish an access policy.
  - ➔ **Comment** : Enter a descriptive name for this rule for identifying purposes.
  - ➔ **MAC Address** : Enter MAC address in valid MAC address format(xx:xx:xx:xx:xx:xx) and click **"Add"** button to add in the MAC group of each rule. Click **"Remove"** button can remove MAC address in the group of each rule. There are **10** MAC address maximum allowed in each rule.
  - ➔ **Local / Destination IP** : Specify local(LAN)/ destination IP addresses range required for this rule. If you specify local IP addresses range from 192.168.1.1 to 192.168.2.254. The matches a range of local IP addresses include every single IP address from the first to the last, so the example above includes everything from 192.168.1.1 to 192.168.2.254.
  - ➔ **Protocol** : Select **Any** or specify protocol(**TCP, UDP, ICMP, URL Blocking** and

**Application**) from drop-down list. When you select **ICMP** or **Layer 7 Application**, the Local(LAN)/ Destination Port cannot be used.

If you want to block websites with specific URL address or using specific keywords, enter each URL or keywords in the **"URL Blocking"** field and click **"Add"** button to add in the URL Blocking list of each rule. Click **"Remove"** button can remove URL or keywords.


- ➔ **Local Port** : Specify local port(LAN port) range required for this rule
- ➔ **Destination Port** : Specify destination port range required for this rule
- ➔ **Active** : Check **Enable** button to activate this rule, and **Disable** to deactivate.

Click **"Add"** button to add control rule to List. There are **10** rules maximum allowed in this Control List. All rules can be removed or edited on the List. Click **Reboot** button to activate your changes.

## QoS Setup

Quality of Service (QoS) refers to both a network's ability to deliver data with minimum delay, and the networking methods used to control the use of bandwidth. Without QoS, all traffic data is equally likely to be dropped when the network is congested. This can cause a reduction in network performance and make the network inadequate for time-critical application such as video-on-demand.

A classifier groups traffic into data flows according to specific criteria such as the source address, destination address, source port number, destination port number or incoming port number. For example, you can configure a classifier to select traffic from the same protocol port (such as FTP) to form a flow.



Please click on **Advance** -> **QoS** and follow the below setting.

- **Rules** : Use the rules to define the classifiers. After you define the rules, you can specify action to act upon the traffic that matches the rules
  - ➔ **Comment** : Enter a descriptive name for this rule for identifying purposes.

- ➔ **MAC Address** : Enter MAC address in valid MAC address format(xx:xx:xx:xx:xx:xx) and click **“Add”** button to add in the MAC group of each rule. Click **“Remove”** button can remove MAC address in the group of each rule. There are **10** MAC address maximum allowed in each rule.
- ➔ **Local / Destination IP** : Specify local(LAN)/ destination IP addresses range required for this rule. If you specify local IP addresses range from 192.168.1.1 to 192.168.2.254. The matches a range of local IP addresses include every single IP address from the first to the last, so the example above includes everything from 192.168.1.1 to 192.168.2.254.
- ➔ **DSCP Class** : Differentiated services code point, DSCP. Select Any or specify classify traffic from drop-down list.
 

The Per-Hop Behavior (PHB) is indicated by encoding a 6-bit value—called the Differentiated Services Code Point (DSCP)—into the 8-bit Differentiated Services (DS) field of the IP packet header. Below depicts class for DSCP.

  - ✓ **BE** : *Default* PHB, which is typically best-effort traffic
  - ✓ **EF** : *Expedited Forwarding* PHB, dedicated to low-loss, low-latency traffic
  - ✓ **AF** : *Assured Forwarding* PHB, which gives assurance of delivery under conditions. The AF behavior group defines four separate AF classes. Within each class, packets are given a drop precedence (high, medium or low). The combination of classes and drop precedence yields twelve separate DSCP encodings from **AF11** through **AF43** (see table)

DROP Precedence	Class 1	Class 2	Class 3	Class 4
Low Drop	AF11	AF21	AF31	AF41
Medium Drop	AF12	AF22	AF32	AF42
High Drop	AF13	AF23	AF33	AF43

- ➔ **Protocol** : Select **Any** or specify protocol(**TCP, UDP, ICMP, Application**) from drop-down list. When you select **ICMP** or **Layer 7 Application** , the Local/ Destination Port cannot used.
  - ➔ **Local Port** : Specify local port(LAN port) range required for this rule
  - ➔ **Destination Port** : Specify destination port range required for this rule
- **Action** : After configuring rule, a policy rule ensures that a traffic flow gets the requested treatment in the network.
    - ➔ **Remark DSCP** : Specify a new DSCP class, if you want to replace or remark the DSCP

- ➔ **Bandwidth** : Click "**Enable**" to activate function, and click "**Disable**" to deactivate function
- ➔ **Upload / Download** : Specify the bandwidth in kilobit per second (Kbps). Enter a number between **8** to **8192**, default upload is **128** Kbps, download is **1024** Kbps.

Click "**Add**" button to add QoS rule to List. There are **10** rules maximum allowed in this QoS List. All rules can be removed or edited on the List. Click **Reboot** button to activate your changes.


When you create rules on the QoS List, the previous rules have higher priority. Below depict the examples for explaining priority of QoS setup.

- **Example 1** : On this setting, the FTP has **1024** Kbps upload and **8196** Kbps download on **192.168.2.10**. The remaining IP address and other remaining protocol of IP address 192.168.2.10 only can use total bandwidth **512** Kbps bandwidth. Because rule 1's priority is higher than rule 2
- **Example 2** : On this setting, the FTP has **512** Kbps upload and **512** Kbps download on **192.168.2.10** Because rule 1's priority is higher than rule 2

## Resource Sharing

### DMZ

DMZ is commonly work with the NAT functionality as an alternative of Virtual Server(Port Forwarding) while wanting all ports of DMZ host visible to Internet users. Virtual Server rules have precedence over the DMZ rule. In order to use a range of ports available to access to different internal hosts Virtual Server rules are needed.



Please click on **Advance -> DMZ** and follow the below setting.

### DMZ Setup

#### DMZ

DMZ :  Enable  Disable

IP Address :


- **DMZ** : By default, it's "**Disable**". Check **Enable** radial button to enable DMZ.
- **IP Address** : Enter IP address of DMZ host and only one DMZ host is supported.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes.


## Virtual Server (Port Forwarding)

“Virtual Server” can also referred to as “Port Forward” as well and used interchangeably. Resources in the network can be exposed to the Internet users in a controlled manner including on-line gaming, video conferencing or others via Virtual Server setup. Don't repeat ports' usage to avoid confusion.

Suppose you want to assign ports 21-25 to one FTP, Telnet and SMTP server (A in the example), and port 80 to another (B in the example). You assign the LAN IP addresses and the ISP assigns the WAN IP address. The NAT network appears as a single host on the Internet.



Please click on **Advance** -> **Virtual Server** and follow the below setting.



- **Virtual Server** : By Default, It's “Disable”. Check **Enable** radial button to enable Virtual Server.
- **Description** : Enter appropriate message for resource sharing via Virtual Server.
- **Private IP** : Enter corresponding IP address of internal resource to share.
- **Protocol Type** : Select appropriate sessions, TCP or UDP, from shared host via multiple private ports.
- **Private Port** : A port or a range of ports may be specified as **start:end**; i.e. port 20:80
- **Public Port** : A port or a range of ports may be specified as **start:end**; i.e. port 20:80

Click “Add” button to add Virtual Server rule to List. Total of maximum **20** rules are allowed in this List. All rules can be edited or removed from the List. Click **Reboot** button to activate your changes.

While creating multiple Virtual Server rules, the prior rules have higher priority. The Virtual server rules have precedence over the DMZ one while both rules exist. Example 1 and 2 demonstrate proper usage of DMZ and Virtual Server rules.

- **Example 1** : All connections should be redirected to **192.168.2.12** while DMZ is enabled. Since Virtual Server rules have precedence over the DMZ rule all connections to TCP port 22 will be directed to TCP port 22 of 192.168.2.10 and remaining connections to port TCP **20~80** will be redirected to port TCP **20~80** of **192.168.2.11**

**DMZ Enabled : 192.168.2.12**

Rule	Protocol	Private IP	Private Port	Public Port
1	TCP	192.168.2.10	22	22
2	TCP	192.168.2.11	20:80	20:80

- **Example 2** : All connections should be redirected to **192.168.2.12** while DMZ is enabled. Since Virtual Server rules have precedence over the DMZ rule all other connections to TCP port **20~80** will be redirected to port **20~80** of **192.168.2.11**. The rule 2 won't take effect.

**DMZ Enabled : 192.168.2.12**

Rule	Protocol	Private IP	Private Port	Public Port
1	TCP	192.168.2.11	20:80	20:80
2	TCP	192.168.2.10	22	22



## System Status

This section breaks down into subsections of *System Overview*, *Station Statistics*, *Extra Information* and *Event Log*.

### Overview

Detailed information on **System**, **WAN Information**, **LAN Information** and **DHCP Server Status** can be reviewed via this page.

- **System** : Display the information of the system.

System	
Host Name	: TEW-676APBO
Operating Mode	: CPE Mode
Location	:
Description	: Wireless Outdoor PoE Access Point
Firmware Version	: Cen-CPE-N5H5R V1.0.15
Firmware Date	: 2010-12-16 02:52:11
Device Time	: 2000-01-01 00:28:01
System Up Time	: 28:01

- **System Name** : The name of the system.
- **Operating Mode** : The mode currently in service.
- **Location** : The reminding note on the geographical location of the system.
- **Description** : The reminding note of the system.
- **Firmware Version** : The current firmware version installed.
- **Firmware Date** : The build time of the firmware installed.
- **Device Time** : The current time of the system.
- **System Up Time** : The time period that system has been in service since last reboot.

- **WAN Information** : Display the information of the WAN interface.

WAN Information	
Mode	: Dynamic IPMode <b>Renew</b> <b>Release</b>
MAC Address	: 00:11:A3:07:03:48
IP Address	:
IP Netmask	:
IP Gateway	:
Primary DNS	:
Secondary DNS	:
Receive Bytes	: 704577
Receive Packets	: 3423
Transmit Bytes	: 0
Transmit Packets	: 10790

The WAN port specified **Dynamic IP**, the Release and Renew button will be show-up, click **Release** button to release IP address of WAN port, **Renew** button to renew IP address through DHCP server.

The WAN port specified **PPPoE** or **PPTP**, and the **Connect** and **DisConnect** button will be show up. Click "**Connect**" button to assigned IP address from PPPoE or PPTP server, "**DisConnect**" button to release IP address of WAN port.

- **Mode** : Supports Static, Dynamic, PPPoE and PPTP modes.
- **Reconnect Mode** : The current reconnect mode of the PPPoE or PPTP.
- **MAC Address** : The MAC address of the WAN port.
- **IP Address** : The IP address of the WAN port.
- **IP Netmask** : The IP netmask of the WAN port.
- **IP Gateway** : The gateway IP address of the WAN port.
- **Primary DNS** : The primary DNS server in service.
- **Secondary DNS** : The secondary DNS server in service.
- **Receive bytes** : The total received packets in bytes on the WAN port.
- **Receive packets** : The total received packets of the WAN port.
- **Transmit bytes** : The total transmitted packets in bytes of the WAN port.
- **Transmit packets** : The total transmitted packets of the WAN port.

- **LAN Information** : Display total received and transmitted statistics on the LAN interface.

LAN Information	
MAC Address	: 00:11:A3:07:03:47
IP Address	: 192.168.10.101
IP Netmask	: 255.255.255.0
Receive Bytes	: 139752
Receive Packets	: 1495
Transmit Bytes	: 1143453
Transmit Packets	: 1328

- ➔ **MAC Address** : The MAC address of the LAN port.
- ➔ **IP Address** : The IP address of the LAN port.
- ➔ **IP Netmask** : The IP netmask of the LAN port.
- ➔ **Receive bytes** : The total received packets in bytes on the LAN port.
- ➔ **Receive packets** : The total received packets of the LAN port.
- ➔ **Transmit bytes** : The total transmitted packets in bytes of the LAN port.
- ➔ **Transmit packets** : The total transmitted packets of the LAN port.

- **DHCP Server Status** : Users could retrieve DHCP server and DHCP clients' IP/MAC address via this field.

DHCP Server Status		
DHCP : Enable		
Start IP : 192.168.10.101		
End IP : 192.168.10.254		
DNS1 IP : 192.168.10.100		
DNS2 IP :		
WINS IP :		
Domain :		
Lease Time : 86400		
IP Address	MAC Address	Expired In
	none	

- ➔ **IP Address** : IP addresses to LAN devices by DHCP server.
- ➔ **MAC Address** : MAC addresses of LAN devices.
- ➔ **Expired In** : Shows how long the leased IP address will expire.

### Station Statistics

Link information, Transmit and Receive Statistics for the connection with AP, Below depicts an example for Station Statistics.

Station Statistics		Refresh
<b>Link Status</b>		
Status	: Disconnected	
ESSID	: TRENDnet576	
Extra Info	:	
Channel	:	
Link Speed	Tx(Mbps) 0	Rx(Mbps) 0
Link Quality	: 0%	
Signal Strength ANT0	: 0%	
Signal Strength ANT1	: 0%	
<b>HT Status</b>		
Channel Bandwidth	: 20	
Guard Interval	: long	
MCS	: 0	
<b>Transmit Statistics</b>		
Frames Transmitted Successfully	11728	
Frames Transmitted Successfully Without Retry	11728	
Frames Transmitted Successfully After Retry(s)	0	
Frames Fail To Receive ACK After All Retries	0	
RTS Frames Successfully Receive CTS	0	
RTS Frames Fail To Receive CTS	0	
<b>Receive Statistics</b>		
Frames Received Successfully	3694	
Frames Received With CRC Error	1959	
Frames Dropped Due To Out-of-Resource	0	
Duplicate Frames Received	0	

- **Link Status :**
  - ➔ **Status :** Shows the current link status. It should be “**Connected**” or “**Disconnected**”.
  - ➔ **ESSID :** Shows the current SSID, which must be the same on the wireless client and AP in order for communication to be established.
  - ➔ **BSSID :** Shows the associated BSSID, which can be used to identify the wireless access point.
  - ➔ **Extra Info :** Shows the current link status of extra information. It should be “**Link is Up**” or “**Link is Down**”,
  - ➔ **Channel :** Shows current channel and central channel, its corresponding frequency.
  - ➔ **Link Speed(Mbps) :** The data transfer speed adopted by this network. (measured in Mbits per second)
  - ➔ **Link Quality :** Shows the link quality of the system with an access point.
  - ➔ **Signal Strength ANT0/ANT1 :** Shows the wireless signal strength of the connection between system and an access point.

- **HT Status :**
  - ➔ **Channel BandWidth :** Shows the current channel bandwidth used for communication. It should be “**20**” or “**40**”
  - ➔ **Guard Interval :** Shows the current GI used for communication. It should be “**short**” or “**long**”.
  - ➔ **MCS :** Shows the current GI used for communication. It should be between **0** to **15** or **32**.

- **Transmit Statistics**
  - ➔ **Frames Transmitted Successfully:** The number of successfully transmitted frames.
  - ➔ **Frames Transmitted Successfully Without Retry:** The number of successfully transmitted frames without any retry.
  - ➔ **Frames Transmitted Successfully After Retry(s):** The number of successfully transmitted frames with one or more retries.
  - ➔ **Frames Fail To Receive ACK After All Retries:** The number of unsuccessfully transmitted frame with many retries.
  - ➔ **RTS Frames Successfully Receive CTS:** The number of successful received CTS (Clear To Send) response after this TEW-676APBO sends out the RTS (Request To Send) message.
  - ➔ **RTS Frames Fail To Receive CTS:** The number of unsuccessful received CTS

response after this TEW-676APBO sends out the RTS message.

- **Receive Statistics**
  - ➔ **Frames Received Successfully:** The number of successful received frames.
  - ➔ **Frames Received With CRC Error:** The number of received frames with CRC (Cyclical Redundancy Checking) error.
  - ➔ **Frames Dropped Due To Out-of-Resource:** The number of dropped frames.
  - ➔ **Duplicate Frames Received:** The number of duplicate frames.

### Extra Info

Users could pull out information such as Route table, ARP table, MAC table, Bridge table or STP available in the drop-down list from system. The “Refresh” button is used to retrieve latest table information.

The screenshot shows a window titled "Extra Information" with a "Refresh" button in the top right corner. Below the title bar is a dropdown menu currently set to "Netstat Information". The main content is a table with the following data:

Netstat Information						
Protocol	LiveTime	Status	SrcIP	SrcPort	DestIP	DestPort
top	65	TIME_WAIT	192.168.10.143	49518	192.168.10.101	80
top	49	TIME_WAIT	192.168.10.143	49515	192.168.10.101	80
top	119	TIME_WAIT	192.168.10.143	49530	192.168.10.101	80
top	70	TIME_WAIT	192.168.10.143	49519	192.168.10.101	80
top	61	TIME_WAIT	192.168.10.143	49522	192.168.10.101	80
top	101	TIME_WAIT	192.168.10.143	49528	192.168.10.101	80
top	86	TIME_WAIT	192.168.10.143	49523	192.168.10.101	80
top	60	TIME_WAIT	192.168.10.143	49517	192.168.10.101	80
top	111	TIME_WAIT	192.168.10.143	49528	192.168.10.101	80
top	54	TIME_WAIT	192.168.10.143	49516	192.168.10.101	80
top	75	TIME_WAIT	192.168.10.143	49520	192.168.10.101	80
top	6	TIME_WAIT	192.168.10.143	49507	192.168.10.101	80
top	1	TIME_WAIT	192.168.10.143	49508	192.168.10.101	80
top	431999	ESTABLISHED	192.168.10.143	49531	192.168.10.101	80
top	28	TIME_WAIT	192.168.10.143	49511	192.168.10.101	80
top	116	TIME_WAIT	192.168.10.143	49529	192.168.10.101	80
top	96	TIME_WAIT	192.168.10.143	49525	192.168.10.101	80
top	33	TIME_WAIT	192.168.10.143	49512	192.168.10.101	80
top	38	TIME_WAIT	192.168.10.143	49513	192.168.10.101	80
top	91	TIME_WAIT	192.168.10.143	49524	192.168.10.101	80
top	17	TIME_WAIT	192.168.10.143	49509	192.168.10.101	80
top	76	TIME_WAIT	192.168.10.143	49521	192.168.10.101	80
top	44	TIME_WAIT	192.168.10.143	49514	192.168.10.101	80
top	22	TIME_WAIT	192.168.10.143	49510	192.168.10.101	80
top	12	TIME_WAIT	192.168.10.143	49508	192.168.10.101	80

- **Netstat Information** : Select “**NetStatus Information**” on the drop-down list, the connection track list should
- NetStatus will show all connection track on the system, the information include *Protocol, Live Time, Status, Source/Destination IP address and Port.*
- **Route table information** : Select “**Route table information**” on the drop-down list to display route table.

TEW-676APBO could be used as a L2 or L3 device. It doesn't support dynamic routing protocols such as RIP or OSPF. Static routes to specific hosts, networks or default gateway are set up automatically according to the IP configuration of system's interfaces. When used as a L2 device, it could switch packets and, as L3 device, it's capable of being a gateway to route packets inward and outward.

Route Information			
Destination	Gateway	Netmask	Interface
192.168.10.0	0.0.0.0	255.255.255.0	bre0

- **ARP table Information** : Select “**ARP Table Information**” on the drop-down list to display ARP table.

ARP associates each IP address to a unique hardware address (MAC) of a device. It is important to have a unique IP address as final destination to switch packets to.

ARP Table Information		
IP Address	MAC Address	Interface
192.168.10.143	00:26:2D:5B:46:53	bre0

- **Bridge table information** : Select “**Bridge Table information**” on the drop-down list to display bridge table.

Bridge table will show Bridge ID and STP's Status on the each Ethernet bridge and its attached interfaces, the Bridge Port should be attached to some interfaces.

Bridge Table Information			
Bridge Port	Bridge ID	STP Enabled	Interface
bre0	8000.0011a3070347	no	eth2

- **Bridge MAC information** : Select “**Bridge MACs Information**” on the drop-down list to display MAC table.

This table displays local MAC addresses associated with wired or wireless interfaces,

but also remember non-local MAC addresses learned from wired or wireless interfaces.

Ageing timers will be reset when existing MAC addresses in table are learned again or added when new MAC addresses are seen from wired or wireless interfaces as well. When time runs out for a particular entry, it will be pruned from the table. In that situation, switching packet to that particular MAC address will be discontinued.

Bridge MACs Information			
Port	MAC Address	Local	Ageing Timer
LAN	00:11:a3:07:03:47	yes	0.00
LAN	00:26:2d:5b:46:53	no	0.01

- **Bridge STP Information** : Select “**Bridge STP Information**” on the drop-down list to display a list of bridge STP information.

Bridge STP Information			
<b>bre0</b>			
bridge id	8000.0011a3070347		
designated root	8000.0011a3070347		
root port	0	path cost	0
max age	20.00	bridge max age	20.00
hello time	2.00	bridge hello time	2.00
forward delay	15.00	bridge forward delay	15.00
ageing time	300.00		
hello timer	1.05	tcn timer	0.00
topology change timer	0.00	gc timer	1.05
flags			
<b>eth2 (1)</b>			
port id	8001	state	forwarding
designated root	8000.0011a3070347	path cost	100
designated bridge	8000.0011a3070347	message age timer	0.00
designated port	8001	forward delay timer	0.00
designated cost	0	hold timer	0.00
flags			

### QoS Plot

The QoS Plot show graphs which continuously represents the current data traffic on each QoS rule. The chart scale and throughput dimension (bps, Kbps, Mbps) changes dynamically according to the mean throughput value. The statistics is updated automatically every 5 seconds. The throughput statistics of QoS can be updated manually using the **Refresh** button.

QoS List			
#	Comment	Remark DSCP	Bandwidth(U/D)kbps
No QoS Rule in the List!			

### Event Log

The Event log displays system events when system is up and running. Also, it becomes very useful as a troubleshooting tool when issues are experienced in system.

System Log			
Refresh Clear			
Result			
Time	Facility	Severity	Message
2000-01-01 00:00:06	System	Info	dnsmasq[137]: started, version 2.40 cachesize 150
2000-01-01 00:00:06	System	Info	dnsmasq[137]: compile time options: no-IPv6 GNU-getopt no-RTC no-MMU no-ISC-leasefile no-DBus no-18N TFTP
2000-01-01 00:00:06	System	Warn	dnsmasq[137]: failed to access /etc/resolv.conf: No such file or directory
2000-01-01 00:00:06	System	Info	dnsmasq[137]: cleared cache
2000-01-01 00:00:23	System	Info	Authentication successful for root from 192.168.10.143
2000-01-01 00:20:12	System	Info	Change settings of Management (APCLI_EDIT_SITE_SURVEY) from 192.168.10.143

- **Time** : The date and time when the event occurred.
- **Facility** : It helps users to identify source of events such "System" or "User"
- **Severity** : Severity level that a specific event is associated such as "info", "error", "warning", etc.
- **Message** : Description of the event.

Click **Refresh** button to renew the log, or click **Clear** button to clear all the record.

### CPE + AP Mode Configuration


When CPE+AP mode is chosen, the system can be configured as a Customer Premises Equipment(CPE). This section provides detailed explanation for users to configure in the CPE+AP mode with help of illustrations. In the CPE+AP mode, functions listed in the table below are also available from the Web-based GUI interface.

OPTION	System	Wireless	Advance	Utilities	Status
Functions	Operating Mode	General Setup	DMZ	Profiles Settings	System Overview
	WAN	Advanced Setup	IP Filter	Firmware Upgrade	Station Statistics
	LAN	Repeater AP Setup	MAC Filter	Network Utility	Extra Info
	DDNS	Wireless Profile	Virtual Server	Reboot	QoS Plot
	Management	Site Survey	Parental Control		Event Log
	Time Server		QoS		
	UPNP				
	SNMP				

CPE+AP Mode Functions

### External Network Connection Network Requirement

It can be used as an Outdoor Customer Premises Equipment (CPE) to receive and repeat wireless signal over last mile application, helping WISPs deliver wireless broadband Internet service to residents and business customers. In the CPE+AP mode, TEW-676APBO is a gateway enabled with NAT and DHCP Server functions. The wired and wireless clients connected to TEW-676APBO are in **different** subnet from those connected to Main Base Station, and, in CPE+AP mode, it **accepts** wireless connections from wireless client devices.





## Configure WAN Setup

There are three connection types for the WAN port : **Static IP**, **Dynamic IP**, **PPPoE** and **PPTP**,

Please click on **System -> WAN** and follow the below setting.

- **Mode** : By default, it's "**Static IP**". Check "Static IP", "Dynamic IP", "PPPoE" or "PPTP" to set up system WAN IP.
  - ➔ **Static IP** : Users can manually setup the WAN IP address with a static IP provided by WISP.
    - ✓ **IP Address** : The IP address of the WAN port; default IP address is 192.168.1.254
    - ✓ **IP Netmask** : The Subnet mask of the WAN port; default Netmask is 255.255.255.0
    - ✓ **IP Gateway** : The default gateway of the WAN port; default Gateway is 192.168.1.1
  - ➔ **Dynamic IP** : Please consult with WISP for correct wireless settings to associate with WISP AP before a dynamic IP, along with related IP settings including DNS can be available from DHCP server. If IP Address is not assigned, please double check with your wireless settings and ensure successful association. Also, you may go to "**WAN Information**" in the Overview page to click **Release** button to


release IP address and click **Renew** button to renew IP address again.

- ✓ **Hostname** : The Hostname of the WAN port

- ➔ **PPPoE** : To create wireless PPPoE WAN connection to a PPPoE server in network.

- ✓ **User Name** : Enter User Name for PPPoE connection
- ✓ **Password** : Enter Password for PPPoE connection
- ✓ **Reconnect Mode** :
  - **Always on** – A connection to Internet is always maintained.
  - **On Demand** – A connection to Internet is made as needed.
  - **Manual** – Click the "**Connect**" button on "**WAN Information**" in the Overview page to connect to the Internet.
- ✓ **Idle Time** : Time to last before disconnecting PPPoE session when it is idle. Enter preferred Idle Time in minutes. Default is "0", indicates disabled. When Idle time is disabled, the "**Reconnect Mode**" will turn out "**Always on**"
- ✓ **MTU** : By default, it's **1492** bytes. MTU stands for Maximum Transmission Unit. Consult with WISP for a correct MTU setting.

- ➔ **PPTP** : The Point-to-Point Tunneling Protocol (PPTP) mode enables the implementation of secure multi-protocol Virtual Private Networks (VPNs) through public networks.



- ✓ **IP Address** : The IP address of the WAN port
- ✓ **IP Netmask** : The Subnet mask of the WAN port
- ✓ **PPTP Server IP Address** : The IP address of the PPTP server
- ✓ **User Name** : Enter User Name for PPTP connection
- ✓ **Password** : Enter Password for PPTP connection
- ✓ **Reconnect Mode** :
  - **Always on** – A connection to Internet is always maintained.
  - **On Demand** – A connection to Internet is made as needed.
  - **Manual** – Click the “Connect” button on “WAN Information” in the Overview page to connect to the Internet.
- ✓ **Idle Time** : Time to last before disconnecting PPPoE session when it is idle. Enter preferred Idle Time in minutes. Default is “0”, indicates disabled. When Idle time is disabled, the “Reconnect Mode” will turn out “Always on”
- ✓ **MTU** : By default, it’s **1460** bytes. MTU stands for Maximum Transmission Unit. Consult with WISP for a correct MTU setting.
- ✓ **MPPE Encryption** : Microsoft Point-to-Point Encryption (MPPE) encrypts data in Point-to-Point Protocol(PPP)-based dial-up connections or Point-to-Point Tunneling Protocol (PPTP) virtual private network (VPN) connections. **128-bit** key (strong) and **40-bit** key (standard) MPPE encryption schemes are supported. MPPE provides data security for the PPTP connection that is between the VPN client and the VPN server.


- **DNS** : Check “No Default DNS Server” or “Specify DNS Server IP” radial button as desired to set up system DNS.
  - ➔ **Primary** : The IP address of the primary DNS server.

➔ **Secondary** : The IP address of the secondary DNS server.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes

### Configure DDNS Setup

Dynamic DNS allows you to map domain name to dynamic IP address. Please click on **System -> DDNS Setup** and follow the below setting.



- **Enabled**: By default, it’s “Disable”. The mapping domain name won’t change when dynamic IP changes. The beauty of it is no need to remember the dynamic WAP IP while accessing to it.
- **Service Provider**: Select the preferred Service Provider from the drop-down list including *dyndns*, *dhs*, *ods* and *tzo*
- **Hostname**: Host Name that you register to Dynamic-DNS service and export.
- **User Name & Password**: User Name and Password are used to login DDNS service.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes

## Configure LAN Setup

Here are the instructions for how to setup the local IP Address and Netmask. Please click on **System** -> **LAN** and follow the below setting.


- **LAN IP** : The administrator can manually setup the LAN IP address.
  - ➔ **IP Address** : The IP address of the LAN port; default IP address is 192.168.2.254
  - ➔ **IP Netmask** : The Subnet mask of the LAN port; default Netmask is 255.255.255.0
- **DHCP Setup** : Devices connected to the system can obtain an IP address automatically when this service is enabled.

- ➔ **DHCP** : Check **Enable** button to activate this function or **Disable** to deactivate this service.
- ➔ **Start IP / End IP** : Specify the range of IP addresses to be used by the DHCP server when assigning IP address to clients. The default range IP address is 192.168.2.10 to 192.168.2.70, the netmask is 255.255.255.0
- ➔ **DNS1 IP** : Enter IP address of the first DNS server; this field is required.
- ➔ **DNS2 IP** : Enter IP address of the second DNS server; this is optional.
- ➔ **WINS IP** : Enter IP address of the Windows Internet Name Service (WINS) server; this is optional.
- ➔ **Domain** : Enter the domain name for this network.
- ➔ **Lease Time** : The IP addresses given out by the DHCP server will only be valid for the duration specified by the lease time. Increasing the time ensure client operation without interruptions, but could introduce potential conflicts. Lowering the lease time will avoid potential address conflicts, but might cause more interruptions to the client while it will acquire new IP addresses from the DHCP server. Default is **86400** seconds

Click **Save** button to save your changes. Click **Reboot** button to activate your changes

## Access Point Association Configure Wireless General Setting

The administrator can change the data transmission, channel and output power settings for the system. Please click on **Wireless -> General Setup** and follow the below setting.



- **Band Mode** : Select an appropriate wireless band; bands available are **801.11a** or **802.11a/n mixed** mode.
- **Transmit Rate Control** : Select the desired rate from the drop-down list; the options are auto or ranging from **6** to **54** Mbps for **802.11a**
- **Tx Power** : You can adjust the output power of the system to get the appropriate coverage for your wireless network. Specify digit number between **1** to **100** (the unit is %) for your environment. If you are not sure of which setting to choose, then keep the default setting, **100%**.

When **Band Mode** select in **802.11a only mode**, the **HT(High Throughput) Physical Mode and 11n Configuration** settings should be hidden immediately.

- **Operating Mode** : By default, it's Mixed Mode.
  - ➔ **Mixed Mode** : In this mode packets are transmitted with a preamble compatible with the legacy 802.11a/g, the rest of the packet has a new format. In this mode the receiver shall be able to decode both the Mixed Mode packets and legacy packets.
  - ➔ **Green Field** : In this mode high throughput packets are transmitted without a legacy compatible part.
- **Channel Bandwidth** : The "Auto" MHz option is usually best. The other option is available for special circumstances.
- **Guard Interval** : Using "Auto" option can increase throughput. However, it can also increase error rate in some installations, due to increased sensitivity to radio-frequency reflections. Select the option that works best for your installation.
- **MCS** : This parameter represents transmission rate. By default (Auto) the fastest possible transmission rate will be selected. You have the option of selecting the speed if necessary. (Refer to **Appendix C. MCS Data Rate**)
- **MPDU Enable** : Check **Enable** button to activate this function, and **Disable** to deactivate.
- **A-MPDU** : A-MPDU (Aggregated Mac Protocol Data Unit) allows the transmissions of multiple Ethernet frames to a single location as burst of up to 64kbytes This is performed on the hardware itself. Select "Manual" to set "MPDU Density"
- **MPDU Density** : Minimum separation of MPDUs in an A-MPDU.

0	1	2	3	4	5	6	7
No Restriction	¼ μs	½ μs	1 μs	2 μs	4 μs	8 μs	16 μs


- **A-MSDU** : Aggregated Mac Service Data Unit, A-MSDU. Select **Enable** to allows aggregation for multiple MSDUs in one MPDU. Default is disabled.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes.

## Wireless Advanced Setup

To achieve optimal wireless performance, it is necessary to tweak advance setting per requirements properly, not necessary higher the better or lower.

The administrator can change the RTS threshold and fragmentation threshold settings for the system. Please click on **Wireless -> Advanced Setup** and follow the below setting.



- **Short Slot** : By default, it's "Enable" for reducing the slot time from the standard **20 microseconds** to the **9 microsecond** short slot time

Slot time is the amount of time a device waits after a collision before retransmitting a packet. Reducing the slot time decreases the overall back-off, which increases throughput. Back-off, which is a multiple of the slot time, is the random length of time a station waits before sending a packet on the LAN. For a sender and receiver own right of the channel the shorter slot time help manage shorter wait time to re-transmit from collision because of hidden wireless clients or other causes. When collision sources can be removed sooner and other senders attempting to send are listening the channel(CSMA/CA) the owner of the channel should continue ownership and finish their transmission and release the channel. Then, following ownership of the channel will be sooner for the new pair due to shorter slot time. However, when long duration of existing collision sources and shorter slot time exist the owners might experience subsequent collisions. When adjustment to longer slot time can't improve performance then RTS/CTS could supplement and help improve performance.

- **Extra Slot Time** : Slot time is in the range of **1~255** and set in unit of *microsecond*. The default value is **9** microsecond.
- **ACK Timeout** : ACK timeout is in the range of **1~255** and set in unit of *microsecond*. The default value is **32** microsecond.

All data transmission in 802.11b/g request an "Acknowledgement" (ACK) send by receiving radio. The transmitter will resend the original packet if correspondent ACK failed to arrive within specific time interval, also refer to as "ACK Timeout".

ACK Timeout is adjustable due to the fact that distance between two radio links may vary in different deployment. ACK Timeout makes significant influence in performance of long distance radio link. If ACK Timeout is set too short, transmitter will start to "Resend" packet before ACK is received, and throughputs become low due to excessively high re-transmission.

ACK Timeout is best determined by distance between the radios, data rate of average environment. The Timeout value is calculated based on round-trip time of packet with a little tolerance, So, if experiencing re-transmissions or poor performance the ACK Timeout could be made longer to accommodate.

- **Beacon Interval** : Beacon Interval is in the range of **20~1024** and set in unit of *millisecond*. The default value is **100** msec.

Access Point (AP) in IEEE 802.11 will send out a special approximated 50-byte frame, called "Beacon". Beacon is broadcast to all the stations, provides the basic information of AP such as SSID, channel, encryption keys, signal strength, time stamp, support data rate.

All the radio stations received beacon recognizes the existence of such AP, and may proceed next actions if the information from AP matches the requirement. Beacon is sent on a periodic basis, the time interval can be adjusted.

By increasing the beacon interval, you can reduce the number of beacons and associated overhead, but that will likely delay the association and roaming process because stations scanning for available access points may miss the beacons. You can decrease the beacon interval, which increases the rate of beacons. This will make the association and roaming process very responsive; however, the network will incur additional overhead and throughput will go down.

- **DTIM Interval** : The DTIM interval is in the range of **1~255**. The default is **1**. DTIM is defined as *Delivery Traffic Indication Message*. It is used to notify the wireless stations, which support power saving mode, when to wake up to receive multicast frame. DTIM is necessary and critical in wireless environment as a mechanism to fulfill power-saving synchronization.

A DTIM interval is a count of the number of beacon frames that must occur before the access point sends the buffered multicast frames. For instance, if DTIM Interval is set to 3, then the Wi-Fi clients will expect to receive a multicast frame after receiving three Beacon frame. The higher DTIM interval will help power saving and possibly decrease wireless throughput in multicast applications.

- **Fragment Threshold** : The Fragment Threshold is in the range of **256~2346** byte. The default is **2346** byte.

Each Wi-Fi packet can be divided into smaller packets, marked with a sequential fragment number and re-assemble in the receiving ends. The purpose is to make a short frame, instead of long frame, transmitting by radio in a heavy noisy environment. Because of sending smaller frames, corruptions are much less likely to occur. The pros is obvious, the cons is the overhead for transmission. So, in a clean environment, higher fragment threshold can be an option to increase throughput.

Fragmentation will be triggered by setting the Fragment Threshold, usually in Byte-length. Only when the frame size is over the Threshold, fragmentation will take place automatically.

- **RTS Threshold** : TRTS Threshold is in the range of **1~2347** byte. The default is **2347** byte.

The main purpose of enabling RTS by changing RTS threshold is to reduce possible

Queue	Data Transmitted Clients to AP	Priority	Description
AC_BK	Background.	Low	High throughput. Bulk data that requires maximum throughput and is not time-sensitive is sent to this queue (FTP data, for example).
AC_BE	Best Effort	Medium	Medium throughput and delay. Most traditional IP data is sent to this queue
AC_VI	Video	High	Minimum delay. Time-sensitive video data is automatically sent to this queue
AC_VO	Voice	High	Time-sensitive data like VoIP and streaming media are automatically sent to this queue

collisions due to hidden wireless clients. RTS in AP will be enabled automatically if the packet size is larger than the Threshold value. By default, RTS is disabled in a normal environment supports non-jumbo frames.

- **Short Preamble** : By default, it's **"Enable"**. To **Disable** is to use Long 128-bit

Preamble Synchronization field.

The preamble is used to signal "here is a train of data coming" to the receiver. The short preamble provides 72-bit Synchronization field to improve WLAN transmission efficiency with less overhead.

- **Tx Burst** : By default, it's **"Enable"**. To **Disable** is to deactivate Tx Burst. With TX burst enabled, AP will send many packets in a burst, without collision detection and RTS/CTS for each packet. TX Burst have better throughput but cause interference with other APs in channel.
- **Pkt\_Aggregate** : By default, it's **"Enable"** Increase efficiency by aggregating multiple packets of application data into a single transmission frame. In this way, 802.11n networks can send multiple data packets with the fixed overhead cost of just a single frame.
- **WMM** : By default, it's **"Disable"**. To **Enable** is to use WMM and the WMM parameters should appears.

	Aifsn	CWMin	CWMax	Txop	ACM	AckPolicy
AC_BE	3	15	63	0	<input type="checkbox"/>	<input type="checkbox"/>
AC_BK	7	15	1023	0	<input type="checkbox"/>	<input type="checkbox"/>
AC_VI	1	7	15	94	<input type="checkbox"/>	<input type="checkbox"/>
AC_VO	1	3	7	47	<input type="checkbox"/>	<input type="checkbox"/>

	Aifsn	CWMin	CWMax	Txop	ACM
AC_BE	3	15	1023	0	<input type="checkbox"/>
AC_BK	7	15	1023	0	<input type="checkbox"/>
AC_VI	2	7	15	94	<input type="checkbox"/>
AC_VO	2	3	7	47	<input type="checkbox"/>

**WMM Parameters of Access Point** : This affects traffic flowing from the access point to the client station

Configuring QoS options consists of setting parameters on existing queues for different types of wireless traffic. You can configure different minimum and maximum wait times for the transmission of packets in each queue based on



the requirements of the media being sent. Queues automatically provide minimum transmission delay for Voice, Video, multimedia, and mission critical applications, and rely on best-effort parameters for traditional IP data.

As an Example, time-sensitive Voice & Video, and multimedia are given effectively higher priority for transmission (lower wait times for channel access), while other applications and traditional IP data which are less time-sensitive but often more data-intensive are expected to tolerate longer wait times.

- ✓ **Aifsn** : The Arbitration Inter-Frame Spacing Number specifies a wait time (in milliseconds) for data frames
- ✓ **CWmin** : Minimum Contention Window. This parameter is input to the algorithm that determines the initial random backoff wait time ("window") for retry of a transmission. The value specified here in the Minimum Contention Window is the upper limit (in milliseconds) of a range from which the initial random backoff wait time is determined.
- ✓ **CWmax** : Maximum Contention Window. The value specified here in the Maximum Contention Window is the upper limit (in milliseconds) for the doubling of the random backoff value. This doubling continues until either the data frame is sent or the Maximum Contention Window size is reached. Once the Maximum Contention Window size is reached, retries will continue until a maximum number of retries allowed is reached. Valid values for the "cwmax" are 1, 3, 7, 15, 31, 63, 127, 255, 511, or 1024. The value for "cwmax" must be higher than the value for "cwmin".
- ✓ **Txop** : Transmission Opportunity is an interval of time when a WME AP has the right to initiate transmissions onto the wireless medium (WM). This value specifies (in milliseconds) the Transmission Opportunity (TXOP) for AP; that is, the interval of time when the WMM AP has the right to initiate transmissions on the wireless network.
- ✓ **ACM** : Admission Control Mandatory, ACM only takes effect on AC\_VI and AC\_VO. When you do not click Checkbox, it means that the ACM is controlled by the connecting AP. If you click Checkbox, it means that the Client is in charge.
- ✓ **AckPolicy** : Acknowledgment Policy, WMM defines two ACK policies: **Normal ACK** and **No ACK**. Click "**Checkbox**" indicates "**No ACK**"  
When the no acknowledgment (No ACK) policy is used, the recipient does not acknowledge received packets during wireless packet exchange. This policy is suitable in the environment where communication quality is fine and interference is weak. While the No ACK policy helps improve

transmission efficiency, it can cause increased packet loss when communication quality deteriorates. This is because when this policy is used, a sender does not retransmit packets that have not been received by the recipient.

When the Normal ACK policy is used, the recipient acknowledges each received unicast packet.

➔ **WMM Parameters of Station** : This affects traffic flowing from the client station to the access point.

- ✓ **Aifsn** : The Arbitration Inter-Frame Spacing Number specifies a wait time (in milliseconds) for data frames
- ✓ **CWmin** : Minimum Contention Window. This parameter is input to the algorithm that determines the initial random backoff wait time ("window") for retry of a transmission. The value specified here in the Minimum Contention Window is the upper limit (in milliseconds) of a range from which the initial random backoff wait time is determined.
- ✓ **CWmax** : Maximum Contention Window. The value specified here in the Maximum Contention Window is the upper limit (in milliseconds) for the doubling of the random backoff value. This doubling continues until either the data frame is sent or the Maximum Contention Window size is reached. Once the Maximum Contention Window size is reached, retries will continue until a maximum number of retries allowed is reached. Valid values for the "cwmax" are 1, 3, 7, 15, 31, 63, 127, 255, 511, or 1024. The value for "cwmax" must be higher than the value for "cwmin".
- ✓ **Txop** : Transmission Opportunity is an interval of time when a WME AP has the right to initiate transmissions onto the wireless medium (WM). This value specifies (in milliseconds) the Transmission Opportunity (Txop) for AP; that is, the interval of time when the WMM AP has the right to initiate transmissions on the wireless network.
- ✓ **ACM** : Admission Control Mandatory, ACM only takes effect on AC\_VI and AC\_VO. When you do not click Checkbox, it means that the ACM is controlled by the connecting AP. If you click Checkbox, it means that the Client is in charge.


Change these settings as described here and click **Save** button to save your changes. Click **Reboot** button to activate your changes. The items in this page are for AP's RF



advanced settings and will be applied to **Repeater AP**.

### Site Survey


Use this tool to scan and locate WISP Access Points and select one to associate with. Please click on **Wireless -> Site Survey**. Below depicts an example for site survey.



- **ESSID : Available** Extend Service Set ID of surrounding Access Points.
- **MAC Address** : MAC addresses of surrounding Access Points.
- **Signal** : Received signal strength of all found Access Points.
- **Channel** : Channel numbers used by all found Access Points.
- **Security** : Security type by all found Access Points.
- **Band** : Wireless band used by all found Access Points.
- **Network Type** : Network type used by all found Access Points.
- **Select** : Click "Select" to configure settings and associate with chosen AP.

### Create Wireless Profile

The administrator can configure station profiles via this page. Please click on **Wireless -> Wireless Profile** and follow the below setting.



- **MAC Address** : The MAC address of the Wireless Station is displayed here.
- **Profile Name** : Set different profiles for quick connection uses.
- **ESSID** : Assign Service Set ID for the wireless system.
- **Lock to AP MAC** : This allows the station to always maintain connection to a particular AP with a specific MAC address. This is useful as sometimes there can be few identically named SSID's (AP's) with different MAC addresses. With AP lock on, the station will lock to MAC address and not roam between several Access Points with the same ESSID.
- **Channel/Frequency** : Select the desired channel range.
- **Security Type** : Select the desired security type from the drop-down list; the options are "NONE", "OPEN", "SHARED", "WPA-PSK" and "WPA2-PSK".
  - ➔ **OPEN / SHARED** : OPEN and SHARED require the user to set a WEP key to exchange data.

Key Length	Hex	ASCII
64-bit	10 characters	5 characters
128-bit	26 characters	13 characters

- ✓ **Key Index** : key index is used to designate the WEP key during data transmission. 4 different WEP keys can be entered at the same time, but only one is chosen.
- ✓ **WEP Key #** : Enter **HEX** or **ASCII** format WEP key value; the system supports up to 4 sets of WEP keys.
- ➔ **WPA-PSK (or WPA2-PSK)** : WPA (or WPA2) Algorithms, allows the system accessing the network by using the WPA-PSK protected access.

- ✓ **Cipher Suite** : Select the desired cipher suite from the drop-down list; the options are **AES** and **TKIP**
  - ✓ **Pre-shared Key** : Enter the information for pre-shared key; the key can be either entered as a 256-bit secret in **64 HEX** digits format, or **8 to 63 ASCII** characters.
- **Profile List** : The user can manage the created profiles for home, work or public areas. Below depict an example for Profile List

- ➔ Click **“Edit”** an exist profile on the Profile List. The field of System Configuration and Security Policy will display profile's content. Edit profile's content and then click **“Save”** button to save the profile.
- ➔ Click **“Delete”** to remove profile.
- ➔ Click and Select a profile from list, then click the **“Connect”** button to connecting to the wireless network with the profile setting. After clicking **“Connect”** button, the system should be jump to **Remote AP Page**, you can verify connecting status on **Remote AP Page**.


Change these settings as described here and click **Save** button to save your changes. Click **Reboot** button to activate your changes

## Wireless LAN Network Creation

The network manager can configure related wireless settings, **Repeater AP Setup**, **Security Settings**, and **MAC Filter Settings**.

### Repeater AP Setup

Administrators can configure ESSID, SSID broadcasting, Maximum number of client associations, security type settings and MAC Filter settings.




- **Enable Repeater AP** : By default, it's "Enable" for repeater AP. Select "Enable" to activate Repeater AP or click "Disable" to deactivate this function
- **ESSID** : Extended Service Set ID, When clients are browsing for available wireless networks, this is the SSID that will appear in the list. ESSID will determine the service type available to AP's clients associated with the specified AP.
- **Client Isolation** : By default, it's "Disable".  
Select "Enable", all clients will be isolated from each other, which means they can't reach each other.
- **Hidden SSID** : By default, it's "Disable".  
Enable this option to stop the SSID broadcast in your network. When disabled, people could easily obtain the SSID information with the site survey software and get access to the network if security is not turned on. When enabled, network security is enhanced. It's suggested to enable it after AP security settings are

archived and setting of AP's clients could make to associate to it.

- **Maximum Clients** : The default value is **32**. You can enter the number of wireless clients that can associate to a particular SSID. When the number of client is set to 5, only 5 clients at most are allowed to connect to this Repeater AP.
- **Security Type** : Select the desired security type from the drop-down list; the options are **Disable**, **WEP**, **WPA-PSK**, **WPA2-PSK**, **WPA-Enterprise**, **WPA2-Enterprise** and **WEP 802.1X**.
  - ➔ **Disable** : Data are unencrypted during transmission when this option is selected.
  - ➔ **WEP** : Wired Equivalent Privacy(WEP) is a data encryption mechanism based on a 64-bit or 128-bit shared key.

Key Length	Hex	ASCII
64-bit	10 characters	5 characters
128-bit	26 characters	13 characters



- ✓ **Authentication Method** : Enable the desire option among **OPEN**, **SHARED** or **WEPAUTO**.
- ✓ **Key Index** : key index is used to designate the WEP key during data transmission. 4 different WEP keys can be entered at the same time, but only one is chosen.
- ✓ **WEP Key #** : Enter **HEX** or **ASCII** format WEP key value; the system supports up to 4 sets of WEP keys.

➔ **WPA-PSK (or WPA2-PSK)** : WPA (or WPA2) Algorithms, allows the system accessing the network by using the WPA-PSK protected access.

The screenshot shows a configuration panel titled "WPA". It contains two fields: "Cipher Suite" with a dropdown menu currently set to "AES", and "Pre-shared Key" with an empty text input field.

- ✓ **Cipher Suite** : By default, it is **AES**. Select either AES or TKIP cipher suites
- ✓ **Pre-shared Key** : Enter the pre-shared key; the format shall go with the selected key type.
- ✓ **Group Key Update Period** : By default, it is **3600** seconds. This time interval for rekeying GTK, broadcast/multicast encryption keys, in seconds. Entering the time-length is required.

➔ **WPA-Enterprise (or WPA2-Enterprise)**: The RADIUS authentication and encryption will be both enabled if this is selected.

The screenshot shows three configuration sections:
 

- WPA General**: Cipher Suite (AES), Group Key Update Period (3600 seconds), PMK Cache Period (10 minute), and Pre-Authentication (Disable selected).
- Authentication RADIUS Server**: Authentication Server (empty), Port (1812), Shared Secret (empty), and Session Timeout (0).
- MAC Filter**: Action (Disable).

- ✓ **WPA General Settings** :
  - **Cipher Suite** : By default, it is AES. Select either AES or TKIP cipher suites
  - **Group Key Update Period** : By default, it's **3600** seconds. This time

interval for rekeying GTK, broadcast/multicast encryption keys, in seconds. Entering the time-length is required.

- **PMK Cache Period** : By default, it's 10 minutes. Set **WPA2** PMKID cache timeout period, after time out, the cached key will be deleted.
- **Pre-Authentication** : By default, it's "Disable". To Enable is use to speed up roaming before pre-authenticating IEEE 802.1X/EAP part of the full RSN authentication and key handshake before actually associating with a new AP.

- ✓ **Radius Server Settings** :
  - **IP Address** : Enter the IP address of the Authentication RADIUS server.
  - **Port** : By default, it's **1812**. The port number used to communicate with RADIUS server.
  - **Shared secret** : A secret key used between system and RADIUS server. Supports **8** to **64** characters.
  - **Session Timeout** : The Session timeout is in the range of **0~60** seconds. The default is **0** to disable re-authenticate service. Amount of time before a client will be required to re-authenticate.

➔ **WEP 802.1X** : When WEP 802.1x Authentication is enabled, please refer to the following Dynamic WEP and RADIUS settings to complete configuration.

The screenshot shows two configuration sections:
 

- 802.1x WEP**: Dynamic WEP (Enable).
- Authentication RADIUS Server**: Authentication Server (empty), Port (1812), Shared Secret (empty), and Session Timeout (0).

- ✓ **Radius Server Settings** :
  - **IP Address** : Enter the IP address of the Authentication RADIUS server.
  - **Port** : By default, it's **1812**. The port number used to communicate with RADIUS server.

- **Shared secret** : A secret key used between system and RADIUS server. Supports **8** to **64** characters.
- **Session Timeout** : The Session timeout is in the range of **0~60 seconds**. The default is **0** to disable re-authenticate service. Amount of time before a client will be required to re-authenticate.

Change these settings as described here and click **Save** button to save your changes. Click **Reboot** button to activate your changes

## Wireless MAC Filter Setup

Continue **6.3.1 Repeater AP Setup** section, the administrator can allow or reject clients to access Repeater AP.

- **MAC Filter Setup** : By default, it's "**Disable**". Options are **Disable**, **Only Deny List MAC** or **Only Allow List MAC**.

Two ways to set MAC filter rules :

➔ **Only Allow List MAC**.

The wireless clients in the "**Enable**" list will be **allowed** to access the Access Point; All others or clients in the "**Disable**" list will be **denied**.

➔ **Only Deny List MAC**.

The wireless clients in the "**Enable**" list will be **denied** to access the Access Point; All others or clients in the "**Disable**" list will be **allowed**.

- **Add a station MAC** : Enter MAC address (e.g. aa:bb:cc:00:00:0a) and click "**Add**" button, then the MAC address should display in the "**Enable**" List.

There are a maximum of **20** clients allowed in this "Enable" List. The MAC addresses of the wireless clients can be added and removed to the list using the **Add** and **Remove** buttons.

Click **Reboot** button to activate your changes

## Access Control List IP Filter Setup

Allows to create deny or allow rules to filter ingress or egress packets from specific source and/or to destination IP address on wired (LAN) or Wireless (WAN) ports. Filter rules could be used to filter unicast or multicast packets on different protocols as shown in the IP Filter Setup. Important to note that IP filter rules has precedence over Virtual server rules.

Please click on **Advance** -> **IP Filter Setup** and follow the below setting.

- **Source Address/Mask** : Enter desired source IP address and netmask; i.e. 192.168.2.10/32.
- **Source Port** : Enter a port or a range of ports as *start:end*; i.e. port 20:80
- **Destination Address/Mask** : Enter desired destination IP address and netmask; i.e. 192.168.1.10/32
- **Destination Port** : Enter a port or a range of ports as *start:end*; i.e. port 20:80
- **In/Out** : Applies to Ingress or egress packets
- **Protocol** : Supports *TCP, UDP* or *ICMP*.
- **Listen** : Click *Yes* radial button to match TCP packets only with the SYN flag.
- **Active** : *Deny* to drop and *Pass* to allow per filter rules
- **Interface** : The interface that a filter rule applies

Click "Save" button to add IP filter rule. Total of **20** rules maximum allowed in the IP Filter List. All rules can be edited or removed from the List. Click **Reboot** button to activate your changes.

When you create rules in the IP Filter List, the prior rules maintain higher priority. To allow limited access from a subnet to a destination network manager needs to create allow rules first and followed by deny rules. So, if you just want one IP address to access the system via telnet from your subnet, not others, the Example 1 demonstrates it, not rules in the Example 2.


- ➔ **Example 1** : Create a higher priority rule to allow IP address 192.168.2.2 Telnet access from LAN port first, and deny Telnet access from remaining IP addresses in the same subnet.
- ➔ **Example 2** : All Telnet access to the system from the IP addresses of subnet 192.168.2.x works with the rule 1 of Example 2. The rule 2 won't make any difference.

Rule	Source			Destination			In/Out	Prot.	Listen	Action	Side
	IP/Mask	IP/Mask	Port	IP/Mask	IP/Mask	Port					
1	192.168.10.0/24	192.168.10.254/32	22				In	TCP	n	Deny	LAN
2	192.168.10.2/32	192.168.10.254/32	22				In	TCP	n	pass	LAN

## MAC Filter Setup

Allows to create MAC filter rules to allow or deny unicast or multicast packets from limited number of MAC addresses. Important to note that MAC filter rules have precedence over IP Filter rules.

Please click on **Advance -> MAC Filter Setup** and follow the below setting.



- **MAC Filter Rule** : By default, it's "Disable". Options are **Disabled, Only Deny List MAC** or **Only Allow List MAC**. Click **Save** button to save your change.

Two ways to set the MAC Filter List:

➔ **Only Allow List MAC.**

The wireless clients in the MAC Filter List will be **allowed** to access to Access Point; All others will be denied.

➔ **Only Deny List MAC.**

The wireless clients in the MAC Filter List will be **denied** to access to Access Point; All others will be allowed.

Rule	Source			Destination			In/Out	Protocol	Listen	Action	Side
	IP/Mask	IP/Mask	Port	IP/Mask	IP/Mask	Port					
1	192.168.2.2/32	192.168.2.254/32	22				In	TCP	n	Pass	LAN
2	192.168.2.0/24	192.168.2.254/32	22				In	TCP	n	Deny	LAN


- **MAC Address** : Enter MAC address (e.g. aa:bb:cc:00:00:0a) and click “Add” button, then the MAC address should display in the MAC Filter List.

There are a maximum of **20** clients allowed in this MAC Filter List. The MAC addresses of the wireless clients can be added and removed to the list using the **Add** and **Delete** buttons.


Click **Reboot** button to activate your changes

### Parental Control Setup

Parental Control allows you to block or allow specific kinds of Internet usage and traffic, such as Internet access, designated services, and websites.



Please click on **Advance** -> **Parental Control** and follow the below setting.



- **Rules** : control can be managed by a rule. Use the settings on this screen to establish an access policy.
  - ➔ **Comment** : Enter a descriptive name for this rule for identifying purposes.
  - ➔ **MAC Address** : Enter MAC address in valid MAC address format(xx:xx:xx:xx:xx:xx) and click “Add” button to add in the MAC group of each rule. Click “Remove” button can remove MAC address in the group of each rule. There are **10** MAC address maximum allowed in each rule.
  - ➔ **Local / Destination IP** : Specify local(LAN)/ destination IP addresses range required for this rule. If you specify local IP addresses range from 192.168.1.1 to 192.168.2.254. The matches a range of local IP addresses include every single IP address from the first to the last, so the example above includes everything from 192.168.1.1 to 192.168.2.254.
  - ➔ **Protocol** : Select **Any** or specify protocol(**TCP, UDP, ICMP, URL Blocking** and **Application**) from drop-down list. When you select **ICMP** or **Layer 7**



**Application** , the Local(LAN)/ Destination Port can not used.

If you want to block websites with specific URL address or using specific keywords, enter each URL or keywords in the “**URL Blocking**” field and click “**Add**” button to add in the URL Blocking list of each rule. Click “**Remove**” button can remove URL or keywords.




- **Local Port** : Specify local port(LAN port) range required for this rule
- **Destination Port** : Specify destination port range required for this rule
- **Active** : Check **Enable** button to activate this rule, and **Disable** to deactivate.


Click “**Add**” button to add control rule to List. There are **10** rules maximum allowed in this Control List. All rules can be removed or edited on the List. Click **Reboot** button to activate your changes.

## QoS Setup

Quality of Service (QoS) refers to both a network's ability to deliver data with minimum delay, and the networking methods used to control the use of bandwidth. Without QoS, all traffic data is equally likely to be dropped when the network is congested. This can cause a reduction in network performance and make the network inadequate for time-critical application such as video-on-demand.

A classifier groups traffic into data flows according to specific criteria such as the source address, destination address, source port number, destination port number or incoming port number. For example, you can configure a classifier to select traffic from the same protocol port (such as FTP) to form a flow.





Please click on **Advance -> QoS** and follow the below setting.

**QoS Setup**

**Rules**

Comment :

MAC Address :  **Add**

**Remove**

Local IP :  -

Destination IP :  -

DSCP Class :

Protocol :

Local Port :

Destination Port :

**Action**

Remark DSCP :

Bandwidth :  Enable  Disable

Upload :  Kbits

Download :  Kbits

**Save** **Clear**

**QoS List**

#	Comment	Remark DSCP Rule	Bandwidth(U/D)	Delete	Edit
No QoS Rule in the List!					

- **Rules** : Use the rules to define the classifiers. After you define the rules, you can specify action to act upon the traffic that matches the rules
    - ➔ **Comment** : Enter a descriptive name for this rule for identifying purposes.
    - ➔ **MAC Address** : Enter MAC address in valid MAC address format(xx:xx:xx:xx:xx:xx) and click **"Add"** button to add in the MAC group of each rule. Click **"Remove"** button can remove MAC address in the group of each rule. There are **10** MAC address maximum allowed in each rule.
    - ➔ **Local / Destination IP** : Specify local(LAN)/ destination IP addresses range required for this rule. If you specify local IP addresses range from 192.168.1.1 to 192.168.2.254. The matches a range of local IP addresses include every single IP address from the first to the last, so the example above includes everything from 192.168.1.1 to 192.168.2.254.
    - ➔ **DSCP Class** : Differentiated services code point, DSCP. Select Any or specify classify traffic from drop-down list.
- The Per-Hop Behavior (PHB) is indicated by encoding a 6-bit value—called the Differentiated Services Code Point (DSCP)—into the 8-bit Differentiated Services (DS) field of the IP packet header. Below depicts class for DSCP.
- ✓ **BE** : *Default* PHB, which is typically best-effort traffic
  - ✓ **EF** : *Expedited Forwarding* PHB, dedicated to low-loss, low-latency traffic
  - ✓ **AF** : *Assured Forwarding* PHB, which gives assurance of delivery under conditions. The AF behavior group defines four separate AF classes. Within each class, packets are given a drop precedence (high, medium or low). The combination of classes and drop precedence yields twelve separate DSCP encodings from **AF11** through **AF43**

DROP Precedence	Class 1	Class 2	Class 3	Class 4
Low Drop	AF11	AF21	AF31	AF41
Medium Drop	AF12	AF22	AF32	AF42
High Drop	AF13	AF23	AF33	AF43

Rule	Source IP	Destination IP	DSCP	Protocol	Remark DSCP	Bandwidth (Up/Down)
1	192.168.2.10		ANY	FTP	NO	1024/8196
2			ANY	ANY	NO	512/512

- ➔ **Protocol** : Select **Any** or specify protocol from drop-down list. When you select **ICMP** or **Layer 7 Application** , the Source/ Destination Port cannot be used.
- ➔ **Local Port** : Specify local port(LAN port) range required for this rule
- ➔ **Destination Port** : Specify destination port range required for this rule

■ **Action** : After configuring rule, a policy rule ensures that a traffic flow gets the requested treatment in the network.

Rule	Source IP	Destination IP	DSCP	Protocol	Remark DSCP	Bandwidth (Up/Down)
1			ANY	ANY	NO	512/512
2	192.168.2.10		ANY	FTP	NO	1024/8196

- ➔ **Remark DSCP** : Specify a new DSCP class, if you want to replace or remark the DSCP
- ➔ **Bandwidth** : Click **“Enable”** to activate function, and click **“Disable”** to deactivate function
- ➔ **Upload / Download** : Specify the bandwidth in kilobit per second (Kbps). Enter a number between **8** to **8192**, default upload is **128** Kbps, download is **1024** Kbps.

Click **“Add”** button to add QoS rule to List. There are **10** rules maximum allowed in this QoS List. All rules can be removed or edited on the List. Click **Reboot** button to activate your changes.

When you create rules on the QoS List, the previous rules have higher priority. . Below depict the examples for explaining priority of QoS setup.


- ➔ **Example 1** : On this setting, the FTP has **1024** Kbps upload and **8196** Kbps download on **192.168.2.10**. The remaining IP address and other remaining protocol of IP address 192.168.2.10 only can use total bandwidth **512** Kbps

bandwidth. Because rule 1's priority is higher than rule 2


- ➔ **Example 2** : On this setting, the FTP has **512** Kbps upload and **512** Kbps download on **192.168.2.10** Because rule 1's priority is higher than rule 2

## Resource Sharing DMZ

DMZ is commonly work with the NAT functionality as an alternative of Virtual Server(Port Forwarding) while wanting all ports of DMZ host visible to Internet users. Virtual Server rules have precedence over the DMZ rule. In order to use a range of ports available to access to different internal hosts Virtual Server rules are needed.



Please click on **Advance -> DMZ** and follow the below setting.




- **DMZ** : By default, it's "Disable". Check **Enable** radial button to enable DMZ.
- **IP Address** : Enter IP address of DMZ host and only one DMZ host is supported.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes.


### Virtual Server (Port Forwarding)

"Virtual Server" can also referred to as "Port Forward" as well and used interchangeably. Resources in the network can be exposed to the Internet users in a controlled manner including on-line gaming, video conferencing or others via Virtual Server setup. Don't repeat ports' usage to avoid confusion.

Suppose you want to assign ports 21-25 to one FTP, Telnet and SMTP server (A in the example), and port 80 to another (B in the example). You assign the LAN IP addresses and the ISP assigns the WAN IP address. The NAT network appears as a single host on the Internet.



Please click on **Advance -> Virtual Server** and follow the below setting.



- **Virtual Server** : By Default, It's "Disable". Check **Enable** radial button to enable Virtual Server.
- **Description** : Enter appropriate message for resource sharing via Virtual Server.
- **Private IP** : Enter corresponding IP address of internal resource to share.
- **Protocol Type** : Select appropriate sessions, TCP or UDP, from shared host via multiple private ports.
- **Private Port** : A port or a range of ports may be specified as **start:end**; i.e. port 20:80
- **Public Port** : A port or a range of ports may be specified as **start:end**; i.e. port 20:80

Click "Add" button to add Virtual Server rule to List. Total of maximum **20** rules are allowed in this List. All rules can be edited or removed from the List. Click **Reboot** button to activate your changes.

While creating multiple Virtual Server rules, the prior rules have higher priority. The Virtual server rules have precedence over the DMZ one while both rules exist. Example 1 and 2 demonstrate proper usage of DMZ and Virtual Server rules.

- **Example 1** : All connections should be redirected to **192.168.2.12** while DMZ is enabled. Since Virtual Server rules have precedence over the DMZ rule all

connections to TCP port 22 will be directed to TCP port 22 of 192.168.2.10 and remaining connections to port TCP **20~80** will be redirected to port TCP **20~80** of **192.168.2.11**

**DMZ Enabled : 192.168.2.12**

Rule	Protocol	Private IP	Private Port	Public Port
1	TCP	192.168.2.10	22	22
2	TCP	192.168.2.11	20:80	20:80

- **Example 2** : All connections should be redirected to **192.168.2.12** while DMZ is enabled. Since Virtual Server rules have precedence over the DMZ rule all other connections to TCP port **20~80** will be redirected to port **20~80** of **192.168.2.11**. The rule 2 won't take effect.

**DMZ Enabled : 192.168.2.12**

Rule	Protocol	Private IP	Private Port	Public Port
1	TCP	192.168.2.11	20:80	20:80
2	TCP	192.168.2.10	22	22

## System Status

This section breaks down into subsections of **System Overview**, **Associated Clients Status**, **Remote AP**, **Extra Information** and **Event Log**.

### Overview

Detailed information on **System**, **WAN Information**, **LAN Information**, **Wireless Information** and **DHCP Server Status** can be reviewed via this page.

- **System** : Display the information of the system.

System	
Host Name	: TEW-676APBO
Operating Mode	: CPE + AP Mode
Location	:
Description	: Wireless Outdoor PoE Access Point
Firmware Version	: Cen-CPE-N5H5R V1.0.15
Firmware Date	: 2010-12-16 02:52:11
Device Time	: 2000-01-01 00:48:36
System Up Time	: 48:36

- **System Name** : The name of the system.
- **Operating Mode** : The mode currently in service.
- **Location** : The reminding note on the geographical location of the system.
- **Description** : The reminding note of the system.
- **Firmware Version** : The current firmware version installed.
- **Firmware Date** : The build time of the firmware installed.
- **Device Time** : The current time of the system.
- **System Up Time** : The time period that system has been in service since last reboot.

- **WAN Information** : Display the information of the WAN interface.

WAN Information	
Mode :	Dynamic IP Mode <b>Renew</b> <b>Release</b>
MAC Address :	00:11:A3:07:03:49
IP Address :	
IP Netmask :	
IP Gateway :	
Primary DNS :	
Secondary DNS :	

The WAN port specified **Dynamic IP**, the Release and Renew button will be show-up, click **Release** button to release IP address of WAN port, **Renew** button to renew IP address through DHCP server.

WAN Information	
Mode :	PPPoE Mode
Reconnect Mode :	On Demand <b>Connect</b> <b>DisConnect</b>
MAC Address :	00:11:A3:07:03:49
IP Address :	10.64.64.64
IP Netmask :	255.255.255.255
IP Gateway :	10.112.112.112
Primary DNS :	
Secondary DNS :	

The WAN port specified **PPPoE** or **PPTP**, and the **Connect** and **DisConnect** button will be show up. Click "**Connect**" button to assigned IP address from PPPoE or PPTP server, "**DisConnect**" button to release IP address of WAN port.

- ➔ **Mode** : Supports Static, Dynamic, PPPoE and PPTP modes.
- ➔ **Reconnect Mode** : The current reconnect mode of the PPPoE or PPTP.
- ➔ **MAC Address** : The MAC address of the WAN port.
- ➔ **IP Address** : The IP address of the WAN port.
- ➔ **IP Netmask** : The IP netmask of the WAN port.
- ➔ **IP Gateway** : The gateway IP address of the WAN port.
- ➔ **Primary DNS** : The primary DNS server in service.
- ➔ **Secondary DNS** : The secondary DNS server in service.

- **LAN Information** : Display total received and transmitted statistics on the LAN interface.

LAN Information	
MAC Address :	00:11:A3:07:03:47
IP Address :	192.168.10.101
IP Netmask :	255.255.255.0
Receive Bytes :	3724
Receive Packets :	30
Transmit Bytes :	11157
Transmit Packets :	31

- ➔ **MAC Address** : The MAC address of the LAN port.
- ➔ **IP Address** : The IP address of the LAN port.
- ➔ **IP Netmask** : The IP netmask of the LAN port.
- ➔ **Receive bytes** : The total received packets in bytes on the LAN port.
- ➔ **Receive packets** : The total received packets of the LAN port.
- ➔ **Transmit bytes** : The total transmitted packets in bytes of the LAN port.
- ➔ **Transmit packets** : The total transmitted packets of the LAN port.

- **Wireless Information** : Display the detailed receive and transmit statistics of Wireless interface.

Wireless Information	
AP MAC Address :	00:11:A3:07:03:48
Station MAC Address :	00:11:A3:07:03:49
Channel :	44
AP Rate :	300 Mb/s
Station Rate :	300 Mb/s
Receive Bytes :	193653
Receive Packets :	900
Transmit Bytes :	1042
Transmit Packets :	128

- ➔ **AP MAC Address** : The MAC address of the Repeater AP.
- ➔ **Station MAC Address** : The MAC address of the Wireless Client Station.
- ➔ **Channel** : The current channel on the Wireless port.
- ➔ **AP Rate** : The current Bit Rate on the Repeater AP.

- ➔ **Station Rate** : The current Bit Rate on the Wireless Client Station.
- ➔ **Receive bytes** :The total received packets in bytes on the Wireless port.
- ➔ **Receive packets** : The total received packets on the Wireless port.
- ➔ **Transmit bytes** : The total transmitted packets in bytes on the Wireless port.
- ➔ **Transmit packets** : The total transmitted packets on the Wireless port.

- **DHCP Server Status** : Users could retrieve DHCP server and DHCP clients' IP/MAC address via this field.

DHCP Server Status		
DHCP	: Enable	
Start IP	: 192.168.10.101	
End IP	: 192.168.10.254	
DNS1 IP	: 192.168.10.100	
DNS2 IP	:	
WINS IP	:	
Domain	:	
Lease Time	: 86400	
IP Address	MAC Address	Expired In
	none	

- ➔ **IP Address** : IP addresses to LAN devices by DHCP server.
- ➔ **MAC Address** : MAC addresses of LAN devices.
- ➔ **Expired In** : Shows how long the leased IP address will expire.

## Associated Clients Status

It displays ESSID, on/off Status, Security Type, total number of wireless clients associated with Repeater AP.


Wireless Clients						Refresh
AP Information						
AP	ESSID	MAC Address	Status	Security Type	Clients	
Repeater AP	TRENDnet676_Repeater	00:11:A3:07:03:48	On	Disable	0	

- **AP Information** : Highlights key Repeater AP information.
  - ➔ **AP** : Available Repeater AP.
  - ➔ **ESSID** : Display name of ESSID for Repeater AP.
  - ➔ **MAC Address** : Display MAC address for Repeater AP.
  - ➔ **Status** : On/Off
  - ➔ **Security Type** : Display chosen security type; WEP, WPA/WPA2-PSK, WPA/WPA2-Enterprise.
  - ➔ **Clients** : Display total number of wireless connections on Repeater AP.
  
- **Repeater AP Clients** : Display all associated clients.
  - ➔ **MAC Address** : MAC address of associated clients
  - ➔ **Signal Strength ANT0/ANT1** : Signal Strength of from associated clients.
  - ➔ **Bandwidth** : Channel bandwidth of from associated clients
  - ➔ **Idle Time** : Last inactive time period in seconds for a wireless connection.
  - ➔ **Connect Time** : Total connection time period in seconds for a wireless connection.
  - ➔ **Disconnect** : Click "Delete" button to manually disconnect a wireless client in a Repeater AP.



### Remote AP


SSID, MAC address, antenna 0/1 received signal strength and channel bandwidth for associated AP are available.



- **ESSID** : Shows the current ESSID, which must be the same on the wireless client and AP in order for communication to be established.
- **MAC Address** : Display MAC address of associated AP.
- **Signal Strength ANT0/ANT1** : Shows the wireless signal strength of the connection between system and an access point.
- **BandWidth** : Shows the current channel bandwidth used for communication. It should be "20" or "40"

### Extra Info

Users could pull out information such as Route table, ARP table, MAC table, Bridge table or STP available in the drop-down list from system. The "Refresh" button is used to retrieve latest table information.



- **Netstat Information** : Select "NetStatus Information" on the drop-down list, the connection track list should show-up, the list can be updated using the Refresh button.

NetStatus will show all connection track on the system, the information include

Protocol, Live Time, Status, Source/Destination IP address and Port.

- **Route table information** : Select “Route table information” on the drop-down list to display route table.

TEW-676APBO could be used as a L2 or L3 device. It doesn't support dynamic routing protocols such as RIP or OSPF. Static routes to specific hosts, networks or default gateway are set up automatically according to the IP configuration of system's interfaces. When used as a L2 device, it could switch packets and, as L3 device, it's capable of being a gateway to route packets inward and outward.

Route Information			
Destination	Gateway	Netmask	Interface
10.112.112.112	0.0.0.0	255.255.255.255	ppp0
192.168.10.0	0.0.0.0	255.255.255.0	bre0
0.0.0.0	0.0.0.0	0.0.0.0	ppp0

- **ARP table Information** : Select “ARP Table Information” on the drop-down list to display ARP table.

ARP associates each IP address to a unique hardware address (MAC) of a device. It is important to have a unique IP address as final destination to switch packets to.

ARP Table Information		
IP Address	MAC Address	Interface
192.168.10.143	00:26:2D:5B:46:53	bre0

- **Bridge table information** : Select “Bridge Table information” on the drop-down list to display bridge table.

Bridge table will show Bridge ID and STP's Status on the each Ethernet bridge and its attached interfaces, the Bridge Port should be attached to some interfaces.

Bridge Table Information			
Bridge Port	Bridge ID	STP Enabled	Interface
bre0	8000.0011a3070347	no	eth2 ra0

- **Bridge MAC information** : Select “Bridge MACs Information” on the drop-down list to display MAC table.

This table displays local MAC addresses associated with wired or wireless interfaces, but also remember non-local MAC addresses learned from wired or wireless interfaces.

Ageing timers will be reset when existing MAC addresses in table are learned again or added when new MAC addresses are seen from wired or wireless interfaces as well. When time runs out for a particular entry, it will be pruned from the table. In that situation, switching packet to that particular MAC address will be discontinued.

Bridge MACs Information			
Port	MAC Address	Local	Ageing Timer
LAN	00:11:a3:07:03:47	yes	0.00
Repeater-AP	00:11:a3:07:03:48	yes	0.00
LAN	00:26:2d:5b:46:53	no	0.09

- **Bridge STP Information** : Select “Bridge STP Information” on the drop-down list to display a list of bridge STP information.

Bridge STP Information			
<b>bre0</b>			
bridge id	8000.0011a3070347		
designated root	8000.0011a3070347		
root port	0	path cost	0
max age	20.00	bridge max age	20.00
hello time	2.00	bridge hello time	2.00
forward delay	15.00	bridge forward delay	15.00
ageing time	300.00		
hello timer	0.38	ton timer	0.00
topology change timer	0.00	gc timer	0.38
flags			
<b>eth2 (1)</b>			
port id	8001	state	forwarding
designated root	8000.0011a3070347	path cost	100
designated bridge	8000.0011a3070347	message age timer	0.00
designated port	8001	forward delay timer	0.00
designated cost	0	hold timer	0.41
flags			
<b>ra0 (2)</b>			
port id	8002	state	forwarding
designated root	8000.0011a3070347	path cost	100
designated bridge	8000.0011a3070347	message age timer	0.00
designated port	8002	forward delay timer	0.00
designated cost	0	hold timer	0.43
flags			

### QoS Plot

The QoS Plot show graphs which continuously represents the current data traffic on each QoS rule. The chart scale and throughput dimension (bps, Kbps, Mbps) changes dynamically according to the mean throughput value. The statistics is updated automatically every 5 seconds. The throughput statistics of QoS can be updated manually using the **Refresh** button.

QoS List			
#	Comment	Remark DSCP	Bandwidth(U/D)kbps
No QoS Rule In the List!			

### Event Log

The Event log displays system events when system is up and running. Also, it becomes very useful as a troubleshooting tool when issues are experienced in system.

Result			
Time	Facility	Severity	Message
2000-01-01 00:00:09	System	Info	dnsmasq[141]: started, version 2.40 cachesize 150
2000-01-01 00:00:09	System	Info	dnsmasq[141]: compile time options: no-IPv6 GNU-getopt no-RTC no-MMU no-ISC-leasefile no-DBus no-18N TFTP
2000-01-01 00:00:09	System	Warn	dnsmasq[141]: failed to access /etc/resolv.conf: No such file or directory
2000-01-01 00:00:09	System	Info	dnsmasq[141]: cleared cache
2000-01-01 00:00:23	System	Info	Authentication successful for root from 192.168.10.143

- **Time** : The date and time when the event occurred.
- **Facility** : It helps users to identify source of events such "System" or "User"
- **Severity** : Severity level that a specific event is associated such as "info", "error", "warning", etc.
- **Message** : Description of the event.

Click **Refresh** button to renew the log, or click **Clear** button to clear all the record.

### Client Bridge + Universal Repeater Configuration


When Client Bridge+Universal Repeater mode is activated, the system can be configured as an **Access Point** and **Client Station** simultaneously. This section provides information in configuring the Client Bridge+Universal Repeater mode with graphical illustrations. TEW-676APBO provides functions as stated below where they can be configured via a user-friendly web based interface.

Option	System	Wireless	Utilities	Status
Functions	Operating Mode	General Setup	Profiles Settings	System Overview
	LAN	Advanced Setup	Firmware Upgrade	Clients
	Management	Repeater AP Setup	Network Utility	Remote AP
	Time Server	Wireless Profile	Reboot	Extra Info
	SNMP	Site Survey		Event Log

#### Client Bridge+Universal Repeater Mode Functions

## External Network Connection Network Requirement

It can be used as an Client Bridge or Universal Repeater to receive and repeat wireless signal over last mile applications, helping WISPs deliver wireless broadband Internet service to new residential and business customers. In this mode, TEW-676APBO is enabled with DHCP Server functions. The wired clients of TEW-676APBO are in **the same** subnet from Main Base Station and it **accepts** wireless connections from wireless client devices.



Client Bridge + Universal Repeater mode network Configuration

## Configure LAN IP

Here are the instructions for how to setup the local IP Address and Netmask. Please click on **System -> LAN** and follow the below setting.

### LAN Setup

**Ethernet Connection Type**  
 Mode :  Static IP  Dynamic IP

**Static IP**  
 IP Address : 192.168.10.101  
 IP Netmask : 255.255.255.0  
 IP Gateway : 192.168.10.1

**DNS**  
 DNS :  No Default DNS Server  Specify DNS Server IP  
 Primary DNS :   
 Secondary DNS :

**802.1d Spanning Tree**  
 STP :  Enable  Disable

**DHCP Server**  
 DHCP :  Enable  Disable  
 Start IP : 192.168.10.101  
 End IP : 192.168.10.254  
 DNS1 IP : 192.168.10.100  
 DNS2 IP :   
 WINS IP :   
 Domain :   
 Lease Time : 86400

- **Mode** : Check either “Static IP” or “Dynamic IP” button as desired to set up the system IP of LAN port .
- ➔ **Static IP** : The administrator can manually setup the LAN IP address when static IP is available/ preferred.
  - ✓ **IP Address** : The IP address of the LAN port; default IP address is 192.168.2.254
  - ✓ **IP Netmask** : The Subnet mask of the LAN port; default Netmask is 255.255.255.0

✓ **IP Gateway** : The default gateway of the LAN port; default Gateway is 192.168.2.1

➔ **Dynamic IP** : This configuration type is applicable when the TEW-676APBO is connected to a network with the presence of a DHCP server; all related IP information will be provided by the DHCP server automatically.

**Dynamic IP**

Hostname :

- **Hostname** : The Hostname of the LAN port
- **DNS** : Check either “No Default DNS Server” or “Specify DNS Server IP” button as desired to set up the system DNS.
  - ➔ **Primary** : The IP address of the primary DNS server.
  - ➔ **Secondary** : The IP address of the secondary DNS server.
- **DHCP Setup** : Devices connected to the system can obtain an IP address automatically when this service is enabled.

**DHCP Server**

DHCP :  Enable  Disable

Start IP :

End IP :

DNS1 IP :

DNS2 IP :

WINS IP :

Domain :

Lease Time :

- ➔ **DHCP** : Check **Enable** button to activate this function or **Disable** to deactivate this service.
- ➔ **Start IP / End IP**: Specify the range of IP addresses to be used by the DHCP server when assigning IP address to clients. The default range IP address is 192.168.2.10 to 192.168.2.70, the netmask is 255.255.255.0
- ➔ **DNS1 IP** : Enter IP address of the first DNS server; this field is required.
- ➔ **DNS2 IP** : Enter IP address of the second DNS server; this is optional.
- ➔ **WINS IP** : Enter IP address of the Windows Internet Name Service (WINS) server; this is optional.
- ➔ **Domain** : Enter the domain name for this network.

➔ **Lease Time** : The IP addresses given out by the DHCP server will only be valid for the duration specified by the lease time. Increasing the time ensure client operation without interruptions, but could introduce potential conflicts. Lowering the lease time will avoid potential address conflicts, but might cause more interruptions to the client while it will acquire new IP addresses from the DHCP server. Default is **86400** seconds

Click **Save** button to save your changes. Click **Reboot** button to activate your changes

### Access Point Association Configure Wireless General Setting

The administrator can change the data transmission, channel and output power settings for the system. Please click on **Wireless -> General Setup** and follow the below setting.

**Wireless Setup**

**General Setup**

Band Mode :

Country :

Tx Power :  %

**HT Other**

HT TxStream :

HT RxStream :

**HT Physical Mode**

Operating Mode :  Mixed Mode  Green Field

Channel BandWidth :  20  20/40

Guard Interval :  Long  Auto

MCS :

Reverse Direction Grant (RDG) :  Disable  Enable

A-MSDU :  Disable  Enable

Auto Block ACK :  Disable  Enable

Decline BA Request :  Disable  Enable

- **Band Mode** : Select an appropriate wireless band; bands available are **801.11a** or **802.11a/n mixed** mode.
- **Transmit Rate Control** : Select the desired rate from the drop-down list; the options are auto or ranging from **6** to **54** Mbps for **802.11a**
- **Tx Power** : You can adjust the output power of the system to get the appropriate coverage for your wireless network. Specify digit number between **1** to **100** (the unit is %) for your environment. If you are not sure of which setting to choose, then keep the default setting, **100%**.

When **Band Mode** select in **802.11a only mode**, the **HT(High Throughput) Physical Mode and 11n Configuration** settings should be hidden immediately.

- **Operating Mode** : By default, it's Mixed Mode
  - ➔ **Mixed Mode** : In this mode packets are transmitted with a preamble compatible with the legacy 802.11a/g, the rest of the packet has a new format. In this mode the receiver shall be able to decode both the Mixed Mode packets and legacy packets.
  - ➔ **Green Field** : In this mode high throughput packets are transmitted without a legacy compatible part.
- **Channel Bandwidth** : The **"Auto"** MHz option is usually best. The other option is available for special circumstances.
- **Guard Interval** : Using **"Auto"** option can increase throughput. However, it can also increase error rate in some installations, due to increased sensitivity to radio-frequency reflections. Select the option that works best for your installation.
- **MCS** : This parameter represents transmission rate. By default (Auto) the fastest possible transmission rate will be selected. You have the option of selecting the speed if necessary. (Refer to **Appendix C. MCS Data Rate**)
- **MPDU Enable** : Check **Enable** button to activate this function, and **Disable** to deactivate.
- **A-MPDU** : A-MPDU (Aggregated Mac Protocol Data Unit) allows the transmissions of multiple Ethernet frames to a single location as burst of up to 64kbytes This is performed on the hardware itself. Select "Manual" to set "MPDU Density"
- **MPDU Density** : Minimum separation of MPDUs in an A-MPDU.


0	1	2	3	4	5	6	7
No Restriction	¼ µs	½ µs	1 µs	2 µs	4 µs	8 µs	16 µs

- **A-MSDU** : Aggregated Mac Service Data Unit, A-MSDU. Select **Enable** to allow aggregation for multiple MSDUs in one MPDU. Default is disabled.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes. The items in this page are for AP's RF general settings and will be applied to **Repeater AP**

### Wireless Advanced Setup

To achieve optimal wireless performance, it is necessary to tweak advance setting per requirements properly, not necessary higher the better or lower. The administrator can change the RTS threshold and fragmentation threshold settings for the system. Please click on **Wireless -> Advanced Setup** and follow the below setting.



- **Short Slot** : By default, it's **"Enable"** for reducing the slot time from the standard **20 microseconds** to the **9 microsecond** short slot time  
 Slot time is the amount of time a device waits after a collision before retransmitting a packet. Reducing the slot time decreases the overall back-off, which increases throughput. Back-off, which is a multiple of the slot time, is the random length of time a station waits before sending a packet on the LAN. For a sender and receiver own right of the channel the shorter slot time help manage shorter wait time to re-transmit from collision because of hidden wireless clients or other causes. When collision sources can be removed sooner and other senders attempting to send are listening the channel(CSMA/CA) the owner of the channel should continue



ownership and finish their transmission and release the channel. Then, following ownership of the channel will be sooner for the new pair due to shorter slot time. However, when long duration of existing collision sources and shorter slot time exist the owners might experience subsequent collisions. When adjustment to longer slot time can't improve performance then RTS/CTS could supplement and help improve performance.

- **Extra Slot Time** : Slot time is in the range of **1~255** and set in unit of *microsecond*. The default value is **9** microsecond.
- **ACK Timeout** : ACK timeout is in the range of **1~255** and set in unit of *microsecond*. The default value is **32** microsecond.

All data transmission in 802.11b/g request an "Acknowledgement" (ACK) send by receiving radio. The transmitter will resend the original packet if correspondent ACK failed to arrive within specific time interval, also refer to as "ACK Timeout".

ACK Timeout is adjustable due to the fact that distance between two radio links may vary in different deployment. ACK Timeout makes significant influence in performance of long distance radio link. If ACK Timeout is set too short, transmitter will start to "Resend" packet before ACK is received, and throughputs become low due to excessively high re-transmission.

ACK Timeout is best determined by distance between the radios, data rate of average environment. The Timeout value is calculated based on round-trip time of packet with a little tolerance, So, if experiencing re-transmissions or poor performance the ACK Timeout could be made longer to accommodate.

- **Beacon Interval** : Beacon Interval is in the range of **20~1024** and set in unit of *millisecond*. The default value is **100** msec.

Access Point (AP) in IEEE 802.11 will send out a special approximated 50-byte frame, called "Beacon". Beacon is broadcast to all the stations, provides the basic information of AP such as SSID, channel, encryption keys, signal strength, time stamp, support data rate.

All the radio stations received beacon recognizes the existence of such AP, and may proceed next actions if the information from AP matches the requirement. Beacon is sent on a periodic basis, the time interval can be adjusted.

By increasing the beacon interval, you can reduce the number of beacons and associated overhead, but that will likely delay the association and roaming process because stations scanning for available access points may miss the beacons. You can decrease the beacon interval, which increases the rate of beacons. This will make the association and roaming process very responsive; however, the network will incur additional overhead and throughput will go down.

- **DTIM Interval** : The DTIM interval is in the range of **1~255**. The default is **1**. DTIM is defined as *Delivery Traffic Indication Message*. It is used to notify the wireless stations, which support power saving mode, when to wake up to receive multicast frame. DTIM is necessary and critical in wireless environment as a mechanism to fulfill power-saving synchronization.
 

A DTIM interval is a count of the number of beacon frames that must occur before the access point sends the buffered multicast frames. For instance, if DTIM Interval is set to 3, then the Wi-Fi clients will expect to receive a multicast frame after receiving three Beacon frame. The higher DTIM interval will help power saving and possibly decrease wireless throughput in multicast applications.
- **Fragment Threshold** : The Fragment Threshold is in the range of **256~2346** byte. The default is **2346** byte.
 

Each Wi-Fi packet can be divided into smaller packets, marked with a sequential fragment number and re-assemble in the receiving ends. The purpose is to make a short frame, instead of long frame, transmitting by radio in a heavy noisy environment. Because of sending smaller frames, corruptions are much less likely to occur. The pros is obvious, the cons is the overhead for transmission. So, in a clean environment, higher fragment threshold can be an option to increase throughput.

Fragmentation will be triggered by setting the Fragment Threshold, usually in Byte-length. Only when the frame size is over the Threshold, fragmentation will take place automatically.
- **RTS Threshold** : TRTS Threshold is in the range of **1~2347** byte. The default is **2347** byte.
 

The main purpose of enabling RTS by changing RTS threshold is to reduce possible collisions due to hidden wireless clients. RTS in AP will be enabled automatically if the packet size is larger than the Threshold value. By default, RTS is disabled in a normal environment supports non-jumbo frames.
- **Short Preamble** : By default, it's "*Enable*". To *Disable* is to use Long 128-bit Preamble Synchronization field.
 

The preamble is used to signal "here is a train of data coming" to the receiver. The short preamble provides 72-bit Synchronization field to improve WLAN transmission efficiency with less overhead.
- **Tx Burst** : By default, it's "*Enable*". To *Disable* is to deactivate Tx Burst.
 

With TX burst enabled, AP will send many packets in a burst, without collision detection and RTS/CTS for each packet. TX Burst have better throughput but cause interference



with other APs in channel.

- **Pkt\_Aggregate** : By default, it's "Enable"

Queue	Data Transmitted AP to Clients	Priority	Description
AC_BK	Background.	Low	High throughput. Bulk data that requires maximum throughput and is not time-sensitive is sent to this queue (FTP data, for example).
AC_BE	Best Effort	Medium	Medium throughput and delay. Most traditional IP data is sent to this queue
AC_VI	Video	High	Minimum delay. Time-sensitive video data is automatically sent to this queue
AC_VO	Voice	High	Time-sensitive data like VoIP and streaming media are automatically sent to this queue

Increase efficiency by aggregating multiple packets of application data into a single transmission frame. In this way, 802.11n networks can send multiple data packets with the fixed overhead cost of just a single frame.

- **WMM** : By default, it's "Disable". To **Enable** is to use WMM and the WMM parameters should appears.

	Aifsn	CWMin	CWMax	Txop	ACM	AckPolicy
AC_BE	3	15	63	0	<input type="checkbox"/>	<input type="checkbox"/>
AC_BK	7	15	1023	0	<input type="checkbox"/>	<input type="checkbox"/>
AC_VI	1	7	15	94	<input type="checkbox"/>	<input type="checkbox"/>
AC_VO	1	3	7	47	<input type="checkbox"/>	<input type="checkbox"/>

	Aifsn	CWMin	CWMax	Txop	ACM
AC_BE	3	15	1023	0	<input type="checkbox"/>
AC_BK	7	15	1023	0	<input type="checkbox"/>
AC_VI	2	7	15	94	<input type="checkbox"/>
AC_VO	2	3	7	47	<input type="checkbox"/>

- ➔ **WMM Parameters of Access Point** : This affects traffic flowing from the access point to the client station

Configuring QoS options consists of setting parameters on existing queues for different types of wireless traffic. You can configure different minimum and maximum wait times for the transmission of packets in each queue based on the requirements of the media being sent. Queues automatically provide minimum transmission delay for Voice, Video, multimedia, and mission critical applications, and rely on best-effort parameters for traditional IP data. As an Example, time-sensitive Voice & Video, and multimedia are given effectively higher priority for transmission (lower wait times for channel access), while other applications and traditional IP data which are less time-sensitive but often more data-intensive are expected to tolerate longer wait times.

- ✓ **Aifsn** : The Arbitration Inter-Frame Spacing Number specifies a wait time (in milliseconds) for data frames
- ✓ **CWmin** : Minimum Contention Window. This parameter is input to the algorithm that determines the initial random backoff wait time ("window") for retry of a transmission. The value specified here in the Minimum Contention Window is the upper limit (in milliseconds) of a range from which the initial random backoff wait time is determined.

Queue	Data Transmitted Clients to AP	Priority	Description
AC_BK	Background.	Low	High throughput. Bulk data that requires maximum throughput and is not time-sensitive is sent to this queue (FTP data, for example).
AC_BE	Best Effort	Medium	Medium throughput and delay. Most traditional IP data is sent to this queue
AC_VI	Video	High	Minimum delay. Time-sensitive video data is automatically sent to this queue
AC_VO	Voice	High	Time-sensitive data like VoIP and streaming media are automatically sent to this queue

- ✓ **CWmax** : Maximum Contention Window. The value specified here in the Maximum Contention Window is the upper limit (in milliseconds) for the doubling of the random backoff value. This doubling continues until either the data frame is sent or the Maximum Contention Window size is reached. Once the Maximum Contention Window size is reached, retries will continue until a maximum number of retries allowed is reached. Valid values for the "cwmax" are 1, 3, 7, 15, 31, 63, 127, 255, 511, or 1024. The value for "cwmax" must be higher than the value for "cwmin".
- ✓ **Txop** : Transmission Opportunity is an interval of time when a WME AP has the right to initiate transmissions onto the wireless medium (WM). This value specifies (in milliseconds) the Transmission Opportunity (TXOP) for AP; that is, the interval of time when the WMM AP has the right to initiate transmissions on the wireless network.
- ✓ **ACM** : Admission Control Mandatory, ACM only takes effect on AC\_VI and AC\_VO. When you do not click Checkbox, it means that the ACM is controlled by the connecting AP. If you click Checkbox, it means that the Client is in charge.
- ✓ **AckPolicy** : Acknowledgment Policy, WMM defines two ACK policies: **Normal ACK** and **No ACK**. Click "**Checkbox**" indicates "**No ACK**"  
When the no acknowledgment (No ACK) policy is used, the recipient does not acknowledge received packets during wireless packet exchange. This policy is suitable in the environment where communication quality is fine and interference is weak. While the No ACK policy helps improve transmission efficiency, it can cause increased packet loss when communication quality deteriorates. This is because when this policy is

used, a sender does not retransmit packets that have not been received by the recipient.

When the Normal ACK policy is used, the recipient acknowledges each received unicast packet.

→ **WMM Parameters of Station** : This affects traffic flowing from the client station to the access point.

- ✓ **Aifsn** : The Arbitration Inter-Frame Spacing Number specifies a wait time (in milliseconds) for data frames
- ✓ **CWmin** : Minimum Contention Window. This parameter is input to the algorithm that determines the initial random back off wait time ("window") for retry of a transmission. The value specified here in the Minimum Contention Window is the upper limit (in milliseconds) of a range from which the initial random back off wait time is determined.
- ✓ **CWmax** : Maximum Contention Window. The value specified here in the Maximum Contention Window is the upper limit (in milliseconds) for the doubling of the random backoff value. This doubling continues until either the data frame is sent or the Maximum Contention Window size is reached. Once the Maximum Contention Window size is reached, retries will continue until a maximum number of retries allowed is reached. Valid values for the "cwmax" are 1, 3, 7, 15, 31, 63, 127, 255, 511, or 1024. The value for "cwmax" must be higher than the value for "cwmin".
- ✓ **Txop** : Transmission Opportunity is an interval of time when a WME AP has the right to initiate transmissions onto the wireless medium (WM). This value specifies (in milliseconds) the Transmission Opportunity (Txop) for AP; that is, the interval of time when the WMM AP has the right to initiate transmissions on the wireless network.
- ✓ **ACM** : Admission Control Mandatory, ACM only takes effect on AC\_VI and AC\_VO. When you do not click Checkbox, it means that the ACM is controlled by the connecting AP. If you click Checkbox, it means that the Client is in charge.

Change these settings as described here and click **Save** button to save your changes. Click **Reboot** button to activate your changes. The items in this page are for AP's RF advanced settings and will be applied to **Repeater AP**.

### Site Survey

Use this tool to scan and locate WISP Access Points and select one to associate with. Please click on **Wireless -> Site Survey**. Below depicts an example for site survey.

Station Site Survey							
Scan Result							
ESSID	MAC Address	Signal	Channel	Security	Band	Network Type	Select
TRENDnet802_5GHz	00:14:d1:9c:73:a4	100%	36	NONE	11a/n	Infrastructure	<a href="#">Select</a>
TRENDnet802_5GHz	00:14:d1:9c:fb:d0	100%	40	NONE	11a/n	Infrastructure	<a href="#">Select</a>
brian802gr50	00:14:d1:9b:a5:08	91%	44	WPA1PSKWPA2PSK/TKIPAES	11a/n	Infrastructure	<a href="#">Select</a>

- **ESSID : Available** Extend Service Set ID of surrounding Access Points.
- **MAC Address** : MAC addresses of surrounding Access Points.
- **Signal** : Received signal strength of all found Access Points.
- **Channel** : Channel numbers used by all found Access Points.
- **Security** : Security type by all found Access Points.
- **Band** : Wireless band used by all found Access Points.
- **Network Type** : Network type used by all found Access Points.
- **Select** : Click "Select" to configure settings and associate with chosen AP.

### Create Wireless Profile

The administrator can configure station profiles via this page. Please click on **Wireless -> Wireless Profile** and follow the below setting.

Station Profile								
<b>System Configuration</b>								
MAC Address	00:11:A3:07:03:49							
Profile Name	<input type="text"/>							
ESSID	<input type="text"/>							
Lock to AP MAC	<input type="text"/> (Optional)							
Channel/Frequency	36 (5180MHz) ▼							
<b>Security Policy</b>								
Security Type	NONE ▼							
<b>Save</b>								
<b>Profile List</b>								
Active	#	Profile Name	ESSID	MAC Address	Channel	Security Type	Delete	Edit
	1	AP_Profile0	TRENDnet876		44	NONE	<a href="#">Delete</a>	<a href="#">Edit</a>
<b>Connect</b>								

- **MAC Address** : The MAC address of the Wireless Station is displayed here.
- **Profile Name** : Set different profiles for quick connection uses.
- **ESSID** : Assign Service Set ID for the wireless system.
- **Lock to AP MAC** : This allows the station to always maintain connection to a particular AP with a specific MAC address. This is useful as sometimes there can be few identically named SSID's (AP's) with different MAC addresses. With AP lock on, the station will lock to MAC address and not roam between several Access Points with the same ESSID.
- **Channel/Frequency** : Select the desired channel range.
- **Security Type** : Select the desired security type from the drop-down list; the options are "NONE" "OPEN", "SHARED", "WPA-PSK" and "WPA2-PSK".  
 ➔ **OPEN / SHARED** : OPEN and

SHARED require the user to set a WEP key to exchange data.

- ✓ **Key Index** : key index is used to designate the WEP key during data transmission. 4 different WEP keys can be entered at the same time, but only one is chosen.
- ✓ **WEP Key #** : Enter **HEX** or **ASCII** format WEP key value; the system supports up to 4 sets of WEP keys.
- ➔ **WPA-PSK (or WPA2-PSK)** : WPA (or WPA2) Algorithms, allows the system accessing the network by using the WPA-PSK protected access.

- ✓ **Cipher Suite** : Select the desired cipher suite from the drop-down list; the options are **AES** and **TKIP**
- ✓ **Pre-shared Key** : Enter the information for pre-shared key; the key can be either entered as a 256-bit secret in **64 HEX** digits format, or **8 to 63 ASCII** characters.

- **Profile List** : The user can manage the created profiles for home, work or public areas. Below depict an example for Profile List

Active	#	Profile Name	ESSID	MAC Address	Channel	Security Type	Delete	Edit
<input checked="" type="checkbox"/>	1	AP_Profile0	TRENDnet676		44	NONE	Delete	Edit

- ➔ Click ""**Edit**"" an exist profile on the Profile List. The field of System

Configuration and Security Policy will display profile's content. Edit profile's content and then click "**Save**" button to save the profile.

- ➔ Click "**Delete**" to remove profile.
- ➔ Click and Select a profile from list, then click the "**Connect**" button to connecting to the wireless network with the profile setting. After clicking "**Connect**" button, the system should be jump to **Remote AP Page**, you can verify connecting status on **Remote AP Page**.

Change these settings as described here and click **Save** button to save your changes. Click **Reboot** button to activate your changes

Key Length	Hex	ASCII
64-bit	10 characters	5 characters
128-bit	26 characters	13 characters

### Wireless LAN Network Creation

The network manager can configure related wireless settings, **Repeater AP Setup**, **Security Settings**, and **MAC Filter Settings**.

### Repeater AP Setup

Administrators can configure ESSID, SSID broadcasting, Maximum number of client associations, security type settings and MAC Filter settings.

- **Enable Repeater AP** : By default, it's "Enable" for repeater AP. Select "Enable" to activate Repeater AP or click "Disable" to deactivate this function
- **ESSID** : Extended Service Set ID, When clients are browsing for available wireless networks, this is the SSID that will appear in the list. ESSID will determine the service type available to AP's clients associated with the specified AP.
- **Client Isolation** : By default, it's "Disable".  
Select "Enable", all clients will be isolated from each other, which means they can't reach each other.
- **Hidden SSID** : By default, it's "Disable".  
Enable this option to stop the SSID broadcast in your network. When disabled, people could easily obtain the SSID information with the site survey software and get access to the network if security is not turned on. When enabled, network security is enhanced. It's suggested to enable it after AP security settings are archived and setting of AP's clients could make to associate to it.
- **Maximum Clients** : The default value is 32. You can enter the number of wireless clients that can associate to a particular SSID. When the number of client is set to 5,

Key Length	Hex	ASCII
64-bit	10 characters	5 characters
128-bit	26 characters	13 characters

only 5 clients at most are allowed to connect to this Repeater AP.

- **Security Type** : Select the desired security type from the drop-down list; the options are **Disable**, **WEP**, **WPA-PSK**, **WPA2-PSK**, **WPA-Enterprise**, **WPA2-Enterprise** and **WEP 802.1X**.
  - ➔ **Disable** : Data are unencrypted during transmission when this option is selected.
  - ➔ **WEP** : Wired Equivalent Privacy(WEP) is a data encryption mechanism based on a 64-bit or 128-bit shared key.

**WEP**

Key Index :

WEP Key 1 :

WEP Key 2 :

WEP Key 3 :

WEP Key 4 :

- ✓ **Authentication Method** : Enable the desire option among **OPEN**, **SHARED** or **WEPAUTO**.
- ✓ **Key Index** : key index is used to designate the WEP key during data transmission. 4 different WEP keys can be entered at the same time, but only one is chosen.
- ✓ **WEP Key #** : Enter **HEX** or **ASCII** format WEP key value; the system supports up to 4 sets of WEP keys.

➔ **WPA-PSK (or WPA2-PSK)** : WPA (or WPA2) Algorithms, allows the system accessing the network by using the WPA-PSK protected access.

**WPA**

Cipher Suite :

Pre-shared Key :

- ✓ **Cipher Suite** : By default, it is **AES**. Select either AES or TKIP cipher suites
  - ✓ **Pre-shared Key** : Enter the pre-shared key; the format shall go with the selected key type.
  - ✓ **Group Key Update Period** : By default, it is **3600** seconds. This time interval for rekeying GTK, broadcast/multicast encryption keys, in seconds. Entering the time-length is required.
- ➔ **WPA-Enterprise (or WPA2-Enterprise)**: The RADIUS authentication and encryption will be both enabled if this is selected.

WPA General	
Cipher Suite :	AES
Group Key Update Period :	3600 seconds
PMK Cache Period :	10 minute
Pre-Authentication :	<input checked="" type="radio"/> Disable <input type="radio"/> Enable

Authentication RADIUS Server	
Authentication Server :	<input type="text"/>
Port :	1812
Shared Secret :	<input type="text"/>
Session Timeout :	0

✓ **WPA General Settings :**

- **Cipher Suite :** By default, it is AES. Select either AES or TKIP cipher suites
- **Group Key Update Period :** By default, it's **3600** seconds. This time interval for rekeying GTK, broadcast/multicast encryption keys, in seconds. Entering the time-length is required.
- **PMK Cache Period :** By default, it's 10 minutes. Set **WPA2** PMKID cache timeout period, after time out, the cached key will be deleted.
- **Pre-Authentication :** By default, it's "Disable". To Enable is use to speed up roaming before pre-authenticating IEEE 802.1X/EAP part of the full RSN authentication and key handshake before actually associating with a new AP.

✓ **Radius Server Settings :**

- **IP Address :** Enter the IP address of the Authentication RADIUS server.
- **Port :** By default, it's **1812**. The port number used to communicate with RADIUS server.
- **Shared secret :** A secret key used between system and RADIUS server. Supports **8** to **64** characters.
- **Session Timeout :** The Session timeout is in the range of **0~60 seconds**. The default is **0** to disable re-authenticate service. Amount of time before a client will be required to re-authenticate.

➔ **WEP 802.1X :** When WEP 802.1x Authentication is enabled, please refer to the

following Dynamic WEP and RADIUS settings to complete configuration.

802.1x WEP	
Dynamic WEP :	Enable


Authentication RADIUS Server	
Authentication Server :	<input type="text"/>
Port :	1812
Shared Secret :	<input type="text"/>
Session Timeout :	0

✓ **Radius Server Settings :**

- **IP Address :** Enter the IP address of the Authentication RADIUS server.
- **Port :** By default, it's **1812**. The port number used to communicate with RADIUS server.
- **Shared secret :** A secret key used between system and RADIUS server. Supports **8** to **64** characters.
- **Session Timeout :** The Session timeout is in the range of **0~60 seconds**. The default is **0** to disable re-authenticate service. Amount of time before a client will be required to re-authenticate.

## Wireless MAC Filter Setup

Continue **7.3.1 Repeater AP Setup** section, the administrator can allow or reject clients to access Repeater AP.



- **MAC Filter Setup** : By default, it's "**Disable**". Options are **Disable**, **Only Deny List MAC** or **Only Allow List MAC**.

Two ways to set MAC filter rules :

➔ **Only Allow List MAC.**

The wireless clients in the "**Enable**" list will be **allowed** to access the Access Point; All others or clients in the "**Disable**" list will be **denied**.

➔ **Only Deny List MAC.**

The wireless clients in the "**Enable**" list will be **denied** to access the Access Point; All others or clients in the "**Disable**" list will be **allowed**.

- **Add a station MAC** : Enter MAC address (e.g. aa:bb:cc:00:00:0a) and click "**Add**" button, then the MAC address should display in the "**Enable**" List.

There are a maximum of **20** clients allowed in this "Enable" List. The MAC addresses of the wireless clients can be added and removed to the list using the **Add** and **Remove** buttons.

Click **Reboot** button to activate your changes

## System Status

This section breaks down into subsections of **System Overview**, **Associated Clients Status**, **Remote AP**, **Extra Information** and **Event Log**.

### System Overview

Display detailed information of **System**, **Network**, **LAN and Wireless** in the System Overview page.

- **System** : Display the information of the system.

System	
Host Name	: TEW-676APBO
Operating Mode	: Client Bridge + Universal Repeater Mode
Location	:
Description	: Wireless Outdoor PoE Access Point
Firmware Version	: Cen-CPE-NSH5R V1.0.15
Firmware Date	: 2010-12-16 02:52:11
Device Time	: 2000-01-01 00:17:21
System Up Time	: 17:21

- ➔ **System Name** : The name of the system.
- ➔ **Operating Mode** : The mode currently in service.
- ➔ **Location** : The reminding note on the geographical location of the system.
- ➔ **Description** : The reminding note of the system.
- ➔ **Firmware Version** : The current firmware version installed.
- ➔ **Firmware Date** : The build time of the firmware installed.
- ➔ **Device Time** : The current time of the system.
- ➔ **System Up Time** : The time period that system has been in service since last reboot.



- **Network Information** : Display the information of the Network.

Network	
Mode	: Static IP Mode
IP Address	: 192.168.10.101
IP Netmask	: 255.255.255.0
IP Gateway	: 192.168.10.1
Primary DNS	:
Secondary DNS	:

- ➔ **Mode** : Supports Static or Dynamic modes on the LAN interface.
- ➔ **IP Address** : The management IP of system. By default, it's 192.168.2.254.
- ➔ **IP Netmask** : The network mask. By default, it's 255.255.255.0.
- ➔ **IP Gateway** : The gateway IP address and by default, it's 192.168.2.1.
- ➔ **Primary DNS** : The primary DNS server in service.
- ➔ **Secondary DNS** : The secondary DNS server in service.

- **LAN Information** : Display the detailed receive and transmit statistics of LAN interface.

LAN Information	
MAC Address	: 00:11:A3:07:03:47
Receive Bytes	: 29507
Receive Packets	: 246
Transmit Bytes	: 182779
Transmit Packets	: 263

- ➔ **MAC Address** : The MAC address of the LAN port.
- ➔ **Receive bytes** : The total received packets in bytes on the LAN port.
- ➔ **Receive packets** : The total received packets of the LAN port.
- ➔ **Transmit bytes** : The total transmitted packets in bytes of the LAN port.
- ➔ **Transmit packets** : The total transmitted packets of the LAN port.

- **Wireless Information** : Display the detailed receive and transmit statistics of Wireless interface.

Wireless Information	
AP MAC Address	: 00:11:A3:07:03:48
Station MAC Address	: 00:11:A3:07:03:49
Channel	: 44
AP Rate	: 300 Mb/s
Station Rate	: 300 Mb/s
Receive Bytes	: 2418597
Receive Packets	: 11307
Transmit Bytes	: 6038
Transmit Packets	: 1492

- ➔ **AP MAC Address** : The MAC address of the repeater AP.
- ➔ **Station MAC Address** : The MAC address of the Wireless Client Station.
- ➔ **Channel** : The current channel on the Wireless port.
- ➔ **AP Rate** : The current Bit Rate on the Repeater AP.
- ➔ **Station Rate** : The current Bit Rate on the Wireless Client Station.
- ➔ **Receive bytes** : The total received packets in bytes on the Wireless port.
- ➔ **Receive packets** : The total received packets on the Wireless port.
- ➔ **Transmit bytes** : The total transmitted packets in bytes on the Wireless port.
- ➔ **Transmit packets** : The total transmitted packets on the Wireless port.

- **DHCP Server Status** : Users could retrieve DHCP server and DHCP clients' IP/MAC address via this field.

DHCP Server Status		
DHCP	: Enable	
Start IP	: 192.168.10.101	
End IP	: 192.168.10.254	
DNS1 IP	: 192.168.10.100	
DNS2 IP	:	
WINS IP	:	
Domain	:	
Lease Time	: 86400	
IP Address	MAC Address	Expired In
	none	

- ➔ **IP Address** : IP addresses to LAN devices by DHCP server.
- ➔ **MAC Address** : MAC addresses of LAN devices.
- ➔ **Expired In** : Shows how long the leased IP address will expire.

## Associated Clients Status

It displays ESSID, on/off Status, Security Type, total number of wireless clients associated with Repeater AP.

The screenshot shows a web interface titled "Wireless Clients" with a "Refresh" button. Below the title is a section for "AP Information" containing a table with the following data:

AP	ESSID	MAC Address	Status	Security Type	Clients
Repeater AP	TRENDnet676_Repeater	00:11:A3:07:03:48	On	Disable	0

- **AP Information** : Highlights key Repeater AP information.
  - **AP** : Available Repeater AP.
  - **ESSID** : Display name of ESSID for Repeater AP.
  - **MAC Address** : Display MAC address for Repeater AP.
  - **Status** : On/Off
  - **Security Type** : Display chosen security type; WEP, WPA/WPA2-PSK, WPA/WPA2-Enterprise.
  - **Clients** : Display total number of wireless connections on Repeater AP.
  
- **Repeater AP Clients** : Display all associated clients.
  - **MAC Address** : MAC address of associated clients
  - **Signal Strength ANT0/ANT1** : Signal Strength of from associated clients.
  - **Bandwidth** : Channel bandwidth of from associated clients
  - **Idle Time** : Last inactive time period in seconds for a wireless connection.
  - **Connect Time** : Total connection time period in seconds for a wireless connection.
  - **Disconnect** : Click "Delete" button to manually disconnect a wireless client in a Repeater AP.

## Remote AP

SSID, MAC address, antenna 0/1 received signal strength and channel bandwidth for associated AP are available.

The screenshot shows a web interface titled "Remote AP" with a "Refresh" button. Below the title is a section for "Connection Information" containing a table with the following data:

ESSID	MAC Address	Signal Strength ANT0	Signal Strength ANT1	Bandwidth
No Connection AP!				

- **ESSID** : Shows the current ESSID, which must be the same on the wireless client and AP in order for communication to be established.
- **MAC Address** : Display MAC address of associated AP.
- **Signal Strength ANT0/ANT1** : Shows the wireless signal strength of the connection between system and an access point.
- **BandWidth** : Shows the current channel bandwidth used for communication. It should be "20" or "40"

## Extra Information

Users could pull out information such as Route table, ARP table, MAC table, Bridge table or STP available in the drop-down list from system. The "Refresh" button is used to retrieve latest table information.

The screenshot shows a web interface titled "Extra Information" with a "Refresh" button. Below the title is a section for "Extra Information" with a dropdown menu set to "Route Information". Below this is a table for "Route Information" with the following data:

Destination	Gateway	Netmask	Interface
192.168.10.0	0.0.0.0	255.255.255.0	bre0
0.0.0.0	192.168.10.1	0.0.0.0	bre0

- **Route table information** : Select "Route table information" on the drop-down list to display route table.

TEW-676APBO could be used as a L2 or L3 device. It doesn't support dynamic

routing protocols such as RIP or OSPF. Static routes to specific hosts, networks or default gateway are set up automatically according to the IP configuration of system's interfaces. When used as a L2 device, it could switch packets and, as L3 device, it's capable of being a gateway to route packets inward and outward.

Route Information			
Destination	Gateway	Netmask	Interface
192.168.10.0	0.0.0.0	255.255.255.0	br0
0.0.0.0	192.168.10.1	0.0.0.0	br0

- **ARP table Information :** Select “**ARP Table Information**” on the drop-down list to display ARP table.

ARP associates each IP address to a unique hardware address (MAC) of a device. It is important to have a unique IP address as final destination to switch packets to.

ARP Table Information		
IP Address	MAC Address	Interface
192.168.10.143	00:26:2D:5B:46:53	br0

- **Bridge table information :** Select “**Bridge Table information**” on the drop-down list to display bridge table.

Bridge table will show Bridge ID and STP's Status on the each Ethernet bridge and its attached interfaces, the Bridge Port should be attached to some interfaces. (e.g. eth2, ra0 and apcli0).

Bridge Table Information			
Bridge Port	Bridge ID	STP Enabled	Interface
br0	8000.0011a3070347	no	eth2 ra0 apcli0

- **Bridge MAC information :** Select “**Bridge MACs Information**” on the drop-down list to display MAC table.

This table displays local MAC addresses associated with wired or wireless interfaces, but also remember non-local MAC addresses learned from wired or wireless interfaces.

Ageing timers will be reset when existing MAC addresses in table are learned again or added when new MAC addresses are seen from wired or wireless interfaces as well. When time runs out for a particular entry, it will be pruned from the table. In that situation, switching packet to that particular MAC address will be discontinued.

Bridge MACs Information			
Port	MAC Address	Local	Ageing Timer
LAN	00:11:a3:07:03:47	yes	0.00
Repeater-AP	00:11:a3:07:03:48	yes	0.00
WLAN-Client	00:11:a3:07:03:49	yes	0.00
LAN	00:26:2d:5b:46:53	no	0.11

- **Bridge STP Information :** Select “**Bridge STP Information**” on the drop-down list to display a list of bridge STP information.

Bridge STP Information			
<b>br0</b>			
bridge id	8000.0011a3070347		
designated root	8000.0011a3070347		
root port	0	path cost	0
max age	20.00	bridge max age	20.00
hello time	2.00	bridge hello time	2.00
forward delay	15.00	bridge forward delay	15.00
ageing time	300.00		
hello timer	0.38	ton timer	0.00
topology change timer	0.00	gc timer	2.37
flags			
<b>eth2 (1)</b>			
port id	8001	state	forwarding
designated root	8000.0011a3070347	path cost	100
designated bridge	8000.0011a3070347	message age timer	0.00
designated port	8001	forward delay timer	0.00
designated cost	0	hold timer	0.41
flags			
<b>ra0 (2)</b>			
port id	8002	state	forwarding
designated root	8000.0011a3070347	path cost	100
designated bridge	8000.0011a3070347	message age timer	0.00
designated port	8002	forward delay timer	0.00
designated cost	0	hold timer	0.43
flags			
<b>apcli0 (3)</b>			
port id	8003	state	forwarding
designated root	8000.0011a3070347	path cost	100
designated bridge	8000.0011a3070347	message age timer	0.00
designated port	8003	forward delay timer	0.00
designated cost	0	hold timer	0.45
flags			

## Event Log

The Event log displays system events when system is up and running. Also, it becomes very useful as a troubleshooting tool when issues are experienced in system.

System Log				Refresh	Clear
Result					
Time	Facility	Severity	Message		
2000-01-01 00:00:06	System	Info	dnsmasq[112]: started, version 2.40 cachesize 150		
2000-01-01 00:00:06	System	Info	dnsmasq[112]: compile time options: no-IPv6 GNU-getopt no-RTC no-MMU no-ISC-leaselib no-DBus no-18N TFTP		
2000-01-01 00:00:06	System	Warn	dnsmasq[112]: failed to access /etc/resolv.conf: No such file or directory		
2000-01-01 00:00:06	System	Info	dnsmasq[112]: cleared cache		
2000-01-01 00:00:23	System	Info	Authentication successful for root from 192.168.10.143		

- **Time** : The date and time when the event occurred.
- **Facility** : It helps users to identify source of events such “System” or “User”
- **Severity** : Severity level that a specific event is associated such as “info”, “error”, “warning”, etc.
- **Message** : Description of the event.

Click **Refresh** button to renew the log, or click **Clear** button to clear all the record.

## Router AP Mode Configuration


When Router AP mode is chosen, the system can be configured as a Router with Access Point and WDS function. This section provides detailed explanation for users to configure in the Router AP mode with help of illustrations. In the Router AP mode, functions listed in the table below are also available from the Web-based GUI interface.

OPTION	System	Wireless	Advance	Utilities	Status
Functions	Operating Mode	General Setup	DMZ	Profiles Settings	System Overview
	WAN	Advanced Setup	IP Filter	Firmware Upgrade	Station Statistics
	LAN	Virtual AP Setup	MAC Filter	Network	Extra Info
	DDNS	WDS Setup	Virtual	Reboot	QoS Plot
	Managemen		Parental		Event Log
	Time Server		QoS		
	UPNP				
	SNMP				

*Router AP Mode Functions*

## External Network Connection Network Requirement

It can be used as an Router AP with WDS function. In this mode, TEW-676APBO is a gateway enabled with NAT and DHCP Server functions. The wireless clients connected to TEW-676APBO are in **different** subnet from those connected to Internet.



Router AP mode network configuration

## Configure WAN Setup

There are three connection types for the WAN port : **Static IP**, **Dynamic IP**, **PPPoE** and **PPTP**.

Please click on **System -> WAN** and follow the below setting.

- **Mode** : By default, it's "**Static IP**". Check "Static IP", "Dynamic IP", "PPPoE" or "PPTP" to set up system WAN IP.

➔ **Static IP** : Users can manually setup the WAN IP address with a static IP provided by WISP.

- ✓ **IP Address** : The IP address of the WAN port; default IP address is 192.168.1.254

- ✓ **IP Netmask** : The Subnet mask of the WAN port; default Netmask is 255.255.255.0
- ✓ **IP Gateway** : The default gateway of the WAN port; default Gateway is 192.168.1.1

➔ **Dynamic IP** : Please consult with WISP for correct wireless settings to associate with WISP AP before a dynamic IP, along with related IP settings including DNS can be available from DHCP server. If IP Address is not assigned, please double check with your wireless settings and ensure successful association. Also, you may go to "**WAN Information**" in the Overview page to click **Release** button to release IP address and click **Renew** button to renew IP address again.

- ✓ **Hostname** : The Hostname of the WAN port

➔ **PPPoE** : To create wireless PPPoE WAN connection to a PPPoE server in network.

- ✓ **User Name** : Enter User Name for PPPoE connection
- ✓ **Password** : Enter Password for PPPoE connection
- ✓ **Reconnect Mode** :
  - **Always on** – A connection to Internet is always maintained.
  - **On Demand** – A connection to Internet is made as needed.
  - **Manual** – Click the "**Connect**" button on "**WAN Information**" in the Overview page to connect to the Internet.
- ✓ **Idle Time** : Time to last before disconnecting PPPoE session when it is idle. Enter preferred Idle Time in minutes. Default is "0", indicates disabled. When Idle time is disabled, the "**Reconnect Mode**" will turn out "**Always on**"
- ✓ **MTU** : By default, it's **1492** bytes. MTU stands for Maximum Transmission Unit. Consult with WISP for a correct MTU setting.

- ➔ **PPTP** : The Point-to-Point Tunneling Protocol (PPTP) mode enables the implementation of secure multi-protocol Virtual Private Networks (VPNs) through public networks.

- ✓ **IP Address** : The IP address of the WAN port
- ✓ **IP Netmask** : The Subnet mask of the WAN port
- ✓ **PPTP Server IP Address** : The IP address of the PPTP server
- ✓ **User Name** : Enter User Name for PPTP connection
- ✓ **Password** : Enter Password for PPTP connection
- ✓ **Reconnect Mode** :
  - **Always on** – A connection to Internet is always maintained.
  - **On Demand** – A connection to Internet is made as needed.
  - **Manual** – Click the “**Connect**” button on “**WAN Information**” in the Overview page to connect to the Internet.
- ✓ **Idle Time** : Time to last before disconnecting PPPoE session when it is idle. Enter preferred Idle Time in minutes. Default is “**0**”, indicates disabled. When Idle time is disabled, the “**Reconnect Mode**” will turn out “**Always on**”
- ✓ **MTU** : By default, it's **1460** bytes. MTU stands for Maximum Transmission Unit. Consult with WISP for a correct MTU setting.
- ✓ **MPPE Encryption** : Microsoft Point-to-Point Encryption (MPPE) encrypts data in Point-to-Point Protocol(PPP)-based dial-up connections or Point-to-Point Tunneling Protocol (PPTP) virtual private network (VPN) connections. **128-bit** key (strong) and **40-bit** key (standard) MPPE encryption schemes are supported. MPPE provides data security for the PPTP connection that is between the VPN client and the VPN server.

- **DNS** : Check “No Default DNS Server” or “Specify DNS Server IP” radial button as desired to set up system DNS.
  - ➔ **Primary** : The IP address of the primary DNS server.
  - ➔ **Secondary** : The IP address of the secondary DNS server.
- **MAC Clone** : The MAC address is a 12-digit HEX code uniquely assigned to hardware as identification. Some ISPs require you to register a MAC address in order to access to Internet. If not, you could use default MAC or clone MAC from a PC.

- ➔ **Keep Default MAC Address** : Keep the default MAC address of WAN port on the system.
- ➔ **Clone MAC Address** : If you want to clone the MAC address of the PC, then click the **Clone MAC Address** button. The system will automatically detect your PC's MAC address.
- ➔ **Manual MAC Address** : Enter the MAC address registered with your ISP.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes



## Configure DDNS Setup

Dynamic DNS allows you to map domain name to dynamic IP address. Please click on **System -> DDNS Setup** and follow the below setting.

**Dynamic DNS Setup**

**DDNS**

DDNS :  Enable  Disable

Service Provider :

Hostname :

User Name :

Password :

- **Enabled:** By default, it's "**Disable**". The mapping domain name won't change when dynamic IP changes. The beauty of it is no need to remember the dynamic WAP IP while accessing to it.
- **Service Provider:** Select the preferred Service Provider from the drop-down list including *dyndns*, *dhs*, *ods* and *tzo*
- **Hostname:** Host Name that you register to Dynamic-DNS service and export.
- **User Name & Password:** User Name and Password are used to login DDNS service.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes

## Configure LAN Setup

Here are the instructions for how to setup the local IP Address and Netmask. Please click on **System -> LAN** and follow the below setting.

**LAN Setup**

**LAN IP**

IP Address :

IP Netmask :

**802.1d Spanning Tree**

STP :  Enable  Disable

**DHCP Server**

DHCP :  Enable  Disable

Start IP :

End IP :

DNS1 IP :

DNS2 IP :

WINS IP :

Domain :

Lease Time :

- **LAN IP :** The administrator can manually setup the LAN IP address.
  - ➔ **IP Address :** The IP address of the LAN port; default IP address is 192.168.2.254
  - ➔ **IP Netmask :** The Subnet mask of the LAN port; default Netmask is 255.255.255.0
- **DHCP Setup :** Devices connected to the system can obtain an IP address automatically when this service is enabled.

DHCP Server	
DHCP :	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Start IP :	192.168.10.101
End IP :	192.168.10.254
DNS1 IP :	192.168.10.100
DNS2 IP :	
WINS IP :	
Domain :	
Lease Time :	86400

- **DHCP** : Check **Enable** button to activate this function or **Disable** to deactivate this service.
- **Start IP / End IP**: Specify the range of IP addresses to be used by the DHCP server when assigning IP address to clients. The default range IP address is 192.168.2.10 to 192.168.2.70, the netmask is 255.255.255.0
- **DNS1 IP** : Enter IP address of the first DNS server; this field is required.
- **DNS2 IP** : Enter IP address of the second DNS server; this is optional.
- **WINS IP** : Enter IP address of the Windows Internet Name Service (WINS) server; this is optional.
- **Domain** : Enter the domain name for this network.
- **Lease Time** : The IP addresses given out by the DHCP server will only be valid for the duration specified by the lease time. Increasing the time ensure client operation without interruptions, but could introduce potential conflicts. Lowering the lease time will avoid potential address conflicts, but might cause more interruptions to the client while it will acquire new IP addresses from the DHCP server. Default is **86400** seconds

Click **Save** button to save your changes. Click **Reboot** button to activate your changes

## Wireless LAN Network Creation

The network manager can configure related wireless settings, **General Settings**, **Advanced Settings**, **Virtual AP(VAP) Setting**, **Security Settings**, and **MAC Filter Settings**.

## Wireless General Setup

The administrator can change the data transmission, channel and output power settings for the system. Please click on **Wireless** -> **General Setup** and follow the below setting.

Wireless Setup	
<b>General Setup</b>	
MAC Address :	00:11:A3:07:03:48
Band Mode :	802.11 a/n mixed mode
AP Isolation :	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Country :	NONE
Channel/ Frequency :	44 (5220MHz)
Tx Power :	10 %
<b>HT Other</b>	
HT Tx Stream :	2
HT Rx Stream :	2
<b>HT Physical Mode</b>	
Operating Mode :	<input checked="" type="radio"/> Mixed Mode <input type="radio"/> Green Field
Channel BandWidth :	<input type="radio"/> 20 <input checked="" type="radio"/> 20/40
Guard Interval :	<input type="radio"/> Long <input checked="" type="radio"/> Auto
MCS :	Auto
Reverse Direction Grant (RDG) :	<input type="radio"/> Disable <input checked="" type="radio"/> Enable
A-MSDU :	<input checked="" type="radio"/> Disable <input type="radio"/> Enable
Auto Block ACK :	<input type="radio"/> Disable <input checked="" type="radio"/> Enable
Decline BA Request :	<input checked="" type="radio"/> Disable <input type="radio"/> Enable
<b>Save</b>	

- **MAC Address** : The MAC address of the Wireless interface is displayed here.
- **Band Mode** : Select an appropriate wireless band; bands available are **801.11a** or **802.11a/n mixed** mode.
- **AP Isolation** : Select **Enable**, all clients will be isolated from each VAP, that means different VAP's clients can not reach to each other.
- **Transmit Rate Control** : Select the desired rate from the drop-down list; the options are auto or ranging from **6** to **54Mbps** only for **802.11a** mode.
- **Tx Power** : You can adjust the output power of the system to get the appropriate coverage for your wireless network. Specify digit numbers between **1** to **100** (the unit is %) for your environment. If you are not sure which setting to choose, then keep the default setting, **100%**.

When **Band Mode** select in **802.11a only mode**, the **HT(High Throughput)** settings should be hidden immediately.

- **HT TxStream/RxStream** : By default, it's **2**.
- **Operating Mode** : By default, it's Mixed Mode.
  - ➔ **Mixed Mode** : In this mode packets are transmitted with a preamble compatible with the legacy 802.11a/g, the rest of the packet has a new format. In this mode the receiver shall be able to decode both the Mixed Mode packets and legacy packets.
  - ➔ **Green Field** : In this mode high throughput packets are transmitted without a legacy compatible part.
- **Channel Bandwidth** : The "**20/40**" MHz option is usually best. The other option is available for special circumstances.
- **Guard Interval** : Using "**Auto**" option can increase throughput. However, it can also increase error rate in some installations, due to increased sensitivity to radio-frequency reflections. Select the option that works best for your installation.
- **MCS** : This parameter represents transmission rate. By default (Auto) the fastest possible transmission rate will be selected. You have the option of selecting the speed if necessary. (Refer to **Appendix C. MCS Data Rate**)
- **Reverse Direction Grant(RDG)** : Disable or enable reserve direction grant. Default is enabled.
- **A-MSDU** : Aggregated Mac Service Data Unit. Select **Enable** to allow aggregation for multiple MSDUs in one MPDU Default is disabled.
- **Auto Block ACK** : Disable or enable auto block ACK. Default is enabled.
- **Decline BA Request** : Disable or enable decline BA request. Default is disabled.


Change these settings as described here and click **Save** button to save your changes.

Click **Reboot** button to activate your changes. The items in this page are for AP's RF general settings and will be applied to **all VAPs** and **WDS Links**.

## Wireless Advanced Setup

To achieve optimal wireless performance, it is necessary to tweak advance setting per requirements properly, not necessary higher the better or lower.

The administrator can change the RTS threshold and fragmentation threshold settings for the system. Please click on **Wireless -> Advanced Setup** and follow the below setting.



- **Short Slot** : By default, it's "**Enable**" for reducing the slot time from the standard **20 microseconds** to the **9 microsecond** short slot time

Slot time is the amount of time a device waits after a collision before retransmitting a packet. Reducing the slot time decreases the overall back-off, which increases throughput. Back-off, which is a multiple of the slot time, is the random length of time a station waits before sending a packet on the LAN. For a sender and receiver own right of the channel the shorter slot time help manage shorter wait time to retransmit from collision because of hidden wireless clients or other causes. When collision sources can be removed sooner and other senders attempting to send are listening the channel(CSMA/CA) the owner of the channel should continue ownership and finish their transmission and release the channel. Then, following ownership of the channel will be sooner for the new pair due to shorter slot time. However, when long duration of existing collision sources and shorter slot time exist

the owners might experience subsequent collisions. When adjustment to longer slot time can't improve performance then RTS/CTS could supplement and help improve performance.

- **Extra Slot Time** : Slot time is in the range of **1~255** and set in unit of *microsecond*. The default value is **9** microsecond.
- **ACK Timeout** : ACK timeout is in the range of **1~255** and set in unit of *microsecond*. The default value is **32** microsecond.

All data transmission in 802.11b/g request an "Acknowledgement" (ACK) send by receiving radio. The transmitter will resend the original packet if correspondent ACK failed to arrive within specific time interval, also refer to as "ACK Timeout".

ACK Timeout is adjustable due to the fact that distance between two radio links may vary in different deployment. ACK Timeout makes significant influence in performance of long distance radio link. If ACK Timeout is set too short, transmitter will start to "Resend" packet before ACK is received, and throughputs become low due to excessively high re-transmission.

ACK Timeout is best determined by distance between the radios, data rate of average environment. The Timeout value is calculated based on round-trip time of packet with a little tolerance, So, if experiencing re-transmissions or poor performance the ACK Timeout could be made longer to accommodate.

- **Beacon Interval** : Beacon Interval is in the range of **20~1024** and set in unit of *millisecond*. The default value is **100** msec.

Access Point (AP) in IEEE 802.11 will send out a special approximated 50-byte frame, called "Beacon". Beacon is broadcast to all the stations, provides the basic information of AP such as SSID, channel, encryption keys, signal strength, time stamp, support data rate.

All the radio stations received beacon recognizes the existence of such AP, and may proceed next actions if the information from AP matches the requirement. Beacon is sent on a periodic basis, the time interval can be adjusted.

By increasing the beacon interval, you can reduce the number of beacons and associated overhead, but that will likely delay the association and roaming process because stations scanning for available access points may miss the beacons. You can decrease the beacon interval, which increases the rate of beacons. This will make the association and roaming process very responsive; however, the network will incur additional overhead and throughput will go down.

- **DTIM Interval** : The DTIM interval is in the range of **1~255**. The default is **1**.

DTIM is defined as *Delivery Traffic Indication Message*. It is used to notify the wireless stations, which support power saving mode, when to wake up to receive multicast frame. DTIM is necessary and critical in wireless environment as a mechanism to fulfill power-saving synchronization.

A DTIM interval is a count of the number of beacon frames that must occur before the access point sends the buffered multicast frames. For instance, if DTIM Interval is set to 3, then the Wi-Fi clients will expect to receive a multicast frame after receiving three Beacon frame. The higher DTIM interval will help power saving and possibly decrease wireless throughput in multicast applications.

- **Fragment Threshold** : The Fragment Threshold is in the range of **256~2346** byte. The default is **2346** byte.

Each Wi-Fi packet can be divided into smaller packets, marked with a sequential fragment number and re-assemble in the receiving ends. The purpose is to make a short frame, instead of long frame, transmitting by radio in a heavy noisy environment. Because of sending smaller frames, corruptions are much less likely to occur. The pros is obvious, the cons is the overhead for transmission. So, in a clean environment, higher fragment threshold can be an option to increase throughput.

Fragmentation will be triggered by setting the Fragment Threshold, usually in Byte-length. Only when the frame size is over the Threshold, fragmentation will take place automatically.

- **RTS Threshold** : TRTS Threshold is in the range of **1~2347** byte. The default is **2347** byte.

The main purpose of enabling RTS by changing RTS threshold is to reduce possible collisions due to hidden wireless clients. RTS in AP will be enabled automatically if the packet size is larger than the Threshold value. By default, RTS is disabled in a normal environment supports non-jumbo frames.

- **Short Preamble** : By default, it's "**Enable**". To **Disable** is to use Long 128-bit Preamble Synchronization field.

The preamble is used to signal "here is a train of data coming" to the receiver. The short preamble provides 72-bit Synchronization field to improve WLAN transmission efficiency with less overhead.

- **Tx Burst** : By default, it's "**Enable**". To **Disable** is to deactivate Tx Burst.

With TX burst enabled, AP will send many packets in a burst, without collision detection and RTS/CTS for each packet. TX Burst have better throughput but cause interference with other APs in channel.

■ **Pkt\_Aggregate** : By default, it's *“Enable”*

Increase efficiency by aggregating multiple packets of application data into a single transmission frame. In this way, 802.11n networks can send multiple data packets

Queue	Data Transmitted AP to Clients	Priority	Description
AC_BK	Background.	Low	High throughput. Bulk data that requires maximum throughput and is not time-sensitive is sent to this queue (FTP data, for example).
AC_BE	Best Effort	Medium	Medium throughput and delay. Most traditional IP data is sent to this queue
AC_VI	Video	High	Minimum delay. Time-sensitive video data is automatically sent to this queue
AC_VO	Voice	High	Time-sensitive data like VoIP and streaming media are automatically sent to this queue

with the fixed overhead cost of just a single frame.

■ **WMM** : By default, it's *“Disable”*. To *Enable* is to use WMM and the WMM parameters should appears.

	Aifsn	CWMin	CWMax	Txop	ACM	AckPolicy
AC_BE	3	15	63	0	<input type="checkbox"/>	<input type="checkbox"/>
AC_BK	7	15	1023	0	<input type="checkbox"/>	<input type="checkbox"/>
AC_VI	1	7	15	94	<input type="checkbox"/>	<input type="checkbox"/>
AC_VO	1	3	7	47	<input type="checkbox"/>	<input type="checkbox"/>

	Aifsn	CWMin	CWMax	Txop	ACM
AC_BE	3	15	1023	0	<input type="checkbox"/>
AC_BK	7	15	1023	0	<input type="checkbox"/>
AC_VI	2	7	15	94	<input type="checkbox"/>
AC_VO	2	3	7	47	<input type="checkbox"/>

➔ **WMM Parameters of Access Point** : This affects traffic flowing from the access point to the client station

Configuring QoS options consists of setting parameters on existing queues for different types of wireless traffic. You can configure different minimum and maximum wait times for the transmission of packets in each queue based on the requirements of the media being sent. Queues automatically provide minimum transmission delay for Voice, Video, multimedia, and mission critical applications, and rely on best-effort parameters for traditional IP data. As an Example, time-sensitive Voice & Video, and multimedia are given effectively higher priority for transmission (lower wait times for channel access), while other applications and traditional IP data which are less time-sensitive but often more data-intensive are expected to tolerate longer wait times.

- ✓ **Aifsn** : The Arbitration Inter-Frame Spacing Number specifies a wait time (in milliseconds) for data frames
- ✓ **CWmin** : Minimum Contention Window. This parameter is input to the algorithm that determines the initial random backoff wait time ("window") for retry of a transmission. The value specified here in the Minimum Contention Window is the upper limit (in milliseconds) of a range from which the initial random backoff wait time is determined.
- ✓ **CWmax** : Maximum Contention Window. The value specified here in the

Maximum Contention Window is the upper limit (in milliseconds) for the doubling of the random backoff value. This doubling continues until either the data frame is sent or the Maximum Contention Window size is reached. Once the Maximum Contention Window size is reached, retries will continue until a maximum number of retries allowed is reached. Valid values for the "cwmax" are 1, 3, 7, 15, 31, 63, 127, 255, 511, or 1024. The value for "cwmax" must be higher than the value for "cwmin".

- ✓ **Txop** : Transmission Opportunity is an interval of time when a WME AP has the right to initiate transmissions onto the wireless medium (WM). This value specifies (in milliseconds) the Transmission Opportunity (TXOP) for AP; that is, the interval of time when the WMM AP has the right to initiate transmissions on the wireless network.
- ✓ **ACM** : Admission Control Mandatory, ACM only takes effect on AC\_VI and AC\_VO. When you do not click Checkbox, it means that the ACM is controlled by the connecting AP. If you click Checkbox, it means that the Client is in charge.
- ✓ **AckPolicy** : Acknowledgment Policy, WMM defines two ACK policies: **Normal ACK** and **No ACK**. Click **“Checkbox”** indicates **“No ACK”**  
 When the no acknowledgment (No ACK) policy is used, the recipient does not acknowledge received packets during wireless packet exchange. This policy is suitable in the environment where communication quality is fine and interference is weak. While the No ACK policy helps improve transmission efficiency, it can cause increased packet loss when communication quality deteriorates. This is because when this policy is used, a sender does not retransmit packets that have not been received by the recipient.  
 When the Normal ACK policy is used, the recipient acknowledges each received unicast packet.

➔ **WMM Parameters of Station** : *This affects traffic flowing from the client station to the access point.*

Queue	Data Transmitted Clients to AP	Priority	Description
AC_BK	Background.	Low	High throughput. Bulk data that requires maximum throughput and is not time-sensitive is sent to this queue (FTP data, for example).
AC_BE	Best Effort	Medium	Medium throughput and delay. Most traditional IP data is sent to this queue
AC_VI	Video	High	Minimum delay. Time-sensitive video data is automatically sent to this queue
AC_VO	Voice	High	Time-sensitive data like VoIP and streaming media are automatically sent to this queue


- ✓ **Aifsn** : The Arbitration Inter-Frame Spacing Number specifies a wait time (in milliseconds) for data frames
- ✓ **CWmin** : Minimum Contention Window. This parameter is input to the algorithm that determines the initial random backoff wait time ("window") for retry of a transmission. The value specified here in the Minimum Contention Window is the upper limit (in milliseconds) of a range from which the initial random backoff wait time is determined.
- ✓ **CWmax** : Maximum Contention Window. The value specified here in the Maximum Contention Window is the upper limit (in milliseconds) for the doubling of the random backoff value. This doubling continues until either the data frame is sent or the Maximum Contention Window size is reached. Once the Maximum Contention Window size is reached, retries will continue until a maximum number of retries allowed is reached. Valid values for the "cwmax" are 1, 3, 7, 15, 31, 63, 127, 255, 511, or 1024. The value for "cwmax" must be higher than the value for "cwmin".
- ✓ **Txop** : Transmission Opportunity is an interval of time when a WME AP has the right to initiate transmissions onto the wireless medium (WM). This value specifies (in milliseconds) the Transmission Opportunity (Txop) for AP; that is, the interval of time when the WMM AP has the right to initiate transmissions on the wireless network.
- ✓ **ACM** : Admission Control Mandatory, ACM only takes effect on AC\_VI and AC\_VO. When you do not click Checkbox, it means that the ACM is controlled by the connecting AP. If you click Checkbox, it means that the Client is in charge.



Click **Save** button to save your changes. Click **Reboot** button to activate your changes. The items in this page are for AP's RF advanced settings and will be applied to **all VAPs** and **WDS Links**.

### Create Virtual AP (VAP)

The TEW-676APBO support broadcasting multiple SSIDs, allowing the creation of Virtual Access Points, partitioning a single physical access point into **7** logical access points, each of which can have a different set of security and network settings. **Figure 8-2** shows multiple SSIDs with security type settings.



### Virtual AP Overview

The administrator can view all of the Virtual AP's settings via this page. Please click on **Wireless -> Virtual AP Setup** and the Virtual AP Overview Page appears.

Virtual AP Overview						
VAP List						
VAP	ESSID	MAC Address	Status	Security Type	MAC Filter	Edit
Primary AP	TRENDnet676	00:11:A3:07:03:48	On	Disable	Disable	<a href="#">Edit</a>
VAP1		00:00:00:00:00:00	Off	Disable	Disable	<a href="#">Edit</a>
VAP2		00:00:00:00:00:00	Off	Disable	Disable	<a href="#">Edit</a>
VAP3		00:00:00:00:00:00	Off	Disable	Disable	<a href="#">Edit</a>
VAP4		00:00:00:00:00:00	Off	Disable	Disable	<a href="#">Edit</a>
VAP5		00:00:00:00:00:00	Off	Disable	Disable	<a href="#">Edit</a>
VAP6		00:00:00:00:00:00	Off	Disable	Disable	<a href="#">Edit</a>

- **VAP** : Indicate the system's Virtual AP.
- **ESSID** : Indicate the ESSID of the respective Virtual AP
- **MAC Address** : The MAC address of the VAP Interface is displayed here. When you enable AP and reboot system, the MAC address will display here.
- **Status** : Indicate the Status of the respective Virtual AP. The **Primary AP** always on.
- **Security Type** : Indicate an used security type of the respective Virtual AP.
- **MAC Filter** : Indicate an used MAC filter of the respective Virtual AP.
- **Edit** : Click **Edit** button to configure Virtual AP's settings, including security type and MAC Filter.



## Virtual AP Setup

For each Virtual AP, administrators can configure SSID, SSID broadcasting, Maximum number of client associations, security type settings.

Click **Edit** button on the Edit column, and then a Virtual AP setup page appears.

**Primary AP Setup**

**Security**

ESSID : TRENDnet676

Client Isolation :  Enable  Disable

Hidden SSID :  Enable  Disable

Maximum Clients : 32


Security Type : Disable

**MAC Filter**

Action : Disable

Save

- **Enable AP** : By default, it's "**Disable**" for VAP1 ~ VAP6. **The Primary AP always enabled.**  
Select "**Enable**" to activate VAP or click "**Disable**" to deactivate this function
- **ESSID** : Extended Service Set ID, When clients are browsing for available wireless networks, this is the SSID that will appear in the list. ESSID will determine the service type available to AP's clients associated with the specified VAP.
- **Client Isolation** : Select **Enable**, all clients will be isolated from each other, that means all clients can not reach to other clients. Below Figures depict Client Isolation and AP Isolation



- **Hidden SSID** : By default, it's "**Disable**".  
Enable this option to stop the SSID broadcast in your network. When disabled, people could easily obtain the SSID information with the site survey software and get access to the network if security is not turned on. When enabled, network security is enhanced. It's suggested to enable it after AP security settings are archived and setting of AP clients could make to associate to it.
- **Maximum Clients** : The default value is **32**. You can enter the number of wireless clients that can associate to a particular SSID. When the number of client is set to 5, only 5 clients at most are allowed to connect to this VAP.

- **Security Type** : Select the desired security type from the drop-down list; the options are **Disable**, **WEP**, **WPA-PSK**, **WPA2-PSK**, **WPA-Enterprise**, **WPA2-Enterprise** and **WEP 802.1X**.

- ➔ **Disable** : Data are unencrypted during transmission when this option is selected.
- ➔ **WEP** : Wired Equivalent Privacy(WEP) is a data encryption mechanism based on a 64-bit or 128-bit shared key.

- **Authentication Method** : Enable the desire option among **OPEN**, **SHARED** or **WEPAUTO**.

- ➔ **Key Index** : Key index is used to designate the WEP key during data transmission. 4 different WEP keys can be entered at the same time, but only one is chosen.
- ➔ **WEP Key #** : Enter **HEX** or **ASCII** format WEP key value; the system supports up to 4 sets of WEP keys.

Key Length	Hex	ASCII
64-bit	10 characters	5 characters
128-bit	26 characters	13 characters

- ➔ **WPA-PSK (or WPA2-PSK)** : WPA (or WPA2) Algorithms, allows the system accessing the network by using the WPA-PSK protected access.

- ✓ **Cipher Suite** : By default, it is **AES**. Select either AES or TKIP cipher suites
  - ✓ **Pre-shared Key** : Enter the pre-shared key; the format shall go with the selected key type.
  - ✓ **Group Key Update Period** : By default, it is **3600** seconds. This time interval for rekeying GTK, broadcast/multicast encryption keys, in seconds. Entering the time-length is required.
- ➔ **WPA-Enterprise (or WPA2-Enterprise)**: The RADIUS authentication and encryption will be both enabled if this is selected.

- ✓ **WPA General Settings** :
  - **Cipher Suite** : By default, it is AES. Select either AES or TKIP cipher suites
  - **Group Key Update Period** : By default, it's **3600** seconds. This time interval for rekeying GTK, broadcast/multicast encryption keys, in seconds. Entering the time-length is required.
  - **PMK Cache Period** : By default, it's 10 minutes. Set **WPA2** PMKID cache timeout period, after time out, the cached key will be deleted.
  - **Pre-Authentication** : By default, it's "Disable". To Enable is use to speed up roaming before pre-authenticating IEEE 802.1X/EAP part of the full RSN authentication and key handshake before actually associating with a new AP.
- ✓ **Radius Server Settings** :
  - **IP Address** : Enter the IP address of the Authentication RADIUS

server.

- **Port** : By default, it's **1812**. The port number used to communicate with RADIUS server.
- **Shared secret** : A secret key used between system and RADIUS server. Supports **8** to **64** characters.
- **Session Timeout** : The Session timeout is in the range of **0~60 seconds**. The default is **0** to disable re-authenticate service. Amount of time before a client will be required to re-authenticate.

➔ **WEP 802.1X** : When WEP 802.1x Authentication is enabled, please refer to the following Dynamic WEP and RADIUS settings to complete configuration.

802.1x WEP	
Dynamic WEP :	Enable

Authentication RADIUS Server	
Authentication Server :	<input type="text"/>
Port :	1812
Shared Secret :	<input type="text"/>
Session Timeout :	0

✓ **Radius Server Settings :**

- **IP Address** : Enter the IP address of the Authentication RADIUS server.
- **Port** : By default, it's **1812**. The port number used to communicate with RADIUS server.
- **Shared secret** : A secret key used between system and RADIUS server. Supports **8** to **64** characters.
- **Session Timeout** : The Session timeout is in the range of **0~60 seconds**. The default is **0** to disable re-authenticate service. Amount of time before a client will be required to re-authenticate.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes

### Wireless MAC Filter Setup

Continue **Virtual AP Setup** section. For each Virtual AP setting, the administrator can allow or reject clients to access each Virtual AP.

- **MAC Filter Setup** : By default, it's **“Disable”**. Options are **Disable, Only Deny List MAC or Only Allow List MAC**.

Two ways to set MAC filter rules :

➔ **Only Allow List MAC.**

The wireless clients in the **“Enable”** list will be **allowed** to access the Access Point; All others or clients in the **“Disable”** list will be **denied**.

➔ **Only Deny List MAC.**

The wireless clients in the **“Enable”** list will be **denied** to access the Access Point; All others or clients in the **“Disable”** list will be **allowed**.


- **Add a station MAC** : Enter MAC address (e.g. aa:bb:cc:00:00:0a) and click **“Add”** button, then the MAC address should display in the **“Enable”** List.

There are a maximum of **20** clients allowed in this **“Enable”** List. The MAC addresses of the wireless clients can be added and removed to the list using the **Add** and **Remove** buttons.


Click **Reboot** button to activate your changes

### Wireless Network Expansion

The administrator could create WDS Links to expand wireless network. When WDS is enabled, access point functions as a wireless bridge and is able to communicate with other access points via WDS links. A WDS link is **bidirectional** and **both side must support WDS**. Access points know each other by **MAC Address**. In other words, each access point needs to include **MAC address of its peer**. Ensure all access points are configured with the same channel and own same security type settings.



Please click on **Wireless -> WDS Setup** and follow the below setting.



- **Security Type** : Option is "Disable", "WEP", "TKIP" or "AES" from drop-down list. Needs the same type to build WDS links. Security type takes effect when WDS is enabled.
  - ➔ **WEP Key** : Enter 5 / 13 ASCII or 10 / 26 HEX format WEP key.
  - ➔ **TKIP Key** : Enter 8 to 63 ASCII or 64 HEX format TKIP key.
  - ➔ **AES Key** : Enter 8 to 63 ASCII or 64 HEX format AES key.
- **WDS MAC List**
  - ➔ **Enable** : Click **Enable** to create WDS link.
  - ➔ **WDS Peer's MAC Address** : Enter the MAC address of WDS peer.
  - ➔ **Description** : Description of WDS link.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes

The **System Overview** page appears upon the completion of reboot.

## Access Control List

### IP Filter Setup

Allows to create deny or allow rules to filter ingress or egress packets from specific source and/or to destination IP address on wired (LAN) or Wireless (WAN) ports. Filter rules could be used to filter unicast or multicast packets on different protocols as shown in the IP Filter Setup. Important to note that IP filter rules has precedence over Virtual server rules.

Please click on **Advance** -> **IP Filter Setup** and follow the below setting.

- **Source Address/Mask** : Enter desired source IP address and netmask; i.e. 192.168.2.10/32.
- **Source Port** : Enter a port or a range of ports as **start:end**; i.e. port 20:80
- **Destination Address/Mask** : Enter desired destination IP address and netmask; i.e. 192.168.1.10/32
- **Destination Port** : Enter a port or a range of ports as **start:end**; i.e. port 20:80
- **In/Out** : Applies to Ingress or egress packets
- **Protocol** : Supports **TCP**, **UDP** or **ICMP**.

- **Listen** : Click **Yes** radial button to match TCP packets only with the SYN flag.
- **Active** : **Deny** to drop and **Pass** to allow per filter rules
- **Interface** : The interface that a filter rule applies

Click "**Save**" button to add IP filter rule. Total of **20** rules maximum allowed in the IP Filter List. All rules can be edited or removed from the List. Click **Reboot** button to activate your changes.

When you create rules in the IP Filter List, the prior rules maintain higher priority. To allow limited access from a subnet to a destination network manager needs to create allow rules first and followed by deny rules. So, if you just want one IP address to access the system via telnet from your subnet, not others, the Example 1 demonstrates it, not rules in the Example 2.

- ➔ **Example 1** : Create a higher priority rule to allow IP address 192.168.2.2 Telnet access from LAN port first, and deny Telnet access from remaining IP addresses in the same subnet.
- ➔ **Example 2** : All Telnet access to the system from the IP addresses of subnet 192.168.2.x works with the rule 1 of Example 2. The rule 2 won't make any difference.

## MAC Filter Setup

Allows to create MAC filter rules to allow or deny unicast or multicast packets from limited number of MAC addresses. Note, the MAC filter rules have precedence over IP Filter rules.

Please click on **Advance -> MAC Filter Setup** and follow the below setting.

**MAC Filter Setup**

**MAC Rules**

Action :

MAC Address :

**MAC Filter List**

#	MAC Address	Delete	#	MAC Address	Delete
No MAC Rule in the List!					


- **MAC Filter Rule** : By default, it's "*Disable*". Options are **Disabled**, **Only Deny List MAC** or **Only Allow List MAC**. Click **Save** button to save your change.  
Two ways to set the MAC Filter List:
  - ➔ **Only Allow List MAC.**  
The wireless clients in the MAC Filter List will be **allowed** to access to Access Point; All others will be denied.
  - ➔ **Only Deny List MAC.**  
The wireless clients in the MAC Filter List will be **denied** to access to Access Point; All others will be allowed.
- **MAC Address** : Enter MAC address (e.g. aa:bb:cc:00:00:0a) and click "**Add**" button, then the MAC address should display in the MAC Filter List.

There are a maximum of **20** clients allowed in this MAC Filter List. The MAC addresses of the wireless clients can be added and removed to the list using the **Add** and **Delete** buttons.

Click **Reboot** button to activate your changes

## Parental Control Setup

Parental Control allows you to block or allow specific kinds of Internet usage and traffic, such as Internet access, designated services, and websites.



Please click on **Advance -> Parental Control** and follow the below setting.

- **Rules** : control can be managed by a rule. Use the settings on this screen to establish an access policy.
  - ➔ **Comment** : Enter a descriptive name for this rule for identifying purposes.
  - ➔ **MAC Address** : Enter MAC address in valid MAC address format(xx:xx:xx:xx:xx:xx) and click “Add” button to add in the MAC group of each rule. Click “Remove” button can remove MAC address in the group of each rule. There are **10** MAC address maximum allowed in each rule.
  - ➔ **Local / Destination IP** : Specify local(LAN)/ destination IP addresses range required for this rule. If you specify local IP addresses range from 192.168.1.1 to 192.168.2.254. The matches a range of local IP addresses include every single IP address from the first to the last, so the example above includes everything from 192.168.1.1 to 192.168.2.254.
  - ➔ **Protocol** : Select **Any** or specify protocol(**TCP**, **UDP**, **ICMP**, **URL Blocking** and

**Application**) from drop-down list. When you select **ICMP** or **Layer 7 Application**, the Local(LAN)/ Destination Port can not used.

If you want to block websites with specific URL address or using specific keywords, enter each URL or keywords in the “**URL Blocking**” field and click “**Add**” button to add in the URL Blocking list of each rule. Click “**Remove**” button can remove URL or keywords.

- ➔ **Local Port** : Specify local port(LAN port) range required for this rule
- ➔ **Destination Port** : Specify destination port range required for this rule
- ➔ **Active** : Check **Enable** button to activate this rule, and **Disable** to deactivate.


Click “**Add**” button to add control rule to List. There are **10** rules maximum allowed in this Control List. All rules can be removed or edited on the List. Click **Reboot** button to activate your changes.




### QoS Setup


Quality of Service (QoS) refers to both a network's ability to deliver data with minimum delay, and the networking methods used to control the use of bandwidth. Without QoS, all traffic data is equally likely to be dropped when the network is congested. This can cause a reduction in network performance and make the network inadequate for time-critical application such as video-on-demand.

A classifier groups traffic into data flows according to specific criteria such as the source address, destination address, source port number, destination port number or incoming port number. For example, you can configure a classifier to select traffic from the same protocol port (such as FTP) to form a flow.



Please click on **Advance** -> **QoS** and follow the below setting.





- **Rules** : Use the rules to define the classifiers. After you define the rules, you can specify action to act upon the traffic that matches the rules
  - ➔ **Comment** : Enter a descriptive name for this rule for identifying purposes.
  - ➔ **MAC Address** : Enter MAC address in valid MAC address format(xx:xx:xx:xx:xx:xx) and click **“Add”** button to add in the MAC group of

- ➔ **Local / Destination IP** : Specify local(LAN)/ destination IP addresses range required for this rule. If you specify local IP addresses range from 192.168.1.1 to 192.168.2.254. The matches a range of local IP addresses include every single IP address from the first to the last, so the example above includes everything from 192.168.1.1 to 192.168.2.254.
- ➔ **DSCP Class** : Differentiated services code point, DSCP. Select Any or specify classify traffic from drop-down list.
 

The Per-Hop Behavior (PHB) is indicated by encoding a 6-bit value—called the Differentiated Services Code Point (DSCP)—into the 8-bit Differentiated Services (DS) field of the IP packet header. Below depicts class for DSCP.

  - ✓ **BE** : *Default* PHB, which is typically best-effort traffic
  - ✓ **EF** : *Expedited Forwarding* PHB, dedicated to low-loss, low-latency traffic
  - ✓ **AF** : *Assured Forwarding* PHB, which gives assurance of delivery under conditions. The AF behavior group defines four separate AF classes. Within each class, packets are given a drop precedence (high, medium or low). The combination of classes and drop precedence yields twelve separate DSCP encodings from **AF11** through **AF43** (see table)

DROP Precedence	Class 1	Class 2	Class 3	Class 4
Low Drop	AF11	AF21	AF31	AF41
Medium Drop	AF12	AF22	AF32	AF42
High Drop	AF13	AF23	AF33	AF43

- ➔ **Protocol** : Select **Any** or specify protocol from drop-down list. When you select **ICMP** or **Layer 7 Application** , the Source/ Destination Port can not used.
  - ➔ **Local Port** : Specify local port(LAN port) range required for this rule
  - ➔ **Destination Port** : Specify destination port range required for this rule
- **Action** : After configuring rule, a policy rule ensures that a traffic flow gets the requested treatment in the network.
    - ➔ **Remark DSCP** : Specify a new DSCP class, if you want to replace or remark the DSCP
    - ➔ **Bandwidth** : Click **“Enable”** to activate function, and click **“Disable”** to deactivate function
    - ➔ **Upload / Download** : Specify the bandwidth in kilobit per second (Kbps). Enter

a number between 8 to 8192, default upload is 128 Kbps, download is 1024 Kbps.

Click "Add" button to add QoS rule to List. There are 10 rules maximum allowed in this QoS List. All rules can be removed or edited on the List. Click **Reboot** button to activate your changes.


When you create rules on the QoS List, the previous rules have higher priority. Below depict the examples for explaining priority of QoS setup.

- **Example 1** : On this setting, the FTP has 1024 Kbps upload and 8196 Kbps download on 192.168.2.10. The remaining IP address and other remaining protocol of IP address 192.168.2.10 only can use total bandwidth 512 Kbps bandwidth. Because rule 1's priority is higher than rule 2
- **Example 2** : On this setting, the FTP has 512 Kbps upload and 512 Kbps download on 192.168.2.10 Because rule 1's priority is higher than rule 2


## Resource Sharing

### DMZ

DMZ is commonly work with the NAT functionality as an alternative of Virtual Server(Port Forwarding) while wanting all ports of DMZ host visible to Internet users. Virtual Server rules have precedence over the DMZ rule. In order to use a range of ports available to access to different internal hosts Virtual Server rules are needed.



Please click on **Advance -> DMZ** and follow the below setting.




- **DMZ** : By default, it's "Disable". Check **Enable** radial button to enable DMZ.
- **IP Address** : Enter IP address of DMZ host and only one DMZ host is supported. Click **Save** button to save your changes. Click **Reboot** button to activate your changes.

### Virtual Server (Port Forwarding)

"Virtual Server" can also referred to as "Port Forward" as well and used interchangeably. Resources in the network can be exposed to the Internet users in a controlled manner including on-line gaming, video conferencing or others via Virtual Server setup. Don't repeat ports' usage to avoid confusion.

Suppose you want to assign ports 21-25 to one FTP, Telnet and SMTP server (A in the example), and port 80 to another (B in the example). You assign the LAN IP addresses and the ISP assigns the WAN IP address. The NAT network appears as a single host on the Internet.



Please click on **Advance -> Virtual Server** and follow the below setting.

- **Virtual Server** : By Default, It's "**Disable**". Check **Enable** radial button to enable Virtual Server.
  - **Description** : Enter appropriate message for resource sharing via Virtual Server.
  - **Private IP** : Enter corresponding IP address of internal resource to share.
  - **Protocol Type** : Select appropriate sessions, TCP or UDP, from shared host via multiple private ports.
  - **Private Port** : A port or a range of ports may be specified as **start:end**; i.e. port 20:80
  - **Public Port** : A port or a range of ports may be specified as **start:end**; i.e. port 20:80
- Click "**Add**" button to add Virtual Server rule to List. Total of maximum **20** rules are allowed in this List. All rules can be edited or removed from the List. Click **Reboot** button to activate your changes.

While creating multiple Virtual Server rules, the prior rules have higher priority. The Virtual server rules have precedence over the DMZ one while both rules exist. Example 1 and 2 demonstrate proper usage of DMZ and Virtual Server rules.

- **Example 1** : All connections should be redirected to **192.168.2.12** while DMZ is enabled. Since Virtual Server rules have precedence over the DMZ rule all connections to TCP port 22 will be directed to TCP port 22 of 192.168.2.10 and

remaining connections to port TCP **20~80** will be redirected to port TCP **20~80** of **192.168.2.11**

- **Example 2** : All connections should be redirected to **192.168.2.12** while DMZ is enabled. Since Virtual Server rules have precedence over the DMZ rule all other connections to TCP port **20~80** will be redirected to port **20~80** of **192.168.2.11**. The rule 2 won't take effect.

## System Status

This section breaks down into subsections of **System Overview**, **Associated Clients Status**, **WDS Link Status**, **Extra Information** and **Event Log**.

### Overview

Detailed information on **System**, **WAN Information**, **LAN Information**, **Wireless Information** and **DHCP Server Status** can be reviewed via this page.

- **System** : Display the information of the system.

System	
Host Name	: TEW-676APBO
Operating Mode	: Router AP Mode
Location	:
Description	: Wireless Outdoor PoE Access Point
Firmware Version	: Cen-CPE-N5H5R V1.0.15
Firmware Date	: 2010-12-16 02:52:11
Device Time	: 2000-01-01 00:21:54
System Up Time	: 21:54

- ➔ **System Name** : The name of the system.
- ➔ **Operating Mode** : The mode currently in service.
- ➔ **Location** : The reminding note on the geographical location of the system.
- ➔ **Description** : The reminding note of the system.
- ➔ **Firmware Version** : The current firmware version installed.
- ➔ **Firmware Date** : The build time of the firmware installed.
- ➔ **Device Time** : The current time of the system.
- ➔ **System Up Time** : The time period that system has been in service since last reboot.

- **WAN Information** : Display the information of the WAN interface.

WAN Information	
Mode	PPPoEMode
Reconnect Mode	On Demand <b>Connect</b> <b>DisConnect</b>
MAC Address	00:11:A3:07:03:47
IP Address	10.64.64.64
IP Netmask	255.255.255.255
IP Gateway	10.112.112.112
Primary DNS	
Secondary DNS	
Receive Bytes	0
Receive Packets	0
Transmit Bytes	0
Transmit Packets	0

The WAN port specified **Dynamic IP**, the Release and Renew button will be show-up, click **Release** button to release IP address of WAN port, **Renew** button to renew IP address through DHCP server.

WAN Information	
Mode	Dynamic IPMode <b>Renew</b> <b>Release</b>

The WAN port specified **PPPoE** or **PPTP**, and the **Connect** and **DisConnect** button will be show up. Click "**Connect**" button to assigned IP address from PPPoE or PPTP server, "**DisConnect**" button to release IP address of WAN port.

WAN Information	
Mode	PPPoEMode
Reconnect Mode	On Demand <b>Connect</b> <b>DisConnect</b>

- ➔ **Mode** : Supports Static, Dynamic, PPPoE and PPTP modes.
- ➔ **Reconnect Mode** : The current reconnect mode of the PPPoE or PPTP.

- ➔ **MAC Address** : The MAC address of the WAN port.
- ➔ **IP Address** : The IP address of the WAN port.
- ➔ **IP Netmask** : The IP netmask of the WAN port.
- ➔ **IP Gateway** : The gateway IP address of the WAN port.
- ➔ **Primary DNS** : The primary DNS server in service.
- ➔ **Secondary DNS** : The secondary DNS server in service.
- ➔ **Receive bytes** : The total received packets in bytes on the WAN port.
- ➔ **Receive packets** : The total received packets of the WAN port.
- ➔ **Transmit bytes** : The total transmitted packets in bytes of the WAN port.
- ➔ **Transmit packets** : The total transmitted packets of the WAN port.

- **LAN Information** : Display total received and transmitted statistics on the LAN interface.

LAN Information	
MAC Address	00:11:A3:07:03:48
IP Address	192.168.10.101
IP Netmask	255.255.255.0
Receive Bytes	65986
Receive Packets	752
Transmit Bytes	116267
Transmit Packets	268

- ➔ **MAC Address** : The MAC address of the LAN port.
- ➔ **IP Address** : The IP address of the LAN port.
- ➔ **IP Netmask** : The IP netmask of the LAN port.
- ➔ **Receive bytes** : The total received packets in bytes on the LAN port.
- ➔ **Receive packets** : The total received packets of the LAN port.
- ➔ **Transmit bytes** : The total transmitted packets in bytes of the LAN port.
- ➔ **Transmit packets** : The total transmitted packets of the LAN port.

- **Wireless Information** : Display the detailed receive and transmit statistics of Wireless interface.

Wireless Information	
MAC Address	:00:11:A3:07:03:48
Channel	:44
Rate	:300 Mb/s
Receive Bytes	:528781
Receive Packets	:2947
Transmit Bytes	:164287
Transmit Packets	:288

- ➔ **MAC Address** : The MAC address of the Wireless Port.
- ➔ **Channel** : The current channel on the Wireless port.
- ➔ **Rate** : The current Bit Rate on the Wireless port.
- ➔ **Receive bytes** :The total received packets in bytes on the Wireless port.
- ➔ **Receive packets** : The total received packets on the Wireless port.
- ➔ **Transmit bytes** : The total transmitted packets in bytes on the Wireless port.
- ➔ **Transmit packets** : The total transmitted packets on the Wireless port.

- **DHCP Server Status** : Users could retrieve DHCP server and DHCP clients' IP/MAC address via this field.

DHCP Server Status		
DHCP	: Enable	
Start IP	: 192.168.10.101	
End IP	: 192.168.10.254	
DNS1 IP	: 192.168.10.100	
DNS2 IP	:	
WINS IP	:	
Domain	:	
Lease Time	: 86400	
IP Address	MAC Address	Expired In
	none	

- ➔ **IP Address** : IP addresses to LAN devices by DHCP server.
- ➔ **MAC Address** : MAC addresses of LAN devices.
- ➔ **Expired In** : Shows how long the leased IP address will expire.

## Associated Clients

It displays ESSID, on/off Status, Security Type, total number of wireless clients associated with all Virtual AP.

Wireless Clients						
<a href="#">Refresh</a>						
VAP Information						
VAP	ESSID	MAC Address	Status	Security Type	Clients	
Primary AP	TRENDnet878	00:11:A3:07:03:48	On	Disable	1	
VAP1		00:00:00:00:00:00	Off	Disable	0	
VAP2		00:00:00:00:00:00	Off	Disable	0	
VAP3		00:00:00:00:00:00	Off	Disable	0	
VAP4		00:00:00:00:00:00	Off	Disable	0	
VAP5		00:00:00:00:00:00	Off	Disable	0	
VAP6		00:00:00:00:00:00	Off	Disable	0	
Primary AP Clients						
MAC Address	Signal Strength ANT0	Signal Strength ANT1	Bandwidth	Idle Time	Connect Time	Disconnect
00:26:C8:2C:68:40	100%(-43dBm)	100%(-48dBm)	40MHz	0	261	<a href="#">Delete</a>

- **VAP Information** : Highlights key VAP information.
  - ➔ **VAP** : Available VAP from Primary AP to VAP6.
  - ➔ **ESSID** : Display name of ESSID for each VAP.
  - ➔ **MAC Address** : Display MAC address for each VAP.
  - ➔ **Status** : On/Off
  - ➔ **Security Type** : Display chosen security type; WEP, WPA/WPA2-PSK, WPA/WPA2-Enterprise.
  - ➔ **Clients** : Display total number of wireless connections for each VAP.
- **VAP Clients** : Display all associated clients on each Virtual AP.
  - ➔ **MAC Address** : MAC address of associated clients
  - ➔ **Signal Strength ANT0/ANT1** : Signal Strength of from associated clients.
  - ➔ **Bandwidth** : Channel bandwidth of from associated clients
  - ➔ **Idle Time** : Last inactive time period in seconds for a wireless connection.
  - ➔ **Connect Time** : Total connection time period in seconds for a wireless connection.
  - ➔ **Disconnect** : Click "Delete" button to manually disconnect a wireless client in a Virtual AP.



### Show WDS Link

Peers MAC Address, antenna 0/1 received signal strength, phy mode and channel bandwidth for each WDS are available.

The screenshot shows a web interface titled "WDS Information" with a "Refresh" button. Below it is a table titled "WDS Link Status" with the following data:

MAC Address	Signal Strength ANT0	Signal Strength ANT1	Phy Mode	Bandwidth	MCS	SIGI
00:11:A3:07:03:60	no signal	no signal	HTMIX	40M	14	0

- **MAC Address** : Display MAC address of WDS peer.
- **Signal Strength ANT0/ANT1** : Indicate the signal strength of the respective WDS links.
- **Phy Mode** : Indicate the phy mode of the respective WDS linked.
- **BandWidth** : Indicate the channel bandwidth of the respective WDS linked.
- **MCS** : Indicate the MCS of the respective WDS linked.
- **SIGI** : Indicate the SIGI (Short Guard Interval) of the respective WDS linked. "1" indicate the Short Guard Interval, "0" indicate the Long Guard Interval.

### Extra Info

Users could pull out information such as Route table, ARP table, MAC table, Bridge table or STP available in the drop-down list from system. The "Refresh" button is used to retrieve latest table information.

The screenshot shows a web interface titled "Extra Information" with a "Refresh" button. Below it is a dropdown menu set to "Netstat Information". Below the dropdown is a table titled "Netstat Information" with the following data:

Protocol	LiveTime	Status	SrcIP	SrcPort	DestIP	DestPort
tcp	2	TIME_WAIT	192.168.10.102	50113	192.168.10.101	80
tcp	91	TIME_WAIT	192.168.10.102	50130	192.168.10.101	80
tcp	59	TIME_WAIT	192.168.10.102	50123	192.168.10.101	80
tcp	63	TIME_WAIT	192.168.10.102	50124	192.168.10.101	80
tcp	83	TIME_WAIT	192.168.10.102	50128	192.168.10.101	80
tcp	32	TIME_WAIT	192.168.10.102	50118	192.168.10.101	80
tcp	7	TIME_WAIT	192.168.10.102	50114	192.168.10.101	80
tcp	37	TIME_WAIT	192.168.10.102	50119	192.168.10.101	80
tcp	112	TIME_WAIT	192.168.10.102	50134	192.168.10.101	80
tcp	13	TIME_WAIT	192.168.10.102	50115	192.168.10.101	80
tcp	68	TIME_WAIT	192.168.10.102	50125	192.168.10.101	80
udp	20		192.168.10.102	137	192.168.10.255	137
tcp	27	TIME_WAIT	192.168.10.102	50117	192.168.10.101	80
tcp	73	TIME_WAIT	192.168.10.102	50126	192.168.10.101	80
tcp	431999	ESTABLISHED	192.168.10.102	50137	192.168.10.101	80
tcp	102	TIME_WAIT	192.168.10.102	50132	192.168.10.101	80
tcp	43	TIME_WAIT	192.168.10.102	50120	192.168.10.101	80
tcp	117	TIME_WAIT	192.168.10.102	50135	192.168.10.101	80
tcp	96	TIME_WAIT	192.168.10.102	50131	192.168.10.101	80
tcp	107	TIME_WAIT	192.168.10.102	50133	192.168.10.101	80
udp	15		192.168.10.102	68	255.255.255.255	67
tcp	18	TIME_WAIT	192.168.10.102	50116	192.168.10.101	80
tcp	119	TIME_WAIT	192.168.10.102	50136	192.168.10.101	80
tcp	78	TIME_WAIT	192.168.10.102	50127	192.168.10.101	80
tcp	48	TIME_WAIT	192.168.10.102	50121	192.168.10.101	80
tcp	53	TIME_WAIT	192.168.10.102	50122	192.168.10.101	80



- **Netstat Information** : Select “**NetStatus Information**” on the drop-down list, the connection track list should show-up, the list can be updated using the Refresh button.

NetStatus will show all connection track on the system, the information include *Protocol, Live Time, Status, Source/Destination IP address and Port.*

- **Route table information** : Select “**Route table information**” on the drop-down list to display route table.

TEW-676APBO could be used as a L2 or L3 device. It doesn't support dynamic routing protocols such as RIP or OSPF. Static routes to specific hosts, networks or default gateway are set up automatically according to the IP configuration of system's interfaces. When used as a L2 device, it could switch packets and, as L3 device, it's capable of being a gateway to route packets inward and outward.

Route Information			
Destination	Gateway	Netmask	Interface
192.168.10.0	0.0.0.0	255.255.255.0	br0

- **ARP table Information** : Select “**ARP Table Information**” on the drop-down list to display ARP table.

ARP associates each IP address to a unique hardware address (MAC) of a device. It is important to have a unique IP address as final destination to switch packets to.

ARP Table Information		
IP Address	MAC Address	Interface
192.168.10.102	00:26:C6:2C:68:40	br0

- **Bridge table information** : Select “**Bridge Table information**” on the drop-down list to display bridge table.

Bridge table will show Bridge ID and STP's Status on the each Ethernet bridge and its attached interfaces, the Bridge Port should be attached to some interfaces e.g. ra0 ~ra6 and wds0~wds3).

Bridge Table Information			
Bridge Port	Bridge ID	STP Enabled	Interface
br0	8000.0011a3070348	no	ra0 wds0

- **Bridge MAC information** : Select “**Bridge MACs Information**” on the drop-down list to display MAC table.

This table displays local MAC addresses associated with wired or wireless interfaces, but also remember non-local MAC addresses learned from wired or wireless interfaces.

Ageing timers will be reset when existing MAC addresses in table are learned again or added when new MAC addresses are seen from wired or wireless interfaces as well. When time runs out for a particular entry, it will be pruned from the table. In that situation, switching packet to that particular MAC address will be discontinued.

Bridge MACs Information			
Port	MAC Address	Local	Ageing Timer
PrimaryAP	00:11:a3:07:03:48	yes	0.00
PrimaryAP	00:26:c6:2c:68:40	no	0.09

- **Bridge STP Information** : Select “**Bridge STP Information**” on the drop-down list to display a list of bridge STP information.

Bridge STP Information			
<b>br0</b>			
bridge id	8000.0011a3070348		
designated root	8000.0011a3070348		
root port	0	path cost	0
max age	20.00	bridge max age	20.00
hello time	2.00	bridge hello time	2.00
forward delay	15.00	bridge forward delay	15.00
ageing time	300.00		
hello timer	0.53	ton timer	0.00
topology change timer	0.00	gc timer	0.53
flags			
<b>ra0 (1)</b>			
port id	8001	state	forwarding
designated root	8000.0011a3070348	path cost	100
designated bridge	8000.0011a3070348	message age timer	0.00
designated port	8001	forward delay timer	0.00
designated cost	0	hold timer	0.55
flags			
<b>wds0 (2)</b>			
port id	8002	state	forwarding
designated root	8000.0011a3070348	path cost	100
designated bridge	8000.0011a3070348	message age timer	0.00
designated port	8002	forward delay timer	0.00
designated cost	0	hold timer	0.55
flags			

## QoS Plot

The QoS Plot show graphs which continuously represents the current data traffic on each QoS rule. The chart scale and throughput dimension (bps, Kbps, Mbps) changes dynamically according to the mean throughput value. The statistics is updated automatically every 5 seconds. The throughput statistics of QoS can be updated manually using the **Refresh** button.

QoS List			
#	Comment	Remark DSCP	Bandwidth(U/D)kbps
No QoS Rule in the List!			

## Event Log

The Event log displays system events when system is up and running. Also, it becomes very useful as a troubleshooting tool when issues are experienced in system.

System Log			
Refresh Clear			
Result			
Time	Facility	Severity	Message
2000-01-01 00:00:09	System	Info	started: BusyBox v1.12.1
2000-01-01 00:00:09	System	Info	dnsmasq[131]: started, version 2.40 cachesize 150
2000-01-01 00:00:09	System	Info	dnsmasq[131]: compile time options: no-IPv6 GNU-getopt no-RTC no-MMU no-ISC-leasefile no-DBus no-I18N TFTP
2000-01-01 00:00:09	System	Warn	dnsmasq[131]: failed to access /etc/resolv.conf: No such file or directory
2000-01-01 00:00:09	System	Info	dnsmasq[131]: cleared cache
2000-01-01 00:01:25	System	Info	Authentication successful for root from 192.168.10.102

- **Time** : The date and time when the event occurred.
- **Facility** : It helps users to identify source of events such "System" or "User"
- **Severity** : Severity level that a specific event is associated such as "info", "error", "warning", etc.
- **Message** : Description of the event.

Click **Refresh** button to renew the log, or click **Clear** button to clear all the record.

## System Management

### Configure Management

Administrator could specify geographical location of the system via instructions in this page. Administrator could also enter new Root and Admin passwords and allow multiple login methods.

Please click **System -> Management** and follow the below settings.

### Management Setup

System Information

System Name :	TEW-676APBO
Description :	Wireless Outdoor PoE Access Point
Location :	

Root Password

New Root Password :	
Check Root Password :	

Admin Password

New Admin Password :	
Check New Password :	

Admin Login Methods

Enable HTTP :	<input checked="" type="checkbox"/>	Port :	80	
Enable HTTPS :	<input checked="" type="checkbox"/>	Port :	443	<b>UploadKey</b>
Enable Telnet :	<input checked="" type="checkbox"/>	Port :	23	
Enable SSH :	<input checked="" type="checkbox"/>	Port :	22	<b>GenerateKey</b>
Host Key Footprint : ssh-rsa AAAAB3NzaC1yc2EAAAADAQABAAQgwl				

Ping Watchdog

Ping Watchdog :	<input type="radio"/> Enable	<input checked="" type="radio"/> Disable	
IP Address To Ping :			
Ping Interval :	300	Seconds	
Startup Delay :	300	Seconds	
Failure Count To Reboot :	3		

**Save**

## ■ System Information

- ➔ **System Name** : Enter a desired name or use the default one.
- ➔ **Description** : Provide description of the system.
- ➔ **Location** : Enter geographical location information of the system. It helps administrator to locate the system easier.

The system supports **two** management accounts, root and admin. The network manager is assigned with full administrative privileges, when logging in as **root** user, to manage the system in all aspects. While logging in as an **admin** user, only subset of privileges is granted such as basic maintenance. For example, root user can change passwords for both root and admin account, and admin user can only manage its own. For more information about covered privileges for these two accounts, please refer to **Appendix D. Network manager Privileges**.

- **Root Password** : Log in as a root user and is allowed to change its own, plus admin user's password.
  - ➔ **New Password** : Enter a new password if desired
  - ➔ **Check New Password** : Enter the same new password again to check.
- **Admin Password** : Log in as a admin user and is allowed to change its own,
  - ➔ **New Password** : Enter a new password if desired
  - ➔ **Check New Password** : Enter the same new password again to check.
- **Admin Login Methods** : Only **root** user can enable or disable system login methods and change services port.
  - ➔ **Enable HTTP** : Check to select HTTP Service.
  - ➔ **HTTP Port** : The default is 80 and the range is between 1 ~ 65535.
  - ➔ **Enable HTTPS** : Check to select HTTPS Service
  - ➔ **HTTPS Port** : The default is 443 and the range is between 1 ~ 65535.
  
  - ➔ **Enable Telnet** : Check to select Telnet Service
  - ➔ **Telnet Port** : The default is 23 and the range is between 1 ~ 65535.
  - ➔ **Enable SSH** : Check to select SSH Service
  - ➔ **SSH Port** : Please The default is 22 and the range is between 1 ~ 65535.
- **Ping Watchdog** : The ping watchdog sets the TEW-676APBO Device to continuously


ping a user defined IP address (it can be the internet gateway for example). If it is unable to ping under the user defined constraints, the TEW-676APBO device will automatically reboot. This option creates a kind of "fail-proof" mechanism.

Ping Watchdog is dedicated for continuous monitoring of the particular connection to remote host using the Ping tool. The Ping works by sending ICMP "echo request" packets to the target host and listening for ICMP "echo response" replies. If the defined number of replies is not received, the tool reboots the device.

- ➔ **Enable Ping Watchdog** : control will enable Ping Watchdog Tool.
- ➔ **IP Address To Ping** : specify an IP address of the target host which will be monitored by Ping Watchdog Tool.
- ➔ **Ping Interval** : specify time interval (in seconds) between the ICMP "echo requests" are sent by the Ping Watchdog Tool. Default is **300** seconds.
- ➔ **Startup Delay** : specify initial time delay (in seconds) until first ICMP "echo requests" are sent by the Ping Watchdog Tool. The value of Startup Delay should be at least **60** seconds as the network interface and wireless connection initialization takes considerable amount of time if the device is rebooted. Default is **300** seconds.
- ➔ **Failure Count To Reboot** : specify the number of ICMP "echo response" replies. If the specified number of ICMP "echo response" packets is not received continuously, the Ping Watchdog Tool will reboot the device.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes

Without a valid certificate, users may encounter the following problem in IE7 when they try to access system's WMI (<https://192.168.2.254>). There will be a "Certificate Error", because the browser treats system as an illegal website.



Click "**Continue to this website**" to access the system's WMI. The system's Overview page will appear.

## Configure System Time

System time can be configured via this page, and manual setting or via a NTP server is supported.

Please click on **System -> Time Server** and follow the below setting.

- **Local Time** : Display the current system time.
- **NTP Client** : To synchronize the system time with NTP server.
  - ➔ **Enable** : Check to select NTP client.
  - ➔ **Default NTP Server** : Select the NTP Server from the drop-down list.
  - ➔ **Time Zone** : Select a desired time zone from the drop-down list.
  - ➔ **Daylight saving time** : Enable or disable Daylight saving.

Click **Save** button to save your changes. Click **Reboot** button to activate your changes

## Configure UPnP


Universal Plug and Play(UPnP) is an architecture to enable pervasive peer-to-peer network connectivity between PCs, intelligent devices and appliances when UPnP is supported. UPnP works on TCP/IP network to enable UPnP devices to connect and access to each other, very well adopted in home networking environment.



- **UPnP** : By default, it's "**Disable**". Select "**Enable**" or "**Disable**" of UPnP Service.

Click **Save** button to save changes and click **Reboot** button to activate changes

For UPnP to work in Windows XP, the "TEW-676APBO" must be available in "**My Network Places**", as shown here: (your specific model may vary)




If these devices are not available, you should verify that the correct components and services are loaded in Windows XP. Please refer to **Appendix E. Using UPnP on Windows XP**

## Configure SNMP Setup

SNMP is an application-layer protocol that provides a message format for communication between SNMP managers and agents. By enabling SNMP function, the administrator can obtain the system information remotely.

Please click on **System -> SNMP Setup** and follow the below setting.



- **SNMP v2c Enable**: Check to enable SNMP v2c.



- ➔ **ro community** : Set a community string to authorize read-only access.
- ➔ **rw community** : Set a community string to authorize read/write access.

- **SNMP v3 Enable**: Check to enable SNMP v3.  
SNMPv3 supports the highest level SNMP security.

SNMP v3	
Enable :	<input checked="" type="checkbox"/>
SNMP ro user :	<input type="text"/>
SNMP ro password :	<input type="text"/>
SNMP rw user :	<input type="text"/>
SNMP rw password :	<input type="text"/>

- **SNMP ro user** : Set a community string to authorize read-only access.
- **SNMP ro password** : Set a password to authorize read-only access.
- **SNMP rw user** : Set a community string to authorize read/write access.
- **SNMP rw password** : Set a password to authorize read/write access.

- **SNMP Trap** : Events such as cold start, interface up & down, and association & disassociation will report to an assigned server.

SNMP Trap	
Enable :	<input checked="" type="checkbox"/>
Community :	<input type="text"/>
IP 1 :	<input type="text"/>
IP 2 :	<input type="text"/>
IP 3 :	<input type="text"/>
IP 4 :	<input type="text"/>

- **Community** : Set a community string required by the remote host computer that will receive trap messages or notices send by the system.
- **IP** : Enter the IP addresses of the remote hosts to receive trap messages.


Click **Save** button to save changes and click **Reboot** button to activate.

## Backup / Restore and Reset to Factory

Backup current configuration, restore prior configuration or reset back to factory default configuration can be executed via this page.

Please click on **Utilities** -> **Profile Setting** and follow the below setting.


- **Save Settings to PC** : Click **Save** button to save the current configuration to a local disk.



- **Load Settings from PC** : Click **Browse** button to locate a configuration file to restore, and then click **Upload** button to upload.
- **Reset To Factory Default** : Click **Default** button to reset back to the factory default settings and expect **Successful** loading message. Then, click **Reboot** button to activate.

## Firmware Upgrade


Firmware is the main software image that system needs to respond to requests and to manage real time operations. Firmware upgrades are sometimes required to include new features or bugs fix. It takes around **2 minutes** to upgrade due to complexity of firmware. To upgrade system firmware, click **Browse** button to locate the new firmware, and then click **Upgrade** button to upgrade.



## Network Utility

The administrator can diagnose network connectivity via the PING and TRACEROUTE utility.

Please click on **Utilities -> Network Utility** and follow the below setting



- **Ping** : This utility will help ping other devices on the network to verify connectivity. Ping utility, using ICMP packets, detects connectivity and latency between two network nodes. As result of that, packet loss and latency time are available in the **Result** field while running the PING test.
  - ➔ **Destination IP/Domain** : Enter desired domain name, i.e. [www.google.com](http://www.google.com), or IP address of the destination, and click **ping** button to proceed. The ping result will be shown in the **Result** field.




→ **Count** : By default, it's 5 and the range is from 1 to 50. It indicates number of connectivity test.


- **Traceroute** : Allows tracing the hops from the TEW-676APBO device to a selected outgoing IP address. It should be used for the finding the route taken by ICMP packets across the network to the destination host. The test is started using the **Start** button, click **Stop** button to stopped test
  - **Destination Host** : Specifies the Destination Host for the finding the route taken by ICMP packets across the network.
  - **MAX Hop** : Specifies the maximum number of hops( max time-to-live value) traceroute will probe.

### Reboot

This function allows user to restart system with existing or most current settings when changes are made. Click **Reboot** button to proceed and take around three minutes to complete.




A reminder will be available for remaining time to complete. If power cycle is necessary, please wait till completion of the reboot process.




## Mounting bracket installation

### Package contents




### Install mounting triangle




Align the mounting triangle to the back of the access point. Securely tighten the mounting triangle by using the M5x10 screws and washers.

### Wall mount bracket




Position the provided mounting bracket to the desired location and mount as shown in the above image using the provided wood screws and plugs.

### Pole mount bracket



Insert and fasten the provided U-clamps to the pole as shown in the above image using the provided screw washers, spring washers and nuts.

### Installing brackets



Align the access point with the mount triangle installed with either the wall or pole mount. Using the provided M6x12 bolts tighten both mounts together as shown in the above image.

## Appendix

**WEB GUI Valid Characters**

Block	Field	Valid Characters
LAN	IP Address	IP Format; 1-254
	IP Netmask	128.0.0.0 ~ 255.255.255.252
	IP Gateway	IP Format; 1-254
	Primary DNS	IP Format; 1-254
	Secondary DNS	IP Format; 1-254
	Hostname	Length : 32 0-9, A-Z, a-z ~ ! @ # \$ % ^ * ( ) _ + - { }   : < > ? [ ] / ; ` , . =
WAN	Manual MAC Address	12 HEX chars
	IP Address	IP Format; 1-254
	IP Netmask	128.0.0.0 ~ 255.255.255.252
	IP Gateway	IP Format; 1-254

	Hostname	Length : 32
		0-9, A-Z, a-z
		~ ! @ # \$ % ^ * ( ) _ + - { }   : < > ? [ ] / ; ` , . =
	User name	Length : 32
		0-9, A-Z, a-z
		~ ! @ # \$ % ^ * ( ) _ + - { }   : < > ? [ ] / ; ` , . =
	Password	
	MTU	576 ~ 1492 for PPPoE; 1400 ~ 1460 for PPTP
Idle Time	0 ~ 60 minutes	
Primary DNS	IP Format; 1-254	
Secondary DNS	IP Format; 1-254	
<b>DDNS</b>	Hostname	Length : 32
		0-9, A-Z, a-z
		@ - _ .
	User Name	Length : 32
		0-9, A-Z, a-z
		~ ! @ # \$ % ^ * ( ) _ + - { }   : < > ? [ ] / ; ` , . =
Password		

<b>DHCP Server</b>	Start IP	IP Format; 1-254
	End IP	IP Format; 1-254
	DNS1 IP	IP Format; 1-254
	DNS2 IP	IP Format; 1-254
	WINS IP	IP Format; 1-254
	Domain	Length : 32 0-9, A-Z, a-z ~ ! @ # \$ % ^ * ( ) _ + - { }   : < > ? [ ] / ; ` , . =
	Lease Time	600 ~ 99999999
	<b>Block</b>	<b>Field</b>
<b>Management</b>	System Name/ Location	Length : 32 0-9, A-Z, a-z Space ~ ! @ # \$ % ^ * ( ) _ + - { }   : < > ? [ ] / ; ` , . =
		Description

	Password	Length : 4 ~ 30
		0-9, A-Z, a-z
		~ ! @ # \$ % ^ * ( ) _ + - { }   : < > ? [ ] ; ` , . =
	HTTP/ HTTPS Port	1 ~ 65535
	Telnet/ SSH Port	1 ~ 65535
<b>SNMP</b>	RO/RW community	Length : 32
		0-9, A-Z, a-z
		~ ! @ # \$ % ^ * ( ) _ + - { }   : < > ? [ ] ; ` , . =
	RO/RW user	Length : 31
		0-9, A-Z, a-z
		~ ! @ # \$ % ^ * ( ) _ + - { }   : < > ? [ ] ; ` , . =
	RO/RW password	Length : 8 ~ 32
		0-9, A-Z, a-z
		~ ! @ # \$ % ^ * ( ) _ + - { }   : < > ? [ ] ; ` , . =
	Community	Length : 32
		0-9, A-Z, a-z
		~ ! @ # \$ % ^ * ( ) _ + - { }   : < > ? [ ] ; ` , . =

	IP	IP Format; 1-254
<b>General Setup</b>	Tx Power	1-100 %
<b>Wireless Profile</b>	Profile Name	32 chars
	ESSID	Length : 31 Space 0-9, A-Z, a-z ~ ! @ # \$ % ^ * ( ) _ + - { }   : < > ? [ ] / ; ` , . =
	WEP Key	10, 26 HEX chars or 5, 13 ASCII chars
	Pre-shared Key	8 ~ 63 ASCII chars; 64 HEX chars
<b>Advanced Setup</b>	Beacon Interval	20 ~ 1024
	Date Beacon Rate	1 ~ 255
	Fragment Threshold	256 ~ 2346
	RTS Threshold	1 ~ 2347
<b>Block</b>	<b>Field</b>	<b>Valid Characters</b>



<b>Virtual AP Setup</b>	ESSID	Length : 31 Space 0-9, A-Z, a-z ~!@#\$%^*()_+-{ :<>?[]/;'`.,=	
	Maximum Clients	1 ~ 32	
	VLAN ID	1 ~ 4094	
	WEP Key	10, 26 HEX chars or 5, 13 ASCII chars	
	Group Key Update Period	>=60 seconds	
	PMK Cache Period	> 0 minute	
	Pre-Shared Key	8 ~ 63 ASCII chars; 64 HEX chars	
	Radius Server IP	IP Format; 1-254	
	Radius Port	1 ~ 65535	
	Shared Secret	8 ~ 64 characters	
	Session Timeout	>= 60 seconds; 0 is disable	
	<b>WDS Setup</b>	WEP Key	10, 26 HEX chars or 5, 13 ASCII chars

	TKIP Key	8 ~ 63 ASCII chars; 64 HEX chars
	AES Key	8 ~ 63 ASCII chars; 64 HEX chars
	Peer's MAC Address	12 HEX chars
	Description	32 chars
<b>IP Filter</b>	Source Address	IP Format; 1-254
	Source Mask	0 ~ 32
	Source Port	1 ~ 65535
	Destination Address	IP Format; 1-254
	Destination Mask	0 ~ 32
	Destination Port	1 ~ 65535
<b>MAC Filter</b>	MAC address	MAC Format; 12 HEX chars
<b>Virtual Server</b>	Description	32 chars
	Private IP	IP Format; 1-254
	Private/ Public Port	1 ~ 65535
<b>DMZ</b>	IP Address	IP Format; 1-254
<b>QoS/</b>	Comment	32 chars

<b>Parental Control</b>	MAC Address	MAC Format; 12 HEX chars
	Local/ Destination IP	IP Format; 1-254
	Local/ Destination Port	1 ~ 65535
	Upload & Download	8 ~ 8192 digital number

**MCS Data Rate**

The table below shows the relationships between the variables that allow for the maximum data rate

**Note :**

- ✓ When MCS=32, only Short Guard Interval option is supported, Channel Bandwidth=20 is not supported. If Channel Bandwidth=40, the HT duplicate 6Mbps.
- ✓ When MCS=0~7(One Tx Stream), Guard Interval and Channel Bandwidth are supported
- ✓ When MCS=8~15(Two Tx Stream), Guard Interval and Channel Bandwidth are supported

MCS Index	Modulation	Data Rate (Mb/s)			
		Channel Bandwidth = 20		Channel Bandwidth = 40	
		Long Guard Interval	Short Guard Interval	Long Guard Interval	Short Guard Interval
0	BPSK	6.5	7.2	13.5	15.0
1	QPSK	13.0	14.4	27.0	30.0
2	QPSK	19.5	21.7	40.5	45.0
3	16-QAM	26.0	28.9	54.0	60.0
4	16-QAM	39.0	43.3	81.0	90.0
5	64-QAM	52.0	57.8	108.0	120.0
6	64-QAM	58.5	65.0	121.5	135.0
7	64-QAM	65.0	72.2	135.0	157.5
8	BPSK	13.0	14.4	27.0	30.0
9	QPSK	26.0	28.9	54.0	60.0
10	QPSK	39.0	43.3	81.0	90.0
11	16-QAM	52.0	57.8	108.0	120.0
12	16-QAM	78.0	86.7	162.0	180.0
13	64-QAM	104.0	115.6	216.0	240.0
14	64-QAM	117.0	130.0	243.0	270.0
15	64-QAM	130.0	114.4	270.0	300.0

### System Manager Privileges

There are two system management accounts for maintaining the system; namely, the **root** and **admin** accounts are with different levels of privileges. The root manager account is empowered with full privilege to Read & Write while the admin manager account is Read only.

The following table display CPE admin account's privileges.


Main Menu	Sub Menu	Group	Admin Privilege
<b>System</b>	Operating		Read
	WAN		Read
	LAN		Read & Write
	DDNS		Read & Write
	Time Server		Read & Write
	UPNP		Read & Write
	SNMP		Read
<b>Wireless</b>	General		Read
	Advanced		Read
	Site Survey		Read
<b>Advance</b>	DMZ		Read
	IP Filter		Read
	MAC Filter		Read
	Virtual Server		Read
	Parental		Read

	QoS		Read
<b>Administrator</b>	<b>Management</b>	System	Read
		Root	Read
		Admin	Read & Write
		Login	Read
		Ping	Read
	<b>Profile Settings</b>	Backup Settings	Read & Write
		Restore	Read
		Reset	Read
	System		Read
	Network		Read & Write
	Reboot		Read & Write


## Windows TCP/IP Settings

### ■ Windows XP


1. Click **Start** -> **Settings** -> **Control Panel**, and then “**Control Panel**” window appears. Click on “**Network Connections**”, and then “**Network Connections**” window appears.





2. Click right on “**Local Area Connection**”, and select **Properties**.



3. In “**Local Area Connection Properties**” window, select “**Internet Protocol (TCP/IP)**” and click on **Properties** button.




4. Select “**Use the following IP address**”, and type in  
**IP address : 192.168.2.100**  
**Subnet mask : 255.255.255.0**



## Enabling UPnP in Windows XP

1. Open the **"Add/Remove Programs"** control panel, and then click on **"Add/Remove Windows Components"** in the sidebar. Scroll down and find **"Networking Services"**, highlight it, and then click **Details**.
2. In the **"Networking Services"** window, ensure that the **"Internet Gateway Device"** and **"UPnP User Interface"** options are checked. If they are not, check it to enable them, as shown below, and click OK to continue.





- Next, in the “Control panel”, open the “Administrative Tools” and then open “Services”. Scroll down until you find the “SSDP Discovery Interface”. If the Status is not **Started**, double-click on *SSDP Discovery Interface* to open the service properties. Change the startup type to **Automatic**, then close the properties. Now, right-click on *SSDP Discovery Services*, and choose **Start** from the pop-up menu. The SSDP Discovery Service will then be running and start each time you boot.
- After enabling UPnP and starting the SSDP Discovery Service, it may take few minutes for the “TEW-675APBO/ TEW-676APBO” to be discovered and appear in your “My Network Places”.

**Specification**

<b>Hardware</b>	
<b>Standards</b>	Wired: IEEE 802.3u (100Base-TX) Wireless: IEEE 802.11a/n (5 GHz)
<b>LED Indicator</b>	Power, LAN, WLAN (wireless activity)
<b>Antenna</b>	12dBi patch antenna (polarization: V30°, H30°)
<b>PoE</b>	1 x 10/100Mbps RJ-45 PoE port, Passive only (non-802.3af compliant)
<b>Dimension (L x W x H)</b>	215 x 122 x 66 mm ( 8.5 x 4.8 x 2.6 in)
<b>Weight</b>	1kg (2.2lbs)
<b>Power Consumption</b>	15 Watts (max.)
<b>Management</b>	Web browser (HTTP/HTTPS), SNMP (v2c and 3), Telnet, SSH
<b>Wind Speed Support</b>	210 km/hr
<b>Waterproof</b>	IP66/67 compliant
<b>Temperature</b>	Operating: -20° ~ 60°C (-4°F ~ 140°F) Storage: 0° ~ 60°C (32°F ~ 140°F)
<b>Humidity</b>	Max. 95% (non-condensing)
<b>Power</b>	PoE power injector DC output: 48VDC, 0.4A
<b>Certifications</b>	FCC
<b>Wireless</b>	
<b>Frequency</b>	5.725 ~ 5.845 GHz
<b>Modes</b>	Router, Access Point + WDS, WDS, CPE, Client Bridge + Repeater, CPE + Access Point
<b>Virtual Access Points</b>	7
<b>Associated Clients (max)</b>	224 (AP Mode), 32 (Repeater Mode)
<b>*Coverage</b>	5km line-of-sight
<b>Modulation Technique</b>	802.11a: OFDM with BPSK, QPSK, QAM and 64QAM 802.11n: BPSK, QPSK, 16-QAM, 64-QAM
<b>Data Rate (auto-fallback)</b>	802.11a: up to 54Mbps 802.11a/n: up to 300Mbps
<b>Security</b>	64/128/152-bit WEP, WPA /WPA2-PSK, WPA/WPA2- RADIUS for AP/CPE mode, WEP/WPA2-PSK for WDS mode MAC filter (20 entries) and IP filter (20 entries)
<b>Output Power</b>	Up to 26dBm (FCC)
<b>Receiving Sensitivity</b>	802.11a: -91dBm (typical) @ 6Mbps

	802.11a/n: -68dBm (typical) @ 300Mbps
<b>Channels</b>	FCC: 149,153,157,161,165

## **Limited Warranty**

TRENDnet warrants its products against defects in material and workmanship, under normal use and service, for the following lengths of time from the date of purchase.

TEW-676APBO – 3 Years Warranty

AC/DC Power Adapter, Cooling Fan, and Power Supply carry 1 year warranty.

If a product does not operate as warranted during the applicable warranty period, TRENDnet shall reserve the right, at its expense, to repair or replace the defective product or part and deliver an equivalent product or part to the customer. The repair/replacement unit's warranty continues from the original date of purchase. All products that are replaced become the property of TRENDnet. Replacement products may be new or reconditioned. TRENDnet does not issue refunds or credit. Please contact the point-of-purchase for their return policies.

TRENDnet shall not be responsible for any software, firmware, information, or memory data of customer contained in, stored on, or integrated with any products returned to TRENDnet pursuant to any warranty.

There are no user serviceable parts inside the product. Do not remove or attempt to service the product by any unauthorized service center. This warranty is voided if (i) the product has been modified or repaired by any unauthorized service center, (ii) the product was subject to accident, abuse, or improper use (iii) the product was subject to conditions more severe than those specified in the manual.

Warranty service may be obtained by contacting TRENDnet within the applicable warranty period and providing a copy of the dated proof of the purchase. Upon proper submission of required documentation a Return Material Authorization (RMA) number will be issued. An RMA number is required in order to initiate warranty service support for all TRENDnet products. Products that are sent to TRENDnet for RMA service must have the RMA number marked on the outside of return packages and sent to TRENDnet prepaid, insured and packaged appropriately for safe shipment. Customers shipping from outside of the USA and Canada are responsible for return shipping fees. Customers shipping from outside of the USA are responsible for custom charges, including but not limited to, duty, tax, and other fees.

**WARRANTIES EXCLUSIVE:** IF THE TRENDNET PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, THE CUSTOMER'S SOLE REMEDY SHALL BE, AT TRENDNET'S OPTION, REPAIR OR REPLACE. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. TRENDNET NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION MAINTENANCE OR USE OF TRENDNET'S PRODUCTS.

TRENDNET SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR OR MODIFY, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD.

**LIMITATION OF LIABILITY:** TO THE FULL EXTENT ALLOWED BY LAW TRENDNET ALSO EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATE, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT TRENDNET'S OPTION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE AFFECTED IF ANY REMEDY PROVIDED HEREIN SHALL FAIL OF ITS ESSENTIAL PURPOSE.

**Governing Law:** This Limited Warranty shall be governed by the laws of the state of California.

Some TRENDnet products include software code written by third party developers. These codes are subject to the GNU General Public License ("GPL") or GNU Lesser General Public License ("LGPL").

Go to <http://www.trendnet.com/gpl> or <http://www.trendnet.com> Download section and look for the desired TRENDnet product to access to the GPL Code or LGPL Code.

These codes are distributed WITHOUT WARRANTY and are subject to the copyrights of the developers. TRENDnet does not provide technical support for these codes. Please go to <http://www.gnu.org/licenses/gpl.txt> or <http://www.gnu.org/licenses/lgpl.txt> for specific terms of each license.

PWP05202009v2



## Product Warranty Registration

Please take a moment to register your product online.  
Go to TRENDnet's website at <http://www.trendnet.com/register>

TRENDnet  
20675 Manhattan Place  
Torrance, CA 90501. USA

Copyright ©2012. All Rights Reserved. TRENDnet.